

[Manuals.plus](#) /

› [SoulBay](#) /

› SoulBay Flameless Candles (Model LC004RS) - Instruction Manual

SoulBay LC004RS

SoulBay Flameless Candles (Model LC004RS) - Instruction Manual

Model: LC004RS

1. INTRODUCTION

Thank you for choosing SoulBay Flameless Candles. This instruction manual provides essential information for the safe and efficient use of your 12-piece USB rechargeable LED tea light set. Please read this manual thoroughly before initial use and retain it for future reference.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 12 x SoulBay Flameless LED Tea Lights
- 1 x Charging Base
- 1 x Remote Control
- 1 x USB Power Cable

3. PRODUCT OVERVIEW

3.1 Components

The SoulBay Flameless Candle set consists of LED tea lights, a charging base, and a remote control for convenient operation.



An overview of the SoulBay flameless candle set, showing twelve LED tea lights arranged on their charging base, alongside the remote control and a USB-C charging cable.

3.2 Key Features

- **Rechargeable Design:** Eliminates the need for frequent battery replacement, offering 40-50 hours of continuous light after a 2-hour charge.
- **Remote Control:** Includes a 12-key remote for easy power control, brightness adjustment, light mode selection, and timer settings.
- **Realistic Flickering:** Soft flickering light mimics a natural flame, enhancing ambiance.
- **Long-Lasting Battery:** Built-in lithium batteries provide approximately 42 hours of illumination per full charge.
- **Versatile Application:** Suitable for various indoor and outdoor decorative purposes, including centerpieces, weddings, and holiday decorations.

4. SETUP

4.1 Initial Charging

Before first use, fully charge all tea lights. Place each candle into a slot on the charging base. Connect the USB power cable to the charging base and a compatible USB power source (e.g., wall adapter, computer USB port). The indicator light on each candle will glow red during charging and turn off automatically when fully charged.

Rechargeable Tea Lights with Charging Station

2 Hours
Charging

50+ Hours
Lasting



Charging:



The candle's red indicator light on.

Once fully charged:



The charging base's light turns from red to green.



USB-C Port

A close-up of the charging station with several flameless candles inserted. The image highlights the USB-C charging port and indicates the red light for charging and green light for fully charged status.

4.2 Placement

Place the flameless candles in desired locations. Ensure they are on a stable, flat surface. While suitable for indoor and outdoor

use, they are not waterproof and should be protected from direct water exposure.

5. OPERATING INSTRUCTIONS

5.1 Powering On/Off

- **Manual Switch:** Each candle has a small switch on its bottom. Slide the switch to the "ON" position to turn on the candle, and to "OFF" to turn it off.
- **Remote Control:** Use the "ON" and "OFF" buttons on the remote control to power all candles within range simultaneously.

5.2 Remote Control Functions

The included remote control allows for convenient adjustment of the candles' settings:



An image detailing the functions of the remote control, including buttons for power, brightness adjustment (20% to 100%), four lighting modes (Slow Flicker, Fast Flicker, Breathing Flicker, Steady Light), and four timer options (2, 4, 6, 8 hours).

- **Power (ON/OFF):** Turns all candles on or off.
- **Luminosity (+/-):** Adjusts brightness levels (5 levels from 20% to 100%).
- **Mode:** Cycles through different lighting modes:
 - **SL (Slow Flicker):** Gentle, slow flickering effect.
 - **FL (Fast Flicker):** More rapid flickering effect.
 - **BF (Breathing Flicker):** A subtle, pulsating flicker.
 - **Light (Steady Light):** Constant illumination without flickering.
- **Timer (2H/4H/6H/8H):** Sets the candles to automatically turn off after 2, 4, 6, or 8 hours. The timer operates on a 24-hour cycle, meaning if set for 4 hours at 6 PM, they will turn off at 10 PM and automatically turn on again at 6 PM the next day.

6. MAINTENANCE

- **Cleaning:** Wipe the candles and charging base with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.
- **Handling:** Always handle the candles by their body. Avoid grabbing or twisting the delicate wick, as this can cause damage.
- **Storage:** When not in use for extended periods, store the candles and charging base in a cool, dry place. Ensure candles are fully charged before storing to maintain battery health.



An instructional image showing the correct way to handle the flameless candles by holding the body, and an incorrect way by grabbing the delicate wick, which can cause damage.

7. TROUBLESHOOTING

Problem	Possible Solution
Candles do not turn on.	Ensure the manual switch on the bottom of each candle is in the "ON" position. Check if the candles are fully charged. Replace the remote control battery if necessary.
Remote control is not working.	Ensure there is a clear line of sight between the remote and the candles. Check the remote control battery and replace if needed. Ensure candles are powered on via their manual switch.
Candles do not charge.	Ensure the USB cable is securely connected to both the charging base and the power source. Verify the power source is active. Ensure candles are properly seated in the charging slots.
Difficulty removing candles from charging base.	Gently twist and lift the candle from its slot. Avoid excessive force to prevent damage to the candle or base.
Wick appears damaged or broken.	Avoid handling the candles by the wick. If damage occurs, contact customer support for assistance.

8. SPECIFICATIONS

Home Decor



An image illustrating the dimensions of a single flameless tea light candle: 1.57 inches (4 cm) in diameter and 2.16 inches (5.5 cm) in height.

Feature	Detail
Model Number	LC004RS
Dimensions (each candle)	1.57"D x 1.57"W x 2.17"H (4cm x 4cm x 5.5cm)

Feature	Detail
Item Weight	1.1 Pounds (total package)
Material	Acrylonitrile Butadiene Styrene (ABS)
Light Source Type	LED
Power Source	Battery Powered (Rechargeable Lithium Ion)
Charging Time	Approx. 1.5-2 hours
Operating Time (per charge)	Approx. 40-50 hours
Control Method	Remote Control, Manual Switch
Special Features	Dimmable, Energy Efficient, Lightweight, Rechargeable, Timer
Water Resistance Level	Not Water Resistant

9. SAFETY INFORMATION

- Keep out of reach of children and pets.
- Do not expose candles or charging base to extreme temperatures, direct sunlight, or open flames.
- Do not immerse candles or charging base in water or other liquids.
- Use only the provided USB power cable and charging base.
- Do not attempt to disassemble or modify the product.
- Dispose of batteries and electronic components according to local regulations.

10. WARRANTY AND SUPPORT

SoulBay products are designed for quality and reliability. For any questions, concerns, or technical support regarding your flameless candles, please contact SoulBay customer service. Please refer to your purchase documentation for specific warranty details and contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question