

Bruder 02683

Bruder 02683 MB Sprinter Police Emergency Vehicle Instruction Manual

Model: 02683

1. PRODUCT OVERVIEW

The Bruder 02683 MB Sprinter Police Emergency Vehicle is a highly detailed and functional toy designed for realistic play scenarios. This model is a new addition to the BRUDER police force, offering comprehensive equipment for various police operations.

Key Features:

- **Realistic Features:** Includes opening doors (cab, sliding side door, and rear doors) for realistic play scenarios.
- **Playtime Action:** Equipped with a bworld policeman figure and accessories (e.g., pylons) for staging traffic control, search and rescue, or suspect apprehension.
- **Secure Transport:** Features a separate cell for holding suspects, ensuring their safe transport in role-playing scenarios.
- **Expandable Play World:** Designed to be compatible with the bworld police station (item no. 62732) for expanded police adventures.
- **Detailed Dimensions:** Size 43.5 cm × 16.3 cm × 18.5 cm (approximately 17.1 inches x 6.4 inches x 7.3 inches).



Image 1: Bruder MB Sprinter Police Emergency Vehicle with Policeman figure and accessories.

2. SAFETY INFORMATION

WARNING! Not suitable for children under 36 months. Choking hazard - small parts.

Manufacturer recommended age: 36 months - 15 years.

3. WHAT'S IN THE BOX

- MB Sprinter Police emergency vehicle with Light & Sound Module
- Policeman figure

4. SETUP

4.1 Battery Installation for Light & Sound Module

1. Locate the Light & Sound Module on the roof of the MB Sprinter vehicle.
2. Carefully remove the module from its housing (if detachable) or locate the battery compartment.
3. Using a small screwdriver (not included), open the battery compartment cover.
4. Insert 3 LR44 batteries (required, not included) into the compartment, ensuring correct polarity (+/-).
5. Close the battery compartment cover and secure it with the screw.
6. Re-attach the Light & Sound Module to the vehicle's roof if it was removed.

4.2 Figure and Accessory Placement

- The bworld Policeman figure is articulated and can be placed in the driver's seat or positioned outside the vehicle.

- Accessories such as pylons can be set up to create various play scenarios.



Image 2: The MB Sprinter Police vehicle ready for action with its accessories.

5. OPERATING INSTRUCTIONS

5.1 Opening and Closing Doors

- **Cab Doors:** Gently pull the door handles to open the front cab doors. Push to close until they click securely.
- **Sliding Side Door:** Slide the side door open to access the main compartment. Slide back to close.
- **Rear Doors:** Open the rear doors to access the vehicle's interior, including the integrated cell. Close firmly.



Image 3: The MB Sprinter with its side door open, revealing the interior.

5.2 Activating Light & Sound Module

- Press the buttons on the Light & Sound Module located on the roof to activate various light and sound functions (e.g., siren, engine sounds).
- Press again to cycle through sounds or deactivate.

5.3 Using the Integrated Cell

- The rear compartment features a separate cell for role-playing scenarios involving suspect transport.
- Place the policeman figure or other bworld figures inside the cell for secure transport.



Image 4: Interior view of the MB Sprinter, highlighting the integrated cell.

5.4 Official Product Video

Video 1: Official product demonstration of the Bruder 02683 MB Sprinter Police Emergency Vehicle,

showcasing its features and play possibilities.

5.5 Related Bruder Sprinter Videos

Video 2: Demonstration of the Bruder MB Sprinter 02670, highlighting general Sprinter features that may apply to your model.

Video 3: Demonstration of the Bruder 02672 MB Sprinter Camper, showing additional functionalities of Bruder Sprinter models.

6. MAINTENANCE

6.1 Cleaning

- Wipe the vehicle and figures with a damp cloth to remove dust and dirt.
- Avoid using harsh chemicals or abrasive cleaners, as these may damage the plastic.

6.2 Storage

- Store the toy in a cool, dry place away from direct sunlight to prevent material degradation.
- Keep small accessories in a designated container to prevent loss.

6.3 Battery Care

- Remove batteries from the Light & Sound Module if the toy will not be used for an extended period to prevent leakage.
- Dispose of used batteries responsibly according to local regulations.

7. TROUBLESHOOTING

7.1 Light & Sound Module Not Functioning

- Check if the 3 LR44 batteries are correctly installed and are not depleted. Replace if necessary.
- Ensure the module is securely attached to the vehicle's roof.

7.2 Stiff Moving Parts

- Inspect for any debris or foreign objects obstructing the moving parts (doors, wheels).
- Apply gentle, even pressure when operating moving parts. Avoid excessive force.

8. SPECIFICATIONS

- **Product Dimensions:** 17.1 x 6.4 x 7.3 inches
- **Item Weight:** 2.82 pounds

- **Item Model Number:** 02683
- **Manufacturer Recommended Age:** 36 months - 15 years
- **Batteries:** 3 LR44 batteries required (not included)
- **Manufacturer:** Bruder

9. WARRANTY AND SUPPORT

Specific warranty information for this product is not available in the provided data. For any product support or warranty inquiries, please refer to the official Bruder Toys website or contact their customer service directly.