

[Manuals.plus](#) /

› [ROMP](#) /

› ROMP Free X Clitoral Stimulator User Manual

ROMP Free X

ROMP Free X Clitoral Stimulator User Manual

Model: Free X

INTRODUCTION

The ROMP Free X is a clitoral stimulator designed to provide pleasure through innovative Pleasure Air Technology. This device offers gentle yet powerful air pressure waves for a unique sensation. It is rechargeable, waterproof, and features multiple intensity levels for a personalized experience.



Image: The ROMP Free X clitoral stimulator, a compact purple device with a light purple stimulation head.

KEY FEATURES

- **Pleasure Air Technology:** Stimulates the clitoris with gentle, non-contact air pressure waves.
- **10 Intensity Levels:** Offers a wide range of stimulation from soft waves to intense peaks.
- **USB Rechargeable:** Convenient charging with a full charge providing up to 45 minutes of use.
- **Waterproof (IPX7):** Suitable for use in water and easy to clean.
- **Body-Safe Silicone:** Made from high-quality, safe materials.
- **Travel-Friendly:** Compact design with a travel pouch for discretion and portability.

ROMP



Pleasure air technology



Durée d'utilisation : 45 min



10 niveaux d'intensité



Silicone sans danger pour le corps

Image: A graphic illustrating the key features of the ROMP Free X, including Pleasure Air Technology, 45 minutes of use, 10 intensity levels, and body-safe silicone.

SAFETY INFORMATION

- Read all instructions before first use.
- This product is for external use only.
- Do not use if the device appears damaged.
- Discontinue use if any discomfort or irritation occurs.
- Keep out of reach of children.
- Consult a healthcare professional if you have any medical concerns.

PACKAGE CONTENTS

- 1 x ROMP Free X Clitoral Stimulator

- 1 x USB Charging Cable
- 1 x Travel Pouch
- 1 x User Manual (this document)

PRODUCT OVERVIEW

The ROMP Free X features a sleek, ergonomic design with intuitive controls. The main body houses the motor and battery, while the soft silicone stimulation head provides the Pleasure Air sensation.

Controls:

- **(+) Button:** Press and hold for 2 seconds to turn on. Short press to increase intensity.
- **(-) Button:** Press and hold for 2 seconds to turn off. Short press to decrease intensity.



Image: The ROMP Free X device, highlighting its power and intensity control buttons.

SETUP

1. Charging the Device

1. Locate the charging port on the device.
2. Connect the provided USB charging cable to the device and a USB power source (e.g., computer, wall adapter).
3. The indicator light will illuminate during charging. A full charge takes approximately 120 minutes and provides up to 45 minutes of use.
4. Disconnect the cable once fully charged.

ROMP



Image: The ROMP Free X device being charged via its USB cable.

2. Preparation for First Use

1. Before the first use, and after each subsequent use, clean the device as described in the Maintenance section.
2. For enhanced comfort and glide, apply a water-based lubricant to the stimulation head and your clitoris.

OPERATING INSTRUCTIONS

1. Power On/Off

- To turn on: Press and hold the(+) button for 2 seconds.
- To turn off: Press and hold the(-) button for 2 seconds.

2. Adjusting Intensity

- To increase intensity: Short press the(+) button. There are 10 intensity levels.

- To decrease intensity: Short press the(-) button.

3. Usage

1. Remove the travel cap from the device.
2. Position the stimulation head over your clitoris, applying light pressure. Adjust the position to find what feels most comfortable and pleasurable.
3. Use the (+) and (-) buttons to cycle through the 10 intensity levels until you find your desired setting.
4. Relax and enjoy the experience.




Image: A diagram illustrating the two main steps for using the ROMP Free X: removing the cap and positioning the device for clitoral stimulation.

4. Alternative Usage Ideas

- The ROMP Free X can also be used to stimulate other erogenous zones, such as nipples or inner thighs.
- Explore using the device with a partner, allowing them to control the intensity for shared pleasure.

Des idées pour jouer



Image: A diagram suggesting alternative ways to use the ROMP Free X, including on nipples and for clitoral stimulation.

MAINTENANCE

1. Cleaning

- Always clean your ROMP Free X before and after each use.
- Wash the device with warm water and a mild, toy-friendly soap or a specialized toy cleaner.
- Rinse thoroughly with clean water.
- Pat dry with a lint-free cloth or allow to air dry completely.
- Do not use harsh chemicals, alcohol, or petroleum-based cleaners, as these can damage the silicone.

ROMP



Image: The ROMP Free X device shown in water, highlighting its waterproof design for easy cleaning.

2. Storage

- Store the device in its travel pouch in a clean, dry, and cool place.
- Avoid direct sunlight or extreme temperatures.
- Keep away from other silicone products to prevent material degradation.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or not charged.	Charge the device fully (approx. 120 minutes).

Problem	Possible Cause	Solution
Weak or no stimulation.	Incorrect placement or low intensity setting.	Adjust placement on the clitoris. Increase intensity using the (+) button. Ensure device is fully charged.
Device stops working during use.	Battery depleted.	Recharge the device.
Discomfort or irritation.	Lack of lubrication or allergic reaction.	Apply more water-based lubricant. Discontinue use if irritation persists and consult a doctor.

SPECIFICATIONS

Feature	Detail
Model	Free X
Brand	ROMP
Material	Silicone
Color	Violet
Dimensions (L x W x H)	13 x 10.5 x 6 cm (5.1 x 4.1 x 2.4 inches)
Weight	91 grams (3.2 ounces)
Battery Type	1 Lithium-ion (included)
Charging Time	Approx. 120 minutes
Usage Time	Up to 45 minutes on a full charge
Intensity Levels	10
Waterproof Rating	IPX7
Manufacturer	WOW Tech
Country of Origin	China

ROMP




Image: A technical drawing of the ROMP Free X with its dimensions indicated.

WARRANTY & SUPPORT

For warranty information and customer support, please refer to the official ROMP website or contact your retailer. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CSG35ZC2>

More documents and user manuals: **<https://manuals.plus/>**