

[Manuals.plus](#) /

› [Bewinner](#) /

› Bewinner Portable A4 Thermal Printer User Manual

## Bewinner Bewinners36fomz9kd

# Bewinner Portable A4 Thermal Printer

## INSTRUCTION MANUAL

Model: Bewinners36fomz9kd

---

### Product Overview

The Bewinner Portable A4 Thermal Printer is a compact, inkless printing solution designed for mobile use. It utilizes thermal technology to produce clear prints without the need for ink cartridges, ribbons, or toner. This printer is compatible with both iOS and Android devices via Bluetooth connectivity, making it suitable for various printing tasks on the go.

# PORTABLE PRINTER WITH CLEAR PRINT EFFECT

GOOD ASSISTANT FOR MOBILE OFFICE

ONE-CLICK PRINTING

PRINT VARIOUS

DOCUMENTS



Image: The Bewinner Portable A4 Thermal Printer, highlighting its compact and modern design.

## Key Features:

- **Inkless Thermal Printing:** Eliminates the need for ink, ensuring clean and efficient operation.
- **A4 Paper Compatibility:** Supports thermal paper with widths from 210mm to 218mm.
- **Bluetooth Connectivity:** Seamlessly connects with iOS and Android smartphones.
- **Portable Design:** Compact dimensions (265 x 58 x 30 mm) for easy transport.
- **Long Battery Life:** Integrated 1000 mAh rechargeable lithium battery, providing approximately 90 sheets of continuous A4 printing.
- **Automatic Shut-off:** Powers down after 30 minutes of inactivity to conserve battery.

## Setup Guide

### 1. Charging the Printer

Before initial use, fully charge the printer. Connect the provided USB Type-C cable to the printer's charging interface and a suitable power source. A full charge takes approximately 1.5 hours.

### 2. Loading Thermal Paper

1. Open the paper compartment cover.
2. Insert a roll of A4 thermal paper (210mm to 218mm width) into the compartment, ensuring the printable side faces the print head.
3. Gently close the paper compartment cover until it clicks into place. Ensure the paper is aligned correctly.

### 3. App Installation and Bluetooth Connection

1. **Install the App:** For both Android and iOS users, search for "iPrint" in your device's app store and download the application.
2. **Enable Bluetooth:** Turn on the Bluetooth function on your smartphone.
3. **Open the App:** Launch the "iPrint" application.
4. **Connect to Printer:** In the app, tap the "Select Device" button (usually located at the top) to navigate to the "My Devices" page.
5. Locate and tap on the Bluetooth device name that begins with "GT08" to establish a connection. If the device does not appear, tap the "Refresh" button and try again.



Image: The printer connected to a smartphone, illustrating the wireless printing capability.

## Operating Instructions

Once the printer is charged, paper is loaded, and it is successfully connected to your smartphone via the "iPrint" app, you can begin printing.

1. Open the document, image, or content you wish to print within the "iPrint" app.
2. Adjust print settings such as density, size, or number of copies as needed within the app.
3. Initiate the print command from the app. The printer will begin printing at a speed of 10mm/s.



Printed at 10mm/s

Image: The printer in operation, demonstrating its printing speed and output.

The printer supports various document types and can print small notes, banners, and standard documents. Ensure the thermal paper is correctly inserted for optimal print quality.



Image: An example of a document printed using the Bewinner A4 thermal printer.

## Maintenance

### Cleaning the Print Head:

- Ensure the printer is turned off and disconnected from any power source.
- Open the paper compartment.
- Gently wipe the print head with a soft, lint-free cloth lightly dampened with isopropyl alcohol. Allow it to dry completely before closing the compartment or using the printer.

### Storage:

Store the printer in a cool, dry place away from direct sunlight and extreme temperatures. Remove any paper rolls if storing for an extended period.

## Troubleshooting

### Bluetooth Connection Issues:

If the Bluetooth device is not found or fails to connect, perform the following steps:

1. **Restart the Printer:** Turn the printer off and then on again. Ensure it is not connected to any other device.
2. **Check Phone Bluetooth:** Verify that Bluetooth is enabled on your mobile phone.
3. **Enable Location Services:** Activate GPS (location information) in your phone's settings. Then, go to the app's "Permission Management" settings and enable location permission for the "iPrint" app.
4. **Refresh Device List:** Within the "iPrint" app, go to "My Devices" and tap the refresh button to search for devices again. Then, tap on the device to connect.

### Poor Print Quality:

- Ensure you are using high-quality thermal paper.
- Clean the print head as described in the Maintenance section.
- Check the print density settings in the "iPrint" app and adjust if necessary.

## Specifications

<b>Item Type</b>	Inkless Thermal Printer
<b>Connectivity</b>	Bluetooth 4.0 or higher, USB
<b>Supported App System</b>	iOS, Android
<b>Print Resolution</b>	200 dpi
<b>Battery Capacity</b>	1000 mAh rechargeable lithium battery (built-in)
<b>Auto Shut-off</b>	30 minutes of inactivity
<b>Charging Time</b>	Approximately 1.5 hours
<b>Continuous Printing</b>	Approx. 90 sheets of A4 thermal paper
<b>Print Speed</b>	10 mm/s
<b>Applicable Paper Width</b>	210 mm to 218 mm thermal paper
<b>Charging Interface</b>	Type-C
<b>Dimensions (L x W x H)</b>	265 x 58 x 30 mm (approx.)
<b>Model Number</b>	Bewinners36fomz9kd

## Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or contact Bewinner customer service directly. Specific warranty terms may vary by region and retailer.