

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Jackson](#) /

› [Jackson X Series Dinky DK1 H Electric Guitar User Manual](#)

### Jackson XDINKYDK1HSKULLKAOS

# Jackson X Series Dinky DK1 H Electric Guitar User Manual

Model: XDINKYDK1HSKULLKAOS

## INTRODUCTION

The Jackson X Series Dinky DK1 H is a solidbody electric guitar designed for high-performance playing. It features a lightweight Dinky-style nyatoh body, a single high-output humbucker pickup, and a Floyd Rose Special double-locking tremolo system. The graphite-reinforced maple neck with a smooth laurel fingerboard ensures comfortable playability and durability. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your instrument.



Front view of the Jackson X Series Dinky DK1 H Electric Guitar, showcasing its unique Scull Kaos graphic finish, single humbucker pickup, and Floyd Rose tremolo system.

## SETUP

---

### 1. Unboxing and Inspection

- Carefully remove the guitar from its packaging.
- Inspect the instrument for any signs of damage during shipping.
- Ensure all included accessories (tremolo arm, adjustment wrenches) are present.

### 2. Initial Tuning and String Stretching

- Due to the Floyd Rose system, initial tuning requires careful attention.
- Loosen the locking nuts at the headstock.
- Tune the strings to standard pitch (E-A-D-G-B-e) using the tuning machines.
- Gently stretch each string by pulling it away from the fretboard. Retune as necessary. Repeat this process several times until the strings hold their pitch.
- Once stable, tighten the locking nuts at the headstock. Fine-tuning can then be done using the fine tuners on the Floyd Rose bridge.



Close-up of the Jackson Dinky DK1 H headstock, showing the locking nuts that secure the strings for tuning stability with the Floyd Rose system.

### 3. Strap Attachment

- Attach your guitar strap securely to the strap buttons located on the body of the guitar.

---

## OPERATING

## 1. Controls Overview

The Jackson X Series Dinky DK1 H features a simplified control layout for direct tone shaping.

- **Volume Knob:** Controls the overall output level of the guitar. Turn clockwise to increase volume, counter-clockwise to decrease.
- **Tone Knob:** Adjusts the treble response. Turn clockwise for brighter tones, counter-clockwise for warmer, darker tones.
- **Pickup Selector Switch:** This model features a single humbucking pickup, so a traditional selector switch is not present. The single humbucker provides a powerful, focused tone.



Detailed view of the Floyd Rose Special double-locking tremolo system and the volume/tone control knobs on the Jackson Dinky DK1 H.

## 2. Floyd Rose Special Tremolo System

The Floyd Rose Special double-locking tremolo system allows for extreme pitch bending and dive bombs while maintaining tuning stability.

- **Tremolo Arm:** Insert the tremolo arm into its receptacle on the bridge. It can be adjusted for tension.

- **Using the Tremolo:** Gently push down on the arm to lower the pitch, or pull up to raise it. The locking nuts at the headstock and the fine tuners on the bridge work together to keep the guitar in tune even after heavy tremolo use.
- **Fine Tuners:** After locking the nuts, use the small knobs on the bridge to make minor pitch adjustments.

---

## MAINTENANCE

---

### 1. Cleaning

- **Body:** Wipe the body with a soft, lint-free cloth after each use to remove sweat and fingerprints. For deeper cleaning, use a guitar-specific polish.
- **Fretboard:** Periodically clean the laurel fretboard with a soft cloth. If it appears dry, apply a small amount of fretboard conditioner (e.g., lemon oil) to moisturize the wood.
- **Strings:** Wipe down strings after playing to extend their life and maintain tone.

### 2. String Changes

Changing strings on a Floyd Rose system requires a specific procedure to maintain bridge balance and tuning stability. Refer to dedicated Floyd Rose string change guides or consult a qualified guitar technician if you are unfamiliar with the process.

### 3. Fretboard Care

The laurel fretboard should be kept clean and moisturized. Avoid excessive moisture or harsh chemicals.

---

## TROUBLESHOOTING

---

### 1. Tuning Instability

- **Check Locking Nuts:** Ensure the locking nuts at the headstock are securely tightened after initial tuning.
- **String Stretching:** New strings require thorough stretching before they will hold tune reliably, especially with a tremolo system.
- **Floyd Rose Balance:** If the bridge is not level, it can cause tuning issues. This often requires professional adjustment.

### 2. No Sound or Weak Signal

- **Cable Connection:** Ensure your guitar cable is securely plugged into both the guitar and the amplifier.
- **Volume/Tone Knobs:** Check that the volume knob on the guitar and the amplifier are turned up.
- **Amplifier Settings:** Verify your amplifier is on and set to an appropriate input/channel.
- **Battery (if applicable):** While this model typically uses passive pickups, if you have any active components (e.g., aftermarket pickups), check the battery.

---

## SPECIFICATIONS

Feature	Detail
Model Number	XDINKYDK1HSKULLKAOS
Body Material	Nyatoh
Neck Material	Maple (Graphite-reinforced)
Fretboard Material	Laurel Wood
Scale Length	25.5 inches
Number of Strings	6
Pickup Configuration	H (1 Humbucking Pickup)
Bridge System	Floyd Rose Special Double-Locking Tremolo
Item Weight	11.92 pounds
Product Dimensions	44.6 x 18.3 x 4.7 inches
Color	Scull Kaos

## WARRANTY AND SUPPORT

For information regarding warranty coverage and customer support, please refer to the official Jackson Guitars website or contact your authorized dealer. Keep your proof of purchase for warranty claims.

For additional resources and frequently asked questions, visit the [Jackson Store on Amazon](#).