

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Hurom](#) /

› [Hurom H70 Cold Press Juicer Machine User Manual - Model H70FT-BBC06MB](#)

Hurom H70FT-BBC06MB

Hurom H70 Cold Press Juicer Machine User Manual

Model: H70FT-BBC06MB

1. INTRODUCTION

Thank you for choosing the Hurom H70 Cold Press Juicer Machine. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new juicer. Please read it thoroughly before first use and retain it for future reference.





The Hurom H70 Cold Press Juicer Machine, featuring its sleek black design and compact form factor.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before operating the juicer.
- Do not immerse the motor base in water or other liquids.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always ensure the juicer is properly assembled before operation.
- Do not put fingers or other objects into the juicer opening while it is operating. If food becomes lodged, use the food pusher provided.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. PRODUCT COMPONENTS

Familiarize yourself with the various parts of your Hurom H70 juicer for proper assembly and operation.



Feed the Whole Family

Keep your family healthy and happy with the maximized chamber and hopper size.

Key components of the Hurom H70 Juicer: Self-Feeding Hopper, Easy Clean Chamber, Pulp Outlet, Juice Spout, On/Off Switch, Removable Power Cord, and BPA-Free, Impact-Resistant ABS Plastic housing.

- **Self-Feeding Hopper:** Large opening for adding ingredients.
- **Easy Clean Chamber:** The main juicing assembly, designed for simplified cleaning.

- **Pulp Outlet:** Where extracted pulp is discharged.
- **Juice Spout:** Where the fresh juice is dispensed.
- **On/Off Switch:** Controls the power to the unit.
- **Removable Power Cord:** For easy storage and connection.
- **Motor Base:** Contains the motor and controls.

4. SETUP AND ASSEMBLY

The Hurom H70 features an intuitive design with fewer parts, making assembly straightforward.

1. Place the motor base on a stable, flat surface.
2. Align the Easy Clean Chamber with the motor base and gently twist until it locks into place.
3. Insert the auger assembly into the chamber.
4. Place the self-feeding hopper on top of the chamber, ensuring it is securely seated.
5. Connect the power cord to the juicer and then to a suitable electrical outlet.

Ensure all parts are correctly assembled before plugging in the appliance.

5. OPERATING INSTRUCTIONS

The Hurom H70 is designed for efficient cold pressing with minimal preparation.



Save Time & Reduce Mess

Minimal prep required — the large Self-Feeding Hopper deals with most fruits and vegetables without chopping. Ready in minutes.

Utilize the large self-feeding hopper to add various fruits and vegetables, minimizing the need for pre-chopping.

1. **Preparation:** Wash all fruits and vegetables thoroughly. For most produce, minimal chopping is required due to the large self-feeding hopper. Remove large seeds, pits, and hard skins (e.g., pineapple skin, citrus peels).
2. **Start Juicing:** Place a juice collection container under the juice spout and a pulp container under the pulp outlet. Turn the juicer ON using the On/Off switch.
3. **Add Ingredients:** Slowly feed ingredients into the self-feeding hopper. The juicer will automatically process them. Avoid overfilling the hopper or forcing ingredients.
4. **Continuous Juicing:** The wide inlet allows you to add more ingredients even while juicing, reducing interruptions.
5. **Monitor Juice Level:** The front-facing gauge window allows you to monitor the juice level in the chamber.
6. **Finish Juicing:** Once all ingredients are processed, allow the juicer to run for a few more seconds to extract any remaining juice and pulp. Turn the juicer OFF.

The slow squeeze technology ensures maximum juice yield and preserves nutrients, resulting in vibrant, full-flavored juice with minimal waste.

6. CLEANING AND MAINTENANCE

The H70 features a revolutionary strainer-free design for easy cleaning.



Easier & Faster to Clean

No mesh filter. Dual auger system means no scrubbing required—rinses clean in seconds.

The strainer-free design allows for quick rinsing of components under running water, eliminating the need for scrubbing mesh filters.

1. **Disassembly:** Unplug the juicer from the power outlet. Disassemble the hopper, chamber, and auger system.
2. **Rinsing:** Rinse all detachable parts under running water immediately after use. The two-part auger system naturally filters pulp, eliminating mesh screens and making rinsing quick and easy.
3. **Washing:** For a more thorough clean, wash parts with warm, soapy water and a soft brush if necessary.
4. **Drying:** Dry all parts thoroughly before reassembling or storing.
5. **Motor Base:** Wipe the motor base with a damp cloth. **Do not immerse the motor base in water.**

Important: The Hurom H70 is **not dishwasher safe**. Hand washing is required for all detachable components.

7. TROUBLESHOOTING

If you encounter issues with your Hurom H70 juicer, refer to the following common solutions:

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; parts not assembled correctly.	Ensure power cord is securely plugged into outlet and juicer. Check that all juicing chamber components are correctly aligned and locked.
Juicer stops during operation.	Overload; ingredients too large or hard.	Turn off and unplug. Disassemble and clear any blockages. Cut harder ingredients into smaller pieces. Wait a few minutes before restarting.
Low juice yield or wet pulp.	Ingredients fed too quickly; improper assembly.	Feed ingredients slowly. Ensure all parts are correctly assembled and the auger is properly seated.
Excessive vibration or noise.	Improper assembly; foreign object.	Check that all components are securely assembled. Disassemble and check for any foreign objects.

8. PRODUCT SPECIFICATIONS

- **Brand:** Hurom
- **Model Number:** H70FT-BBC06MB
- **Color:** Black
- **Special Feature:** Portable
- **Product Dimensions:** 8"D x 8"W x 16"H
- **Finish Type:** Painted
- **Power Source:** Corded Electric
- **Blade Material:** Stainless Steel
- **Voltage:** 120 Volts
- **Dishwasher Safe:** No
- **Item Weight:** 14.8 pounds
- **UPC:** 888253001131

9. WARRANTY INFORMATION

Hurom products are manufactured with high-quality materials and craftsmanship. For specific warranty details, including coverage period and terms, please refer to the warranty card included with your product or visit the official Hurom website. Keep your proof of purchase for warranty claims.






10. CUSTOMER SUPPORT


For further assistance, technical support, or to inquire about replacement parts, please contact Hurom customer service. You can find contact information on the official Hurom website or through your retailer.

Website: www.hurom.com



Related Documents - H70FT-BBC06MB

	<p>Hurom H320N Series Slow Juicer User Manual</p> <p>Comprehensive user manual for the Hurom H320N Series slow juicer, covering important safety precautions, operating instructions, assembly, disassembly, cleaning, and troubleshooting.</p>
	<p>Hurom H70FT Series Slow Juicer Instruction Manual</p> <p>Comprehensive instruction manual for the Hurom H70FT Series slow juicer, covering safety precautions, assembly, operation, cleaning, and troubleshooting.</p>
	<p>Hurom H310A Series Instruction Manual: Safe Use, Operation, and Cleaning</p> <p>Comprehensive instruction manual for the Hurom H310A Series juicer, covering safety precautions, assembly, operation, cleaning, and troubleshooting. Learn how to use your Hurom juicer effectively and safely.</p>
	<p>Hurom H310A Juicer: Instruction Manual and User Guide</p> <p>This document provides comprehensive instructions for operating, assembling, cleaning, and troubleshooting the Hurom H310A juicer. It includes safety precautions, ingredient preparation guidelines, and maintenance tips for optimal performance.</p>
	<p>Hurom H-200 Series Juicer Instruction Manual</p> <p>Comprehensive instruction manual for the Hurom H-200 Series juicer, covering important safeguards, operating precautions, assembly, usage, disassembly, cleaning, and troubleshooting. Includes guidance on ingredient preparation and filter selection for optimal juicing.</p>

 A black and white photograph of a Hurom H70FT Series slow juicer. The juicer is a tall, cylindrical appliance with a clear plastic body and a dark base. It has a feed chute at the top and a spout at the bottom. The brand name 'Hurom' is printed on the front. The image is framed by a thin black border with small crop marks at the corners.	<p>Hurom H70FT Series Instruction Manual</p> <p>Comprehensive instruction manual for the Hurom H70FT Series slow juicer, covering safety precautions, operation, assembly, disassembly, and troubleshooting.</p>
--	--