

## Conair Ghej29621

# Conair 2-in-1 Turbo Power Steam Iron and Steamer, Model Ghej29621 User Manual

## INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your Conair 2-in-1 Turbo Power Steam Iron and Steamer, Model Ghej29621. Please read all instructions carefully before operating the appliance and retain this manual for future reference. This versatile device is designed for both vertical steaming and horizontal ironing, offering convenience and efficiency for garment care.

## IMPORTANT SAFETY INSTRUCTIONS

- Always unplug the appliance immediately after use and before cleaning.
- Do not reach for an appliance that has fallen into water. Unplug it immediately.
- Do not place or store the appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water.
- Keep the cord away from heated surfaces. Do not pull, twist, or wrap cord around the appliance.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
- Never use while sleeping.
- Never drop or insert any object into any opening.

- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- The appliance is hot when in use. Do not let heated surfaces touch eyes or bare skin.
- Do not place the steam iron directly on any surface while hot or plugged in. Use the provided stand or a heat-resistant surface.
- Always ensure the water tank is securely attached before operating.

## **PRODUCT OVERVIEW**

---

### **Components**

The Conair 2-in-1 Turbo Power Steam Iron and Steamer consists of the main unit, which includes the ceramic soleplate, handle, control panel, and a large detachable water tank.



Image: Angled view of the Conair 2-in-1 Turbo Power Steam Iron and Steamer, highlighting its compact design and detachable water tank.

## Accessories

The following accessories are included to enhance your garment care experience:

- **Delicates Bonnet:** For use on delicate fabrics to protect them from direct heat and steam.

- **Silicone Band & Bristle Brush:** The silicone band helps to pull fabric taut for better steaming, while the bristle brush is ideal for removing lint and opening fabric weaves for deeper steam penetration.
- **Creaser:** To create crisp pleats and creases on garments.



Image: The included accessories for the Conair steam iron: a delicate bonnet, a silicone band with a bristle brush, and a creaser tool.

## SETUP

1. **Unpack the Appliance:** Carefully remove all packaging materials and ensure all components and accessories are present.
2. **Fill the Water Tank:** Detach the water tank from the main unit. Open the fill cap and fill the tank with distilled water. Using distilled water helps prevent mineral buildup and extends the life of your appliance. Do not overfill. Securely close the fill cap and reattach the water tank to the main unit until it clicks into place.
3. **Attach Accessories (Optional):** If using an accessory, align it with the soleplate and attach it firmly. For the delicate bonnet or brush, ensure it snaps securely over the soleplate.

## OPERATING INSTRUCTIONS

### Powering On and Heating

Plug the appliance into a standard electrical outlet. The indicator light will illuminate, signaling that the unit is heating. The Conair 2-in-1 Turbo Power Steam Iron and Steamer features a quick 10-second heat-up time, allowing for rapid use.

### Steam Settings

This appliance offers 5 steam settings, including a premium delicate setting. Select the appropriate steam

level for your fabric type using the control buttons on the handle. Refer to garment care labels for guidance on suitable heat and steam levels.

### **Vertical Steaming**

For vertical steaming, hang the garment on a hanger. Hold the steamer upright, ensuring the soleplate is not in direct contact with the fabric. Press the steam trigger to release steam and move the steamer slowly over the garment, from top to bottom. Use the silicone band and bristle brush attachment for better results on heavier fabrics or to remove lint.



Image: A man demonstrating vertical steaming on a dark jacket using the Conair 2-in-1 Turbo Power Steam Iron and Steamer.

### **Horizontal Ironing**

For horizontal ironing, place the garment on an ironing board or a heat-resistant flat surface. Hold the appliance horizontally and glide the ceramic soleplate over the fabric. Press the steam trigger for bursts of steam as needed. The temperature control feature allows for precise heat adjustment for various fabric types.



Image: A woman using the Conair 2-in-1 Turbo Power Steam Iron and Steamer in a horizontal position to iron a light blue shirt on an ironing board.

## MAINTENANCE AND CARE

---

### Cleaning

- Always unplug the appliance and allow it to cool completely before cleaning.
- Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- To clean the soleplate, wipe it with a damp cloth while the unit is cool. For stubborn residue, a mild detergent can be used, followed by a clean damp cloth.
- Empty the water tank after each use to prevent mineral buildup.

### Storage

Ensure the appliance is completely cool and dry before storing. Empty the water tank. Store the unit and its accessories in a cool, dry place, away from direct sunlight and moisture. Do not wrap the power cord tightly around the appliance.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam produced.	Water tank is empty or low. Unit not heated sufficiently. Steam vents clogged.	Refill water tank. Allow unit to heat for at least 10 seconds. Clean steam vents if necessary.
Water leakage or spitting.	Water tank not properly seated. Overfilled water tank. Using tap water (mineral buildup).	Ensure water tank is securely attached. Do not overfill. Use distilled water.
Unit not heating.	Not plugged in. Power outlet malfunction.	Ensure appliance is securely plugged into a working outlet. Check circuit breaker.
Attachments not staying on.	Not properly aligned or snapped into place.	Ensure attachments are correctly aligned and firmly snapped onto the soleplate.

## SPECIFICATIONS

Feature	Detail
Brand	Conair
Model Name	Ghej29621
Special Feature	Temperature Control
Base Material	Ceramic
Item Weight	3.83 pounds
UPC	074108483362
Manufacturer	Fanser
Heat-up Time	Quick 10 seconds
Steam Settings	5 (including Premium Delicate Setting)
Water Tank	Large Detachable

## WARRANTY AND SUPPORT

Conair products are manufactured to the highest standards and are warranted against defects in materials and workmanship for a specified period from the date of purchase. For detailed warranty information, product registration, or customer support, please refer to the official Conair website or contact their customer service department. Keep your purchase receipt as proof of purchase.

