

[Manuals.plus](#) /

> [Outsunny](#) /

> Outsunny 29 Gallon Patio Wicker Storage Bench Instruction Manual

Outsunny 865-008V00DB

Outsunny 29 Gallon Patio Wicker Storage Bench

Model: 865-008V00DB

Brand: Outsunny

1. PRODUCT OVERVIEW

The Outsunny 29 Gallon Patio Wicker Storage Bench is a versatile 2-in-1 outdoor furniture piece designed to provide both comfortable seating for two and ample storage space. Constructed from durable PE plastic rattan and reinforced with a powder-coated steel frame, this bench is built for outdoor use. It features a thickly padded cushion for enhanced comfort and side handles for easy portability.



Image: The Outsunny 29 Gallon Patio Wicker Storage Bench, showcasing its dark blue cushion and brown wicker finish.

Key Features:

- **Dual Functionality:** Serves as a comfortable two-seater bench and a spacious 29-gallon storage unit.
- **Durable Construction:** Made from hand-woven PE plastic rattan with a powder-coated steel frame for weather resistance and stability.
- **Comfortable Seating:** Includes a thickly padded cushion for optimal comfort.
- **Portable Design:** Equipped with two side handles for easy relocation.
- **Easy Access Storage:** The seat lifts via hinges to reveal the internal storage compartment.

COMFORTABLE CUSHION

Provide You the Ultimate Comfort Experience



Soft Padding



Removable Cushion Covers



Washable Cushion Covers

Image: A detailed view of the PE Rattan Wicker construction, highlighting its hand-woven texture and properties such as UV resistance, durability, and weather resistance.



Storage function

Weight capacity: 50kg

TWO-IN-ONE DESIGN



Seat function

Weight capacity: 110kg



Image: The comfortable cushion, illustrating its soft padding and the convenience of removable and washable covers.

2. SAFETY GUIDELINES

Adhering to these safety guidelines will ensure safe and proper use of your storage bench.

- Always follow the assembly instructions provided in the packaging.
- Exercise caution when opening and closing the seat to access the storage space to prevent pinching.
- Do not exceed the maximum weight capacity of 352 lbs (160 kg) for seating.
- Do not exceed the internal load-bearing capacity of 110 lbs (50 kg) for the storage compartment.
- Ensure the bench is placed on a stable, level surface to prevent tipping.
- Keep children and pets away from the bench during assembly and when opening/closing the lid.
- Store the bench indoors or cover it when not in use during harsh weather conditions to prolong its lifespan.

3. ASSEMBLY INSTRUCTIONS

Assembly of your Outsunny storage bench requires careful attention to detail. Please ensure all parts are present before beginning.

Required Tools (Not Included):

- Phillips head screwdriver
- Adjustable wrench or appropriate size spanner (if bolts are used)

Step-by-Step Assembly:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out and compare them against the parts list provided in your product's specific assembly manual to ensure nothing is missing.
2. **Assemble the Base Frame:** Connect the side panels and front/back panels using the provided hardware. Ensure all connections are aligned correctly.
3. **Attach the Bottom Panel:** Secure the bottom panel of the storage compartment to the assembled frame.
4. **Install the Lid/Seat:** Attach the lid to the main body using the hinges. Ensure the hinges are securely fastened and allow for smooth opening and closing. *(Refer to image below for hinge detail)*
5. **Important Tip for Fasteners:** When tightening screws or bolts, only tighten them to about 80% of their full tightness initially. This allows for minor adjustments and alignment during assembly. Once all components are in place and the bench is fully assembled, go back and securely tighten all fasteners. Do not overtighten to avoid damaging the material.
6. **Place the Cushion:** Once the bench is fully assembled and stable, place the padded cushion on top of the seat.



Image: A close-up of the robust hinge mechanism that allows the bench seat to open and close smoothly, providing access to the storage compartment.




Image: The interior of the storage bench, illustrating the ample space available for storing various outdoor items.

4. OPERATING INSTRUCTIONS

Your Outsunny storage bench is designed for simple and effective use.

Using as a Bench:

- Ensure the cushion is properly placed on the seat.
- The bench is designed to comfortably seat two adults.
- Always sit gently and avoid sudden impacts to prolong the life of the bench.

Accessing Storage:

- To access the storage compartment, simply lift the seat upwards. The integrated hinges will assist in a smooth opening motion.
- Place items into the 29-gallon storage basket.

- To close, gently lower the seat until it rests securely on the bench frame.



Image: The Outsunny storage bench with its lid fully open, showcasing the accessible storage compartment ready for use.

DETAIL DISPLAY



Convenience Side Handle
Easy carry around



Gas Spring
Easy open & close

Image: A visual representation of the bench's dual functionality, illustrating its capacity as both a comfortable seating area and a practical storage solution.

5. CARE AND MAINTENANCE

Proper care and maintenance will extend the life and appearance of your Outsunny storage bench.

- **Cleaning the Rattan:** Wipe the PE rattan surfaces with a damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and drying thoroughly.
- **Cushion Care:** The cushion covers are removable and washable. For cleaning, remove the cushion cover and wipe it with a cloth from both sides. Allow to air dry completely before reattaching.
- **Frame Maintenance:** The powder-coated steel frame is designed for outdoor use, but regular inspection for any signs of rust or damage is recommended. Touch up any scratches with appropriate outdoor paint to prevent rust.
- **Storage:** While the PE rattan is weather-resistant, it is recommended to store the bench indoors or cover it with a waterproof furniture cover during prolonged periods of non-use or harsh weather conditions (e.g., heavy rain, snow, extreme temperatures) to protect against damage and fading.
- **Water Resistance:** Please note that the storage compartment is not designed to be fully waterproof. It is

suitable for storing items that can tolerate some moisture or are already protected. Avoid storing sensitive items that could be damaged by water.

6. TROUBLESHOOTING TIPS

Here are solutions to common issues you might encounter with your storage bench.

- **Issue: Difficulty during assembly.**

Solution: Ensure you have identified all parts correctly and are following the step-by-step instructions in the provided manual. Do not fully tighten all screws until the entire unit is assembled and aligned. If a part seems misaligned, loosen adjacent screws, adjust, and then retighten.

- **Issue: Storage compartment is not waterproof.**

Solution: The bench's storage is designed for general outdoor storage and is not hermetically sealed or fully waterproof. For items requiring complete dryness, consider placing them in waterproof bags or containers inside the bench. Avoid storing electronics or sensitive documents directly in the compartment without additional protection.

- **Issue: Bench feels unstable or wobbly after assembly.**

Solution: Check that all screws and bolts are fully tightened. Ensure the bench is placed on a flat, level surface. If the surface is uneven, consider using shims under the legs to stabilize it.

- **Issue: Cushion appears dirty or stained.**

Solution: Remove the cushion cover and follow the cleaning instructions in the 'Care and Maintenance' section. For tough stains, a gentle fabric cleaner suitable for outdoor materials may be used.

7. PRODUCT SPECIFICATIONS

Detailed specifications for the Outsunny 29 Gallon Patio Wicker Storage Bench.

Specification	Detail
Model Number	865-008V00DB
Overall Dimensions (D x W x H)	17.75"D x 41.25"W x 20.25"H (45.1cm D x 104.8cm W x 51.4cm H)
Color	Dark Blue (Cushion), Brown (Wicker)
Size	Large
Furniture Finish	Powder Coated (Frame)
Seat Height	15.25 Inches (38.7cm)
Seating Capacity	2 people


Specification	Detail
Maximum Weight Recommendation (Seating)	352 lbs (160 kg)
Internal Load-bearing Capacity (Storage)	110 lbs (50 kg)
Item Weight	24.2 pounds (11 kg)
Storage Capacity	29 Gallons
Material	PE Rattan, Steel Frame, Polyester Fabric (Cushion)

PE RATTAN WICKER

Constructed of Quality PE Rattan Wicker with Stylish Weaving Finish



Hand-woven



UV Resistant



Durable



Weather Resistant

Image: A detailed diagram illustrating the key dimensions of the Outsunny storage bench, including width, depth, and height.

8. WARRANTY AND SUPPORT

For specific warranty information regarding your Outsunny 29 Gallon Patio Wicker Storage Bench, please refer to the documentation included with your purchase or contact the manufacturer directly. Warranty terms typically cover manufacturing defects and material flaws under normal use.

Customer Support:

If you require further assistance, have questions about assembly, or need to report a missing/damaged part, please contact Outsunny customer support. You can typically find contact information on the product packaging, the manufacturer's official website, or through your retailer's customer service portal.

When contacting support, please have your product model number (865-008V00DB) and purchase details readily available to expedite the process.

© 2025 Outsunny. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.