

[Manuals.plus](#) /

› [VG VOGCREST](#) /

› VG VOGCREST VG-102 2-in-1 Rechargeable Eyebrow & Facial Trimmer Instruction Manual

VG VOGCREST VG-102

VG VOGCREST VG-102 2-in-1 Rechargeable Eyebrow & Facial Trimmer

INSTRUCTION MANUAL

Introduction

Thank you for choosing the VG VOGCREST 2-in-1 Rechargeable Eyebrow & Facial Trimmer. This versatile device is designed for gentle and precise hair removal, offering both an eyebrow trimmer and a facial hair remover in one compact unit. It features a built-in LED light and convenient USB-C charging for an effortless grooming experience.



VOGCREST



2 in 1 Design



LED Light



TYPE-C Charging



Small Compact Design

EFFORTLESS PAINLESS HAIR REMOVAL

Image: Overview of the VG VOGCREST 2-in-1 Trimmer's key features.

Safety Information

- Avoid applying excessive pressure during use.
- Do not use the device on wet or dirty skin.
- If skin irritation occurs, discontinue use immediately.
- Keep out of reach of children.

Product Overview

The VG VOGCREST trimmer is engineered for efficiency and comfort. It includes two interchangeable heads: a precision eyebrow trimmer and a wider facial hair remover. The device is equipped with a built-in LED light to illuminate fine hairs and a powerful 10000 RPM motor for effective trimming.

Our titanium-plated replacement heads offer safe, skin-friendly trimming without irritation.



Image: Titanium-plated replacement heads for eyebrow trimming and facial hair removal.



Image: Built-in LED light for enhanced visibility during use.

Setup and Charging

Initial Setup

1. Unpack the trimmer and all accessories.
2. Ensure the device is fully charged before first use.

Charging Instructions

The trimmer features convenient USB-C charging. Use the provided USB cable to charge the device. The indicator light will change from red to green when fully charged.



Image: Type-C charging port with indicator light.

Operating Instructions

Follow these steps for effective and gentle hair removal:

1. **Install the desired cutting head:** Gently twist and pull off the current head, then align and twist on the desired head (eyebrow trimmer or facial hair remover).

2. **Activate the device:** Slide the switch upward into the "ON" position. The built-in LED light will illuminate.
3. **For Facial Hair Removal:** Use the wider facial shaver head. Move the device in small, circular motions on clean, dry skin. This is suitable for the upper and lower lip, cheeks, chin, and neck.
4. **For Eyebrow Trimming:** Use the precision eyebrow head. Move the device in small back-and-forth motions to shape and trim eyebrows on clean, dry skin.
5. **Tip:** For stubborn areas, gently hold the skin taut to ensure a closer trim.



Image: Step-by-step guide for using the trimmer.

Demonstration Videos

Video: Overview of the eyebrow and facial trimmer, demonstrating its rechargeable feature and built-in LED light.

Video: Demonstration of the 2-in-1 eyebrow trimmer and facial hair remover in action, highlighting its ease of use.

Maintenance

Cleaning

Regular cleaning ensures optimal performance and hygiene:

1. Turn off the device and remove the cutting head by twisting it counter-clockwise.
2. Use the provided cleaning brush to remove any accumulated hair from the cutting head and the device body.
3. The cutting heads can be rinsed under running water for a more thorough clean. Ensure they are completely dry before reattaching.
4. Wipe the main body of the trimmer with a dry cloth. Do not submerge the main body in water.
5. Reattach the cleaned and dried cutting head by aligning and twisting it clockwise until secure.



Image: Cleaning the detachable head of the trimmer.

Storage

Store the trimmer in a cool, dry place away from direct sunlight and moisture. Keep the protective cap on the active head when not in use to prevent damage.

Troubleshooting

Problem	Possible Cause	Solution
Device not turning on	Low battery or device is off.	Charge the device using the USB-C cable. Ensure the power switch is in the "ON" position.
Poor trimming performance	Hair buildup in the cutting head or dull blades.	Clean the cutting head thoroughly. If performance does not improve, consider replacing the head.
Skin irritation	Excessive pressure or using on wet/dirty skin.	Use gentle, circular motions on clean, dry skin. Discontinue use if irritation persists.

Specifications

- **Model Number:** VG-102
- **Product Dimensions:** 1.4 x 1.2 x 6 inches
- **Weight:** 3.53 ounces
- **Power Source:** Rechargeable Battery (USB-C)
- **Special Feature:** Cordless, Built-in LED Light
- **Manufacturer:** VG VOGCREST

Warranty and Support

VG VOGCREST offers a hassle-free 60-day return policy and a lifetime guarantee for any product defects. For support or to claim your warranty, please contact us through the official VG VOGCREST store or customer service channels.

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

