

SEAJIC OTH-AB202MAX-64

SEAJIC MagSafe Compatible Selfie Stick Tripod Instruction Manual

Model: OTH-AB202MAX-64

Brand: SEAJIC

1. INTRODUCTION

This manual provides detailed instructions for the SEAJIC MagSafe Compatible Selfie Stick Tripod, Model OTH-AB202MAX-64. This versatile device functions as both a selfie stick and a tripod, designed to securely hold your smartphone for photography, video recording, live streaming, and more. Please read this manual thoroughly before use to ensure proper operation and to maximize your product experience.



Figure 1: SEAJIC MagSafe Compatible Selfie Stick Tripod (Model OTH-AB202MAX-64)

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x SEAJIC MagSafe Compatible Selfie Stick Tripod
- 1 x Wireless Remote Control (Rechargeable)
- 1 x Metal Ring (for non-MagSafe devices)

3. PRODUCT OVERVIEW AND FEATURES

The SEAJIC Selfie Stick Tripod is constructed from durable aluminum and metal, offering stability and portability. Key features include:

- **MagSafe Compatibility:** Designed for direct attachment with iPhone 12/13/14/15 series and official MagSafe cases.
- **Universal Phone Support:** Includes a metal ring for secure magnetic attachment with Android phones and non-MagSafe cases.
- **Adjustable Height:** Extends up to 64 inches (163 cm) and folds down to a compact 12.2 inches (31 cm).
- **Flexible Angles:** Features 360° phone rotation and a 270° tripod arm flip for versatile shooting perspectives.
- **Strong Magnetic Hold:** Ensures your phone remains securely attached during use.
- **Rechargeable Wireless Remote:** Compatible with iOS and Android, allowing photo capture and video recording from up to 10 meters (33 feet) away.



Figure 2: MagSafe Phone Attachment



Figure 3: 360° Rotation and Angle Adjustment




Figure 4: Aviation-Grade Aluminum Alloy Rod and Handle

4. SETUP INSTRUCTIONS

4.1 Unfolding the Tripod

1. Hold the main body of the selfie stick tripod.
2. Gently pull the bottom section downwards to extend the tripod legs. Ensure the legs are fully spread for maximum stability.



Figure 5: Stable Tripod Base

4.2 Attaching Your Phone

The tripod features a strong magnetic mount for secure phone attachment.

- **For MagSafe Compatible iPhones (iPhone 12/13/14/15 series) or MagSafe Cases:** Simply align your phone with the magnetic ring on the tripod mount. The magnets will automatically secure your phone in place.
- **For Android Phones or Non-MagSafe Cases:** Use the provided metal ring. Peel off the adhesive backing from the metal ring and center it on the back of your phone or phone case. Ensure it is firmly attached. Once the metal ring is in place, you can magnetically attach your phone to the tripod mount.



Figure 6: MagSafe and Metal Ring Compatibility



Figure 7: Metal Ring Application for Non-MagSafe Devices

4.3 Pairing the Remote Control

1. Remove the wireless remote control from its slot on the tripod handle.
2. Press and hold the button on the remote control until the indicator light begins to flash, indicating it is in pairing mode.
3. On your smartphone, navigate to Bluetooth settings and enable Bluetooth.

4. Search for available devices and select "vimity" (or similar name) from the list to pair. The indicator light on the remote will stop flashing once successfully paired.
5. The remote is now ready to use for capturing photos and videos.



Figure 8: Bluetooth Pairing for Remote Control

5. OPERATING INSTRUCTIONS

5.1 Adjusting Height

To adjust the height, pull the telescopic pole upwards to extend it to your desired length, up to 64 inches. Push it back down to retract. The pole will hold its position once released.

Adjustable Height



Figure 9: Adjustable Height Options

5.2 Adjusting Angle and Rotation

The phone mount allows for flexible positioning:

- **Phone Rotation:** The magnetic phone mount can rotate 360° to switch between portrait and landscape modes.
- **Tripod Arm Flip:** The arm holding the phone mount can be flipped up to 270° to achieve various shooting angles.

**Anti-slip
Silicone Rubber**



5.3 Using as a Selfie Stick

With the tripod legs folded, hold the handle firmly and extend the telescopic pole to your desired length for taking selfies or group photos.

5.4 Using as a Tripod

With the tripod legs fully extended and placed on a stable, flat surface, adjust the height and angle as needed for hands-free photography, video recording, or live streaming.

5.5 Using the Remote Control

Once paired, open your phone's camera application. Press the button on the remote control to remotely trigger the shutter for photos or to start/stop video recording.

6. MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use, fold the selfie stick tripod to its compact size (12.2 inches) and store it in a dry, cool place away from direct sunlight.
- **Remote Battery:** The remote control is rechargeable. Connect it to a standard USB charging port when the battery is low.

7. TROUBLESHOOTING

- **Remote Control Not Pairing:**
 - Ensure the remote control is charged.
 - Verify Bluetooth is enabled on your smartphone.
 - Turn off and on the remote, then try re-pairing.
 - If previously paired, try forgetting the device in your phone's Bluetooth settings and re-pairing.
- **Phone Not Holding Securely:**
 - For MagSafe compatible phones/cases, ensure proper alignment with the magnetic ring.
 - For non-MagSafe devices, ensure the metal ring is correctly and firmly attached to your phone or case.
 - Avoid excessive shaking or impact that could dislodge the phone.

Secure & Powerful With MagSafe

Never fall off



Figure 11: Secure Magnetic Hold

- **Tripod Instability:**
 - Ensure the tripod legs are fully extended and locked into position on a flat, stable surface.
 - Avoid placing the tripod on uneven or slippery surfaces.
- **Remote Control Accidental Triggering:**
 - When storing the tripod, ensure the remote control's button is not pressed by other items in your bag or pocket.

8. SPECIFICATIONS

Feature	Detail
Model Number	OTH-AB202MAX-64
Product Dimensions (Folded)	12.2 inches (31 cm)
Product Dimensions (Extended)	Up to 64 inches (163 cm)

Item Weight	1.01 pounds (0.46 kg)
Material	Aluminum, Metal
Compatible Devices	iPhone 12/13/14/15 series, Android Smartphones (with metal ring)
Special Features	Magnetic Mount, Remote Control
Remote Control Range	10 meters (33 feet)
Tripod Head Type	Ball Heads (integrated)
Manufacturer	vimitty