

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [FlyEagle](#) /

› [FlyEagle Galaxy Projector BL-XK01 User Manual](#)

FlyEagle BL-XK01

FlyEagle Galaxy Projector BL-XK01 User Manual

Model: BL-XK01

INTRODUCTION

Thank you for choosing the FlyEagle Galaxy Projector BL-XK01. This device is designed to transform any room into a captivating cosmic oasis with dynamic colors, adjustable light patterns, and integrated audio features. It projects a field of green stars, accompanied by a nebula cloud and ocean wave effects, creating a soothing and vibrant atmosphere. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and enjoyment of your projector.

SAFETY INFORMATION

Please read all safety instructions before using the product. Failure to follow these instructions may result in electric shock, fire, or other injuries.

- Do not disassemble or modify the device. Repairs should only be performed by qualified personnel.
- Keep the device away from water and moisture. Do not use in wet environments.
- Ensure the power adapter is compatible with your local power supply and is properly connected.
- Avoid direct eye exposure to the laser light.
- Keep out of reach of children and pets to prevent accidental damage or misuse.
- Place the projector on a stable, flat surface to prevent it from falling.

WHAT'S IN THE BOX

Carefully unpack the box and ensure all items are present and in good condition:

- FlyEagle Galaxy Projector (BL-XK01)
- Remote Control

- USB-C Cable
- User Manual



What's in the Box

- Galaxy Projector 📡
- Remote Control 📺
- USB-C Cable 🔌
- Manual 📖

Image: Contents of the product packaging, showing the FlyEagle Galaxy Projector, its remote control, a USB-C charging cable, and the user manual.

SETUP

1. **Placement:** Position the projector on a flat, stable surface in your desired room. For optimal projection, ensure there are no obstructions between the projector and the ceiling/walls.
2. **Power Connection:** Connect the provided USB-C cable to the DC 5V port on the projector and plug the other end into a compatible USB power adapter (not included) or a USB port.
3. **Initial Power On:** Press the power button on the projector or the remote control to turn on the device.

OPERATING INSTRUCTIONS

The FlyEagle Galaxy Projector offers multiple control methods: onboard buttons, remote control, and a smartphone application.




Image: The FlyEagle Galaxy Projector, showcasing its various control options including physical buttons, a remote control, and a smartphone app interface.

1. Onboard Button Control

The projector features several buttons for basic functions:

- **Power Button:** Turns the projector on or off.
- **Light Mode Button:** Cycles through different light effects and colors.
- **Brightness Adjustment:** Adjusts the intensity of the projected light.
- **Music Playback Controls:** Play/Pause, Next/Previous track.

Embrace the Galaxy in your Bedroom




Image: Illustration of the three control methods: direct button control on the projector, remote control, and smartphone application control.

2. Remote Control

The included remote control provides full functionality for the projector.

- **Power ON/OFF:** Separate buttons for stars and ocean wave effects.
- **Color Selection:** Choose from 15 different light colors.
- **Brightness Levels:** Three adjustable brightness settings.
- **Music Controls:** Play/Pause, Volume Up/Down, Next/Previous track.
- **Timer Settings:** Set automatic shutdown for 1, 2, or 4 hours.
- **Rotation Speed:** Adjust the speed of the light effects.

3. App Control (Smart Night Life APP)

For enhanced control and customization, download the 'Smart Night Life' application on your smartphone.

1. **Download App:** Search for 'Smart Night Life' in your device's app store and install it.
2. **Power On Projector:** Ensure the projector is powered on and within Bluetooth range of your smartphone.
3. **Add Device:** Open the app, register/log in, and follow the on-screen instructions to 'Add Device'. The app will guide you through the pairing process.
4. **Customize Settings:** Once connected, you can effortlessly turn the light on/off, adjust light colors, brightness, and set custom timers.



Image: Step-by-step guide on how to use the Smart Night Life app to control the FlyEagle Galaxy Projector, from downloading the app to selecting colors.

4. Voice Control

The projector is compatible with voice commands through the Smart Night Life APP, allowing integration with smart home assistants like Google Assistant and Alexa.

- Ensure your projector is connected to the Smart Night Life APP.
- Link the Smart Night Life APP to your preferred smart home assistant (e.g., Google Home, Amazon Alexa).
- Use voice commands such as "Alexa, turn on the galaxy projector" or "Hey Google, change projector color to blue."

5. Light Modes and Effects

The projector offers 15 LED light color options, projecting green stars, a nebula cloud, and ocean wave effects.

- **Color Selection:** Cycle through various single or mixed color combinations using the remote or app.
- **Brightness:** Adjust between three brightness levels to suit your preference.
- **Speed:** Control the movement speed of the ocean wave and nebula effects.




Image: The FlyEagle Galaxy Projector displaying its multicolor galaxy and ocean wave projections, with an inset showing 15 distinct color options.

6. Bluetooth Speaker & Music Playback

The projector features a built-in Bluetooth speaker for audio playback.

- **Bluetooth Connection:** Turn on Bluetooth on your smartphone or other device. Search for "MX10" (or similar device name) and pair with the projector.
- **USB Disk Playback:** Insert a U disk (USB flash drive) into the USB port on the projector to play music directly.
- **Music Rhythm Mode:** The lights can flicker and change with the rhythm of the music, creating a dynamic visual experience.



Image: The FlyEagle Galaxy Projector highlighting its Bluetooth speaker functionality and USB port for playing music from a phone or USB disk.

7. Timer Function

The projector includes a built-in timer for automatic shutdown.

- Set the timer for 1 hour, 2 hours, or 4 hours using the remote control or the smartphone app.
- The default automatic shutdown time is 4 hours if no timer is manually set.
- This feature helps conserve energy and is ideal for bedtime use.




Image: The FlyEagle Galaxy Projector's timer function, showing options for 1, 2, or 4 hours, ideal for use while sleeping.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the projector. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Lens Care:** Avoid touching the projection lens directly. If cleaning is necessary, use a lens cleaning cloth.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Projector does not turn on.	No power supply or faulty connection.	Ensure the USB-C cable is securely connected and the power adapter is working. Try a different power source.
Lights are dim or not projecting clearly.	Brightness setting is low; lens is dirty; room is too bright.	Increase brightness via remote/app. Clean the projection lens. Use in a darker environment.
Bluetooth speaker not connecting.	Bluetooth is off on your device; projector is not in pairing mode; incorrect device selected.	Ensure Bluetooth is enabled on your device. Restart the projector. Search for "MX10" and try pairing again.
Remote control not working.	Battery depleted; obstruction between remote and projector.	Replace the remote control battery. Ensure clear line of sight to the projector's IR receiver.

Problem	Possible Cause	Solution
App cannot connect to the projector.	Projector is off; Bluetooth is off; app permissions not granted.	Ensure projector is on and Bluetooth is active. Check app permissions in your phone settings. Restart both the app and projector.

SPECIFICATIONS

Feature	Detail
Model Name	BL-XK01
Brand	FlyEagle
Product Dimensions	5.11"D x 6.53"W x 6.53"H
Item Weight	1.32 Pounds
Material	Acrylonitrile Butadiene Styrene (Plastic)
Light Source Type	LED
Number of Light Sources	1
Shade Color	Multicolor
Power Source	Corded Electric (DC 5V)
Voltage	5 Volts (DC)
Wattage	10 Watt-hours
Control Method	App, Voice, Remote, Onboard Buttons
Special Features	Auto on/off, Bluetooth, Dimmable, Remote Control, Timer, Color changing, Music responsive
Indoor/Outdoor Usage	Indoor
Water Resistance Level	Not Water Resistant
Assembly Required	No

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact FlyEagle customer service through their official website or the retailer where the product was purchased. Please retain your proof of purchase for warranty claims.

Online Support: Visit the [FlyEagle Store on Amazon](#) for additional product information and support resources.

