

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [BITZEE](#) /
- › [Bitzee Magicals Digital Pet Instruction Manual](#)

BITZEE 6069953

Bitzee Magicals Digital Pet User Manual

Brand: BITZEE | Model: 6069953

INTRODUCTION

Welcome to the world of Bitzee Magicals, where fantastical digital friends come to life! These interactive digital pets respond to your swipes, tilts, shakes, and touch with unique sounds and reactions. Each Magicals character begins as a baby and requires your care and attention to grow. The more you engage with your Bitzee, the more magical characters you will discover and unlock. This manual provides essential information on setting up, operating, and maintaining your Bitzee Magicals device.



Image: The Bitzee Magicals device, a blue, clam-shell shaped case, open to reveal a vibrant, pixelated digital character on its internal display.

WHAT'S INCLUDED

- 1 Bitzee Magicals Device
- 1 Quick Start Guide
- 1 Instruction Sheet
- 3 AA Batteries (pre-installed)

SETUP

Battery Installation

Your Bitzee Magicals device comes with 3 AA batteries pre-installed. If replacement is needed, ensure the device is powered off. Locate the battery compartment on the back of the unit, open it, and replace the batteries, observing correct polarity. Securely close the compartment.



Image: Packaging details indicating battery type and safety warnings.

Initial Power On

To activate your Bitzee Magicals, simply open the case. The digital pet will appear on the screen, ready for interaction. Follow the on-screen prompts to begin your journey with your first Bitzee character.

OPERATING INSTRUCTIONS

Interacting with Your Bitzee

Bitzee Magicals respond to various physical interactions:

- **Swipes:** Swipe your finger across the touch bar to navigate menus or interact with your pet.

- **Tilts:** Tilt the device to influence your pet's movements or game outcomes.
- **Touch:** Gently touch the screen area to pet your Bitzee or confirm actions.
- **Shakes:** Shake the device for certain reactions or to play specific games.




Image: A hand demonstrating the various interactive gestures with the Bitzee device.

Nurturing Your Digital Pet

Your Bitzee Magicals character requires care to thrive. Pay attention to its needs, which may be indicated by on-screen icons or messages:

- **Feeding:** Provide food when your pet is hungry.
- **Playing:** Engage in mini-games to keep your pet entertained.
- **Rocking to Sleep:** Rock the device gently when your pet is tired.
- **Cleaning:** Address any messes your pet might make.



NURTURE AND PLAY

Image: A hand interacting with the Bitzee, surrounded by pixelated hearts, illustrating the nurturing aspect.

Character Evolution

As you nurture and play with your Bitzee Magicals, they will evolve through different stages:

1. **Baby:** All characters start as babies.
2. **Adult:** With consistent care, your baby Bitzee will grow into an adult.
3. **Super Bitzee:** Rare or legendary adult Bitzee characters can evolve into Super Bitzee, sometimes splitting into two unique Splitzee characters.



Image: A visual representation of a Bitzee character's evolution from baby to adult to Super Bitzee.

New Ways to Play

- **Magic Wand:** Use the Magic Wand feature to cast spells and transform your Bitzee.



USE THE MAGIC WAND TO CAST SILLY SPELLS!

Image: Side-by-side comparison of a Bitzee character before and after a magic wand transformation.

- **Potions:** Earn new Potions by playing games to change your friend's colors.



TRANSFORM WITH NEW POTIONS!

Image: Side-by-side comparison of a Bitzee character changing colors using potions.

- **Super Bitzee Games:** Play unique games with your fully evolved Magicals.



PLAY SUPER BITZEE GAMES

Image: A hand interacting with the Bitzee device, showing a game icon on the screen.

- **Treasure Chest:** Collect gems to add to your Treasure Chest, which helps attract new characters.

CHARACTER COLLECTION

There are 20 unique Bitzee Magicals characters to collect within your device. Discover various creatures like Nessie, Kittycorn, Phoenix, Yeti, and more. Continue to play and nurture your pets to unlock them all and expand your digital collection.



COLLECT 20 FRIENDS IN THE BITZEE POD!

Image: The Bitzee device displaying a character, with an array of other collectible pixelated characters shown above it.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to gently wipe the exterior of the device. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store your Bitzee Magicals in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** If the device will not be used for an extended period, remove the batteries to prevent leakage.

TROUBLESHOOTING

- **Device Not Responding:** Ensure batteries are correctly installed and have sufficient charge. Try replacing the batteries.

- **Screen Issues:** If the display is dim or flickering, replace the batteries. If issues persist, contact customer support.
- **No Sound:** Check if the volume is turned down or muted within the device settings. Replace batteries if necessary.

SPECIFICATIONS

Feature	Detail
Product Dimensions	4.69 x 4 x 3.56 inches
Item Weight	7.4 ounces
Model Number	6069953
Manufacturer	Spin Master
Recommended Age	5 years and up
Batteries	3 AA Batteries (Included)
Release Date	June 12, 2024

WARRANTY AND SUPPORT

This product is covered by the Spin Master Care Commitment. For full details regarding warranty information, product support, or to contact customer service, please visit the official Spin Master website or refer to the contact information provided on the product packaging.

For additional assistance, please refer to the Quick Start Guide and Instruction Sheet included with your Bitzee Magicals device.