

[manuals.plus](#) /› [Edifier](#) /› [Edifier X5 Pro Active Noise Cancelling Earbuds User Manual](#)

## Edifier X5 Pro

# Edifier X5 Pro Active Noise Cancelling Earbuds User Manual

Model: X5 Pro

## 1. INTRODUCTION

Thank you for choosing the Edifier X5 Pro Active Noise Cancelling Earbuds. These true wireless earbuds are designed to provide an immersive audio experience with advanced features such as hybrid active noise cancellation, AI-enhanced call clarity, and a low-latency game mode. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

## 2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- Edifier X5 Pro Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- Ear Tips x 3 pairs (S, M, L)
- User Manual (this document)



Image: Edifier X5 Pro earbuds inside their charging case, with the lid open.

### 3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Edifier X5 Pro earbuds and charging case.



Image: Close-up view of the left and right Edifier X5 Pro earbuds, showing the "EDIFIER" branding on the stems.

- **Earbuds:** Each earbud features a touch control area, microphone, and ear tip.
- **Charging Case:** Houses the earbuds for charging and storage, with a charging indicator light and USB-C port.

## 4. SETUP

### 4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case.

1. Place the earbuds into the charging case.
2. Connect the USB-C charging cable to the charging port on the case and to a power source.
3. The indicator light on the case will show charging status. A full charge provides up to 7 hours of playtime for the earbuds and a total of 31 hours with the charging case (ANC off). Fast charging provides 1 hour of playback from 15 minutes of charging.



Image: The Edifier X5 Pro charging case with a USB-C cable connected to its charging port.

## 4.2 Bluetooth Pairing

To connect your Edifier X5 Pro earbuds to a device:

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for new devices.
3. Select "Edifier X5 Pro" from the list of available devices to connect.
4. Once connected, you will hear an audio prompt, and the indicator light on the case may change.

The earbuds utilize Bluetooth 5.3 for a stable and fast connection.

## 4.3 Edifier ConneX App Customization

Enhance your experience by downloading the Edifier ConneX App. The app allows you to:

- Personalize touch control settings.
- Select preset EQ modes.
- Locate your earbuds.
- Access other advanced features.



Image: A smartphone displaying the Edifier ConneX app interface, showing various customization options for the earbuds.

## 5. OPERATING INSTRUCTIONS

### 5.1 Touch Controls

The Edifier X5 Pro earbuds feature intuitive touch controls. The specific functions can be customized via the Edifier ConneX App. Default controls are typically:

#### Default Touch Control Functions

Action	Function
Double Tap (Either Earbud)	Answer/End Call, Play/Pause Music
Triple Tap (Right Earbud)	Next Track
Triple Tap (Left Earbud)	Previous Track
Press and Hold (Either Earbud)	Switch ANC Mode (Active Noise Cancellation / Ambient Sound / Normal)



Image: Diagram illustrating the touch control areas on the Edifier X5 Pro earbuds and their corresponding functions for calls, music, and ANC mode.

### 5.2 Active Noise Cancellation (ANC)

The hybrid ANC technology effectively reduces ambient noise, allowing for a more focused listening experience. You can switch between ANC, Ambient Sound, and Normal modes by pressing and holding either earbud.



Image: A person wearing Edifier X5 Pro earbuds, with a visual representation of how Active Noise Cancellation reduces surrounding noise.

### 5.3 Game Mode

Activate Game Mode for a significantly low-latency audio experience (0.08s), ideal for gaming. This mode can be enabled through the Edifier ConneX App.




Image: A person playing a mobile game while wearing Edifier X5 Pro earbuds, with an overlay indicating 0.08s low latency.

### 5.4 AI-Enhanced Calls

The built-in microphone with an AI algorithm reduces background noise and enhances voice clarity during calls, ensuring clear communication.



Image: A person smiling and talking on a phone call while wearing Edifier X5 Pro earbuds, emphasizing the clear call quality.

## 6. MAINTENANCE

To ensure the longevity and optimal performance of your Edifier X5 Pro earbuds:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry cloth. Avoid using abrasive materials or harsh chemicals.
- **Ear Tips:** Clean the ear tips periodically and replace them if they become damaged or worn.
- **Water Resistance:** The earbuds are IP55 waterproof, meaning they are protected against dust and low-pressure water jets. Do not submerge them in water. Dry them thoroughly if they get wet.
- **Storage:** Store the earbuds in their charging case when not in use to protect them and keep them charged.




Image: A person drinking from a water bottle while wearing Edifier X5 Pro earbuds, illustrating their IP55 waterproof rating.

## 7. TROUBLESHOOTING

If you encounter issues with your Edifier X5 Pro earbuds, refer to the following common solutions:

- **No Sound/Connection Issues:**

- Ensure earbuds are charged.
- Verify Bluetooth is enabled on your device and "Edifier X5 Pro" is selected.
- Try unpairing and re-pairing the earbuds.
- Restart your device.

- **One Earbud Not Working:**

- Place both earbuds back in the case, close the lid, then open it again.
- Ensure both earbuds are charged.
- Perform a factory reset (refer to the Edifier ConneX App or Edifier support for specific instructions).

- **Charging Issues:**

- Check the USB-C cable and power adapter.
- Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.

- **ANC Not Effective:**

- Ensure ANC mode is activated.
- Check that the ear tips provide a good seal in your ear canal. Try different sized ear tips.

For further assistance, please contact Edifier customer support.

## 8. SPECIFICATIONS

Feature	Detail
Model Name	X5 Pro
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth V5.3
Bluetooth Range	10 Meters
Noise Control	Active Noise Cancellation
Audio Driver Type	Dynamic Driver
Audio Driver Size	10 Millimeters
Frequency Range	20Hz-20KHz
Battery Life (Earbuds)	7 Hours (single charge)
Total Playtime (with case)	Up to 31 Hours (ANC off)
Charging Time (Fast Charge)	15 minutes for 1 hour playback
Water Resistance Level	IP55 Waterproof
Control Method	App, Touch
Item Weight	100 Grams (total package)
Included Components	Cable, Charging Case, Ear Cushions, Ear Tips x 3 pairs (S, M, L), User Manual

## 9. WARRANTY AND SUPPORT

The Edifier X5 Pro earbuds come with a **one-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures reliable performance.

For warranty claims, technical support, or any inquiries, please contact Edifier customer service through their official website or the contact information provided in your product packaging.

**Manufacturer:** Edifier

© 2024 Edifier. All rights reserved.