

[manuals.plus](#) /

› [TCL](#) /

› [TCL TAB 10 Gen2 Tablet User Manual](#)

TCL TAB 10 Gen2

TCL TAB 10 Gen2 Tablet User Manual

Model: TAB 10 Gen2 (8496G1)

1. INTRODUCTION

This manual provides essential information for the proper use and maintenance of your TCL TAB 10 Gen2 tablet. Please read this manual thoroughly before using the device to ensure optimal performance and safety. Keep this manual for future reference.

2. DEVICE OVERVIEW

Familiarize yourself with the physical components and controls of your TCL TAB 10 Gen2 tablet.



Figure 2.1: Front view of the TCL TAB 10 Gen2 tablet, displaying the screen and front camera.




Figure 2.2: Back view of the TCL TAB 10 Gen2 tablet, showing the rear camera module and TCL branding.



Figure 2.3: Side profile of the TCL TAB 10 Gen2 tablet, illustrating its slim design (7.35mm thickness) and light weight (425g).

2.1 Physical Features

- **Display:** 10.4-inch 2K (2000x1200 pixels) NXTVISION display.
- **Cameras:** Front and rear cameras for photos, videos, and video calls.

- **Buttons:** Power button, Volume up/down buttons.
- **Ports:** USB-C port for charging and data transfer.
- **Speakers:** Dual speakers for audio output.
- **Microphone:** Integrated microphone.

3. SETUP

3.1 Initial Charging

Before first use, fully charge your tablet. Connect the provided USB-C cable to the tablet's charging port and the other end to a compatible power adapter. The battery indicator on the screen will show charging progress.

3.2 Powering On/Off

- **To Power On:** Press and hold the Power button until the TCL logo appears.
- **To Power Off:** Press and hold the Power button, then select 'Power off' from the options on the screen.
- **To Restart:** Press and hold the Power button, then select 'Restart' from the options on the screen.

3.3 Initial Setup Wizard

Upon first power-on, the tablet will guide you through an initial setup process. Follow the on-screen instructions to:

1. Select your language.
2. Connect to a Wi-Fi network.
3. Sign in with your Google account or create a new one.
4. Set up screen lock (PIN, pattern, or password).
5. Review and accept terms and conditions.

4. OPERATING INSTRUCTIONS

4.1 Basic Navigation

- **Touch:** Tap an icon to open an app or select an item.
- **Swipe:** Slide your finger across the screen to scroll through pages or content.
- **Pinch-to-Zoom:** Use two fingers to zoom in or out on images and web pages.
- **Home Screen:** Tap the Home button (usually a circle or square icon) to return to the main screen.
- **Recent Apps:** Tap the Recent Apps button (usually a square icon) to view and switch between recently used applications.

4.2 Wi-Fi Connection

To connect to a Wi-Fi network:

1. Go to **Settings > Network & internet > Wi-Fi**.
2. Toggle Wi-Fi **On**.
3. Select your desired network from the list.
4. Enter the password if prompted, then tap **Connect**.

4.3 Display and Audio Features

The TCL TAB 10 Gen2 features a high-resolution display and dual speakers for an enhanced multimedia experience.




Figure 4.1: The 10.4-inch 2K NXTVISION display offers vibrant colors and clear visuals for an immersive viewing experience.




Figure 4.2: The tablet runs on Android 13 and is equipped with a 6000mAh battery, providing up to 9 hours of streaming.

5. MAINTENANCE

5.1 Cleaning the Tablet

- Use a soft, lint-free cloth to clean the screen and body of the tablet.

- Do not use abrasive cleaners, alcohol, or solvents, as these can damage the device.
- Avoid getting moisture into openings.

5.2 Battery Care

- Avoid exposing the tablet to extreme temperatures (hot or cold).
- Do not leave the tablet fully charged or fully discharged for extended periods.
- Use only approved chargers and cables.

5.3 Software Updates

Regularly check for and install software updates to ensure your tablet has the latest features and security enhancements. Go to **Settings > System > System update**.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your TCL TAB 10 Gen2 tablet.

6.1 Tablet Does Not Turn On

- Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again.
- Press and hold the Power button for at least 10-15 seconds to perform a forced restart.

6.2 Screen Is Unresponsive

- Restart the tablet.
- If the issue persists, try a factory reset (note: this will erase all data).

6.3 Cannot Connect to Wi-Fi

- Ensure Wi-Fi is enabled in Settings.
- Check if the Wi-Fi password is correct.
- Restart your Wi-Fi router.
- Forget the network and try connecting again.

6.4 Apps Are Crashing or Freezing

- Close and reopen the app.
- Clear the app's cache and data in **Settings > Apps > [App Name] > Storage & cache**.
- Update the app to its latest version from the Google Play Store.
- Uninstall and reinstall the app.

7. SPECIFICATIONS

Key technical specifications for the TCL TAB 10 Gen2 tablet.

譲れない、 優れたパフォーマンス

Android™ 13搭載

お気に入りのアプリを楽しむことができ、
最新の機能がセキュリティアップデートと共に定期的に提供されます。

一日中 楽しめる

6000 mAh
バッテリー

最大 **9** hours²
ストリーミング

Figure 7.1: The tablet features 128GB of internal storage (ROM) and an octa-core processor for efficient performance.

Feature	Specification
Brand	TCL
Model Number	8496G1
Operating System	Android 13
Display Size	10.36 inches
Display Resolution	2000 x 1200 pixels
CPU Brand	MediaTek
CPU Speed	2000 MHz
RAM Capacity	4096 MB
Memory Storage Capacity	128 GB (expandable via microSD)
Connectivity	Wi-Fi
Battery Capacity	6000 mAh (Lithium Ion)
Battery Life	Up to 9 hours (streaming)
Product Dimensions	15.47 x 24.49 x 0.73 cm
Item Weight	425 g
Color	Space Gray

8. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product or visit the official TCL support website. If you encounter issues not covered in this manual, please contact TCL customer support for assistance.

TCL Official Website: www.tcl.com