

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [FEELNEEDY](#) /

› [FEELNEEDY 3.2L Cat Water Fountain Filter and Pump Sponges \(FN-W06\) Instruction Manual](#)

FEELNEEDY FN-W06

FEELNEEDY 3.2L Cat Water Fountain Filter and Pump Sponges (FN-W06) Instruction Manual

1. PRODUCT OVERVIEW

This manual provides instructions for the FEELNEEDY 3.2L Cat Water Fountain Filter and Pump Sponges, specifically designed for model FN-W06. These sponges are crucial components for maintaining water quality and ensuring the quiet, efficient operation of your pet's water fountain.

The sound-absorbing sponges contribute to the fountain's quiet operation, while the pump sponges protect the pump from debris, extending its lifespan and ensuring a continuous flow of clean water for your pet.



This image displays the two types of filter sponges included in the package alongside various color options of the compatible FEELNEEDY 3.2L cat water fountain (model FN-W06).

2. PACKAGE CONTENTS

Your package should contain the following items:

- 3 x Sound-absorbing Sponges
- 3 x Water Pump Sponges

3. SETUP INSTRUCTIONS

Proper installation of the sponges is essential for the fountain's performance.

1. **Preparation:** Before first use, immerse all filter sponges in clean water for 3 to 5 minutes. This helps to remove any loose carbon dust and ensures optimal filtration from the start.
2. **Locate the Pump:** Open your FEELNEEDY FN-W06 cat water fountain and locate the water pump.

3. **Install Water Pump Sponge:** Place one of the smaller water pump sponges over the intake of the water pump. This sponge acts as a pre-filter, preventing larger debris like pet hair from entering and clogging the pump.
4. **Install Sound-absorbing Sponge:** Position the larger sound-absorbing sponge in its designated slot, typically around the main filter housing or water outlet area, as indicated in your fountain's primary manual. This sponge helps to minimize operational noise.
5. **Reassemble:** Carefully reassemble your water fountain, ensuring all components are securely in place before filling with water and powering on.



A transparent view of the FEELNEEDY cat water fountain, highlighting the correct positions for the 'Water Pump Sponge' and the 'Filter Replacement' within the unit.

4. OPERATING PRINCIPLES

The sponges work in conjunction with the fountain's main filter to provide multi-stage filtration and quiet operation:

- **Water Pump Sponge:** This sponge prevents pet hair, food particles, and other large debris from entering the pump, protecting its motor and ensuring consistent water flow.
- **Sound-absorbing Sponge:** Designed to dampen vibrations and reduce operational noise from the water pump, contributing to a serene environment for your pet.

Extra Quiet

Pet fountain ensures a serene and undisturbed
ambiance in your home



This image demonstrates the quiet operation of the pet fountain, with a sound level indicator ranging from 10dB to 50dB, ensuring a peaceful environment for pets, as shown by a cat sleeping undisturbed next to the fountain.

5. MAINTENANCE

Regular cleaning and replacement of the sponges are vital for the health of your pet and the longevity of the fountain.

- **Cleaning:** Rinse the sponges under running water weekly to remove accumulated debris. Do not use soap or

detergents, as residues can be harmful to pets.

- **Replacement:** It is recommended to replace both the water pump sponge and the sound-absorbing sponge every 2 to 4 weeks, depending on the number of pets using the fountain and the water quality in your area. Frequent replacement ensures optimal filtration and quiet operation.

6. TROUBLESHOOTING

If you encounter issues with your fountain, consider the following:


- **Increased Noise:** If the fountain becomes noticeably louder, the sound-absorbing sponge may be worn out or the water pump sponge might be clogged, causing the pump to work harder. Inspect and replace the sponges as needed.
- **Reduced Water Flow:** A clogged water pump sponge can restrict water flow. Clean or replace the water pump sponge. Also, ensure the main filter is not clogged.
- **Water Quality Issues:** If the water appears cloudy or has an odor despite regular cleaning, the sponges and main filter may need immediate replacement.

7. SPECIFICATIONS

Feature	Detail
Product Model	FN-W06 (for compatible fountain)
Material	Cotton
Sound-absorbing Sponge Dimensions	Approx. 5.2 cm (height) x 3.2 cm (diameter)
Water Pump Sponge Dimensions	Approx. 3.5 cm (length) x 2.8 cm (width)
Compatibility	FEELNEEDY 3.2L Cat Water Fountain (FN-W06)

Compatible with FEELNEEDY 3.2L Pet Water Fountains

(FN-W06)



Note: Please choose official feelneedy filters as others may not be of the right size or material.

This image illustrates the precise measurements of both the sound-absorbing sponge (5.2cm x 3.2cm) and the water pump sponge (3.5cm x 2.8cm), confirming compatibility with FEELNEEDY 3.2L Pet Water Fountains (FN-W06).

8. SUPPORT

For any questions or further assistance, please contact FEELNEEDY customer support:

- **Email:** support@feelneedy.com

© 2024 FEELNEEDY. All rights reserved.