

Neporal MAGICPRO

Neporal MAGICPRO Rechargeable Light Bulbs (Model: MAGIXPRO) - Instruction Manual

Brand: Neporal | Model: MAGIXPRO

1. INTRODUCTION

The Neporal MAGICPRO Rechargeable Light Bulbs offer versatile lighting solutions with dual charging capabilities, multiple color temperatures, and dimmable brightness. Designed for convenience, these bulbs can be used in standard light sockets or as portable lighting with an included hook, making them ideal for daily use, camping, and emergency situations.

Key features include:

- Dual Charging: USB-C and E26/E27 socket charging.
- 3 Color Temperatures: Warm (3000K), Neutral (4500K), and Cool White (6500K).
- Dimmable: Adjustable brightness from 10% to 100%.
- Portable: Includes a hook for hanging.
- Remote and Touch Control.

2. WHAT'S IN THE BOX

- 2 x Neporal MAGICPRO Rechargeable Light Bulbs
- 2 x Portable Hooks
- 1 x USB-C Charging Cable
- 1 x Remote Control



Image: The package contents laid out, showing the two light bulbs, two hanging hooks, one USB-C charging cable, and the remote control.

3. SETUP

3.1 Charging the Bulbs

The MAGICPRO bulbs offer two convenient charging methods:

1. **Via E26/E27 Socket:** Screw the bulb into any standard E26/E27 light socket. The bulb will charge automatically when the socket is live, even if the light is turned off.
2. **Via USB-C Cable:** Connect the provided USB-C cable to the charging port on the side of the bulb and plug the other end into a USB power source (e.g., power bank, laptop, car charger).

A full charge takes approximately 2 hours. The bulb indicates charging status (e.g., red light for charging, light off when fully charged).

GET PERPARED!

"They Thought i Have a Generator"

Family **MUST-HAVE** tool. Keep light on during power outages with 1800mAh battery, 4-50H runtime.

IDEAL GIFT - Ensure reliable, safe lighting for the elderly, parents, children. Prevent accidents and banish fear with ease.

Image: A Neporal MAGICPRO bulb connected to a USB-C charging cable, illustrating the USB charging method.

3.2 Attaching the Portable Hook

For portable use, attach the included hook to the base of the bulb:

1. Remove the plastic cap from the bulb's base.

2. Screw the portable hook onto the bulb's base until secure.



More Than Bulbs!

Explore Endless Possibility

With Portable Hook 

Cord-Free Use 

Image: A Neporal MAGICPRO bulb with the portable hook screwed into its base, demonstrating how to prepare it for hanging.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off and Brightness Control

The bulbs can be controlled via touch or the remote control:

- **Touch Control:** Short press the power button on the bulb to turn it on/off or to cycle through color temperatures. Long press to adjust brightness.
- **Remote Control:** Use the 'ON' and 'OFF' buttons to power the bulbs. Use '+' and '-' buttons to adjust brightness (10%-100%). Dedicated buttons for 50% and 100% brightness are also available.



Image: A visual guide detailing the functions of the remote control and the touch-sensitive power button on the bulb for power, brightness, and color adjustments.

4.2 Color Temperature Selection

Choose from three color temperatures to suit your needs:

- **Remote Control:** Use the dedicated color buttons (e.g., blue for cool white, green for neutral, red for warm) to switch between 3000K (Warm White), 4500K (Neutral White), and 6500K (Cool White).

- **Touch Control:** Short press the power button on the bulb to cycle through the available color temperatures.

4.3 Timer Function

Set a timer for automatic shut-off using the remote control:

- Press the '15MIN', '30MIN', '60MIN', or '120MIN' buttons on the remote to activate the corresponding timer. The bulb will blink to confirm the timer setting.

4.4 Versatile Usage Scenarios

The portable design and dual charging make these bulbs suitable for various applications:

- **Emergency Lighting:** Provides light during power outages.
- **Camping/Outdoor:** Hang in tents, RVs, or outdoor spaces using the hook.
- **Cordless Lamps:** Use in lamps without needing a power outlet.



Image: A collage showing the Neporal MAGICPRO bulbs being used in a tent for camping, as an emergency light in a house during a storm, and as hangable lights for outdoor gatherings.

Video: This video demonstrates the Neporal MAGICPRO bulbs in various daily and emergency lighting scenarios, highlighting their versatility and ease of use.

5. MAINTENANCE

5.1 Battery Life

The battery life varies depending on the brightness setting:

- 10% Brightness (Nightlight Mode): 20-50 hours
- 50% Brightness: 8-15 hours
- 100% Brightness (Full): 4-5 hours



Image: A graphic showing the Neporal MAGICPRO bulb and its battery life performance: 4-6 hours at 100% power, 8-15 hours at 50% power, and 20-50 hours at 20% power.

5.2 Cleaning

To clean the bulb, ensure it is turned off and disconnected from any power source. Wipe gently with a dry, soft cloth. Do not use liquid cleaners or abrasive materials.

6. TROUBLESHOOTING

- **Bulb not charging:** Ensure the USB-C cable is securely connected to both the bulb and the power source. If charging via socket, confirm the socket is live and the bulb is screwed in correctly.
- **Remote control not responding:** Check if the plastic battery tab has been removed from the remote. If the remote has been used for a long time, the battery may need replacement.
- **Short battery runtime:** Battery life is dependent on brightness. Higher brightness settings consume power faster. Ensure the bulb is fully charged (2 hours) before extended use.

7. SPECIFICATIONS

Feature	Detail
Brand	Neporal
Model Name	MAGIXPRO
Light Type	LED
Special Feature	Color Changing, Dimmable, Energy Efficient, Flicker-Free, Rechargeable
Wattage	9 Watts
Bulb Shape Size	A19
Bulb Base	E26
Incandescent Equivalent Wattage	60 Watts
Light Color	3000K (Warm White), 4500K (Neutral White), 6500K (Cool White)
Voltage	100 to 240 Volts
Brightness	700 Lumen
Material	Plastic
Indoor/Outdoor Usage	Indoor
Power Source	AC and Battery
Color Rendering Index	85.0
Average Life	25000 Hours

Control Method	Remote, Touch
Batteries	1 Lithium Ion batteries required (included)

8. WARRANTY & SUPPORT

- **2-Year Replacement Promise:** Your purchase is covered by a 2-year replacement promise.
- **30-Day Free Returns:** Enjoy hassle-free returns within 30 days of purchase.
- **Lifetime Technical Help:** Access technical assistance for the lifetime of your product.
- **24/7 Fast Support:** Dedicated support is available around the clock.
- **U.S. BASE Customer Service:** Benefit from local customer service.



Image: Icons representing 180-day quality guarantee, lifetime technical help, 30-day free returns, and 24/7 fast support.

© 2026 Neporal. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CSK9Q8J6>

More documents and user manuals: <https://manuals.plus/>