

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Merax](#) /
- › [Merax 57.28" Pull-Out Sofa Bed Convertible Loveseat Instruction Manual](#)

Merax 57.28"-Loveseat

Merax 57.28" Pull-Out Sofa Bed Convertible Loveseat Instruction Manual

Model: 57.28"-Loveseat | Brand: Merax

1. INTRODUCTION

Thank you for choosing the Merax 57.28" Pull-Out Sofa Bed Convertible Loveseat. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before use and retain them for future reference.



The Merax 57.28 inch Pull-Out Sofa Bed, dark grey, positioned in a modern living room, showcasing its compact design as a loveseat.

2. SAFETY INFORMATION

- Ensure all parts are securely fastened before use. Regularly check and tighten fasteners as needed.
- Do not exceed the maximum weight capacity of 500 pounds (227 kg) per seat.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Avoid standing or jumping on the sofa or bed.
- Use caution when converting the sofa to a bed and vice versa to prevent pinching or injury.
- Place the sofa on a level surface to ensure stability.

3. PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact Merax customer service.

- Sofa Frame (1)
- Seat Cushion (1)
- Back Cushions (2)
- Throw Pillows (2)
- Legs (4)
- Assembly Hardware (screws, washers, Allen wrench)

4. SETUP AND ASSEMBLY

Assembly is required for this product. It is recommended that one person performs the assembly.

1. Carefully unpack all components and place them on a clean, soft surface to prevent scratches.
2. Attach the four legs to the bottom of the sofa frame using the provided screws and Allen wrench. Ensure they are tightened securely.
3. Place the seat cushion onto the sofa frame.
4. Position the two back cushions against the backrest.
5. Place the two throw pillows on the sofa.
6. Confirm all connections are stable before using the sofa.

DETAILS



A close-up image highlighting key features of the Merax sofa, such as the convenient USB charging ports, comfortable corduroy fabric, high-density foam cushioning, strong feet, and removable pillow covers.

5. OPERATING INSTRUCTIONS


5.1 Converting to Sofa Bed

The Merax loveseat easily converts into a comfortable sleeping bed.

1. Ensure there is sufficient clear space in front of the sofa for extension.
2. Locate the two auxiliary hand straps at the front base of the sofa.
3. Gently pull the straps outwards and upwards. The pull-out bed mechanism will slide forward on smooth wheels.
4. Continue pulling until the bed is fully extended and locked into place.
5. To convert back to a sofa, reverse the process, pushing the bed mechanism back into the sofa until it clicks securely.

ADJUSTABLE BACKREST

Allow you to feel ease while watching TV, reading books, or taking a nap.



Watching TV



Reading Books



Taking a Nap

A visual guide illustrating the three steps to transform the Merax loveseat into a sleeping bed using the auxiliary hand straps and smooth wheels.




A detailed view of the two auxiliary hand straps located at the front of the Merax sofa, used for easily pulling out the bed mechanism.

5.2 Adjusting Backrest

The backrest offers three adjustable angles for optimal comfort.

1. To adjust the backrest, gently push it forward until you hear a click, then recline it to your desired angle.
2. The available angles are approximately 105° (upright), 138° (relaxed), and 180° (flat for sleeping).
3. Ensure the backrest is securely locked into your chosen position before leaning on it.

SIZE inch



An illustration demonstrating the three adjustable backrest positions (105°, 138°, 180°) for the Merax convertible loveseat, suitable for watching TV, reading, or napping.

5.3 Using USB Ports

Convenient USB ports are integrated into the armrest for charging electronic devices.

- Locate the USB ports on the side of the armrest.
- Connect your device's charging cable to the USB port.
- Ensure the sofa is connected to a power source (if applicable, check product specifications for power requirements).

6. MAINTENANCE

6.1 Cleaning the Corduroy Fabric

- **Regular Cleaning:** Vacuum the corduroy fabric regularly using a soft brush attachment to remove dust and debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. Do not rub, as this can spread the stain. For stubborn stains, use a mild fabric cleaner specifically designed for corduroy, testing on

an inconspicuous area first. Follow the cleaner's instructions carefully.

- **Removable Pillow Covers:** The pillow covers are removable. Refer to the care label on the covers for specific washing instructions. Typically, machine wash cold on a gentle cycle and air dry.

6.2 General Care

- Avoid direct sunlight exposure to prevent fading of the fabric.
- Keep the sofa away from heat sources like radiators or fireplaces.
- Periodically check and tighten all assembly hardware to ensure stability.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Sofa feels unstable or wobbly.	Loose assembly hardware or uneven floor.	Check and tighten all screws. Ensure the sofa is on a level surface.
Pull-out bed mechanism is stiff or stuck.	Obstruction, misaligned wheels, or mechanism needs lubrication.	Check for any objects blocking the mechanism. Ensure wheels are clean and aligned. Apply a silicone-based lubricant to moving parts if necessary.
Backrest does not adjust smoothly.	Mechanism obstruction or dirt.	Ensure no fabric or objects are caught in the mechanism. Clean any visible debris.
USB ports are not charging devices.	Sofa not powered, faulty cable, or device issue.	Ensure the sofa's power connection (if any) is secure. Try a different USB cable or device to rule out external issues.

8. SPECIFICATIONS

- **Brand:** Merax
- **Model:** 57.28"-Loveseat
- **Product Dimensions (Sofa):** 57.48"D x 36.61"W x 32.28"H
- **Reclined Length (Bed):** 69.5 Inches
- **Weight Limit:** 500 Pounds
- **Seating Capacity:** 2
- **Material:** Corduroy Fabric, Engineered Wood Frame
- **Adjustable Backrest:** 3 Levels (105°, 138°, 180°)
- **USB Ports:** Yes
- **Included Components:** Two Throw Pillows
- **Assembly Required:** Yes (1 person recommended)

A technical diagram providing precise measurements in inches for the Merax convertible loveseat, showing its dimensions as a sofa and when fully extended as a bed.

MULTI-SCENARIO APPLICATIONS



An image illustrating various suitable environments for the Merax convertible sofa, including living rooms, offices, bedrooms, and studios, emphasizing its versatility.

9. WARRANTY AND SUPPORT

Merax products are designed for quality and durability. For warranty information, product support, or to report missing/damaged parts, please contact Merax customer service through their official website or the retailer where the product was purchased. Please have your model number (57.28"-Loveseat) and purchase details ready when contacting support.