Dreo DR-HPF004S

Dreo Oscillating Fan User Manual

Model: DR-HPF004S

Introduction

This manual provides essential information for the safe and efficient operation of your Dreo Oscillating Fan. Please read it thoroughly before use and retain it for future reference.
The Dreo TurboPoly Fan (Model DR-HPF004S) integrates strong points of floor-standing, air circulation, and smart control into one. It features 9 wind speeds and 6 wind types, omni-directional oscillation, and smart control via the Dreo app, voice assistants, or remote control.

Product Overview



Figure 1: Dreo Oscillating Fan (Model DR-HPF004S) with its remote control and a smartphone displaying the companion app.

Key Features:

- **Omni-Directional Oscillation:** Simultaneous 150° horizontal and 120° vertical oscillation for wide air distribution.
- **Smart Control:** Wi-Fi enabled, controllable via Dreo app, voice commands (Alexa, Google Assistant), touch panel,

and remote control.

- **Powerful Airflow:** TurboSilent technology and DC motor provide up to 110 ft air reach and 66% higher wind volume.
- **Quiet Operation:** Brushless DC motor and bionic blade design ensure ultra-quiet operation as low as 25dB.
- **Multiple Speeds & Modes:** 9 wind speeds and 6 wind types (Normal, Natural, Auto, Sleep, Turbo, Custom).
- **Adjustable Height:** Pedestal adjustable from 37.5 to 43 inches.
- **Convenience:** Built-in 12-hour timer, easy-to-detach blades and grille for cleaning.

Setup

Unpacking and Assembly:

1. Carefully remove all components from the packaging.
2. Assemble the fan according to the included quick start guide. Assembly typically involves attaching the fan head to the pedestal and securing the base with a single screw.
3. Ensure all parts are securely fastened before proceeding.

Connecting to Wi-Fi and App:

1. Download the Dreo app from your smartphone's app store.
2. Follow the in-app instructions to connect your fan to your home's 2.4 GHz Wi-Fi network.
3. Once connected, you can link the fan to Google Assistant or Alexa for voice control.

Your browser does not support the video tag.

Video 1: Quick setup and overview of the fan's features, including Wi-Fi connectivity and app control.

Operating Instructions

Control Methods:

- **Touch Panel:** Use the intuitive touch controls on the fan's body.
- **Remote Control:** Utilize the included remote for convenient operation from a distance.
- **Dreo App:** Access full customization options, scheduling, and advanced features via the smartphone app.
- **Voice Control:** Integrate with Alexa or Google Assistant for hands-free operation.

Wind Speeds and Modes:

The fan offers 9 wind speeds and 6 distinct modes:

- **Normal:** Runs at a fixed speed.
- **Auto:** Adapts fan speed based on ambient temperature.
- **Sleep:** Lowers speed every 30 minutes by a maximum of 2 levels for quiet operation.

- **Natural:** Runs at changing speeds to simulate natural wind.
- **Turbo:** Runs at maximum speed for powerful airflow.
- **Custom:** Allows you to specify fan speed per temperature range via the app.

Oscillation Control:

The fan supports omni-directional oscillation:

- **Horizontal Oscillation:** Up to 150° range. Can be customized for specific angles (e.g., 30°, 60°, 90°, 120°, 150°).
- **Vertical Oscillation:** Up to 120° range. Can be customized for specific angles (e.g., 30°, 60°, 90°, 120°).
- Control oscillation angles precisely via the Dreo app for targeted airflow.

Your browser does not support the video tag.

Video 2: Detailed demonstration of fan controls, including speed, mode, and omni-directional oscillation settings.

Your browser does not support the video tag.

Video 3: Quick overview of the fan's features, including remote control and app functionality.

Maintenance

Cleaning the Fan:

- Always unplug the fan before cleaning.
- Blades and grille can be easily detached for thorough cleaning.
- Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure all parts are completely dry before reassembling and plugging in the fan.

Troubleshooting

Problem	Possible Cause	Solution
Fan does not turn on.	Not plugged in; power outage; power button not pressed.	Ensure fan is securely plugged into a working outlet; check power supply; press the power button.
Weak airflow.	Fan speed too low; dirty blades/grille.	Increase fan speed; clean blades and grille.
Fan makes unusual noise.	Obstruction in fan blades; loose parts.	Unplug and check for obstructions; ensure all parts are securely assembled.
Remote control not working.	Batteries drained; remote out of range; obstruction between remote and fan.	Replace remote batteries; ensure remote is within range and has a clear line of sight to the fan.

Problem	Possible Cause	Solution
App connectivity issues.	Incorrect Wi-Fi password; 5GHz Wi-Fi network; poor Wi-Fi signal.	Verify Wi-Fi password; ensure connection to a 2.4GHz network; move fan closer to router.

Specifications

Feature	Detail
Brand	Dreo
Model Name	DR-HPF004S Silver
Product Dimensions	8.7"D x 13.7"W x 43"H
Item Weight	14.08 Pounds
Power Source	DC Motor
Noise Level	25 dB
Air Flow Capacity	882 Cubic Feet Per Minute
Control Method	App, Remote, Touch, Voice
Special Features	Remote Controlled, Wi-Fi Enabled, Timer, Oscillating, App Operable
UPC	810142854160

Warranty & Support

For warranty information or technical support, please refer to the official Dreo website or contact their customer service directly. The product typically comes with a manufacturer's warranty covering defects in materials and workmanship. You can also refer to the official user manual PDF for more detailed informationDreo User Manual (PDF)

© 2025 Dreo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question