

Pomya Pomyasgb0rv5d8-11

Pomya Household Steam Cleaner User Manual

Model: Pomyasgb0rv5d8-11

INTRODUCTION

Thank you for choosing the Pomya Household Steam Cleaner. This powerful and versatile steam cleaning machine is designed for efficient and stable output, making it ideal for various household appliances and surfaces. With its high-temperature, pressurized steam, it effectively melts and cleans dirt and grime. Please read this manual thoroughly before operation to ensure safe and optimal use of your new steam cleaner.

Key features include:

- **Premium Design:** Integrated ABS suitcase for durability, with 304 stainless steel evaporator and electromagnetic pump.
- **Stable Operation:** Equipped with a 4-foot inlet hose for continuous and stable steam generation from an external water source.
- **High Power Output:** Reaches 230°F (110°C) in 20 seconds, delivering 3.5bar pressurized steam for effective cleaning.
- **Detergent Compatibility:** Allows addition of cleaning solutions to the water for enhanced cleaning.
- **Long Operation Support:** Designed for extended use without overheating, with a recommended 30-minute cycle for nozzle checks.

IMPORTANT SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the appliance:

1. Do not rinse the equipment directly with water. Avoid placing the equipment in damp or splashing environments to prevent short circuits, leakage, or damage.
2. After use, always drain any remaining water from the water inlet pipe and the machine to prevent mineral buildup and freezing, especially in cold weather.
3. Exercise caution when steam cleaning glass products. Do not apply steam to the same position for more than 3 seconds to prevent damage.
4. This appliance is not intended for use by minors or untrained persons.

PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the main unit and included accessories:



Figure 1: The Pomya Household Steam Cleaner main unit, showcasing its compact, portable design with the lid open, revealing the control panel and internal connections.



Figure 2: All included components of the steam cleaner, neatly arranged, including various nozzles, brushes, and the main unit.

The package includes:

- 1 x Steam Cleaner Main Unit
- 1 x Stainless Steel Extension Nozzle
- 1 x Water Heater Cleaning Pipe
- 1 x Atomizing Nozzle
- 1 x Large Brush
- 2 x Nylon Brush
- 2 x Copper Brush
- 2 x Sealing Ring
- 2 x Rubber Ring
- 1 x Flashlight (requires 1 x AA battery, not included)
- 1 x User Manual (this document)



Figure 3: A detailed view of the steam gun nozzle, showing its ergonomic design and steam outlet.



Figure 4: A close-up of the steam cleaner's control panel and the integrated precautions label, providing quick reference for safe operation.

SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Connect Inlet Hose:** Insert the 4-foot inlet hose into the designated port on the steam cleaner. Ensure it is securely connected.
3. **Prepare Water Source:** Place the other end of the inlet hose into an external bucket filled with clean water. This will serve as the continuous water supply for the steam cleaner.
4. **Attach Nozzle/Brush:** Select the appropriate nozzle or brush for your cleaning task and securely attach it to the steam gun.
5. **Power Connection:** Plug the steam cleaner into a standard 110V US power outlet.

OPERATING INSTRUCTIONS

1. **Power On:** Turn on the steam cleaner using the power switch. The unit will begin heating.
2. **Heating Time:** The steam cleaner will reach its operating temperature of up to 230°F (110°C) and generate 3.5bar pressurized steam within approximately 20 seconds.
3. **Begin Cleaning:** Once steam is continuously emitted, direct the nozzle towards the surface you wish to clean. Move the nozzle steadily over the area.
4. **Adding Detergent (Optional):** If desired, a cleaning solution or detergent can be added to the water in the external bucket. Ensure the solution is completely mixed before use.
5. **Operation Duration:** For optimal performance and to prevent overheating, it is suggested to operate the cleaner for 30 minutes, then pause to check if the nozzle is blocked. If no blockage is present, you may resume operation.
6. **Steam Control:** Use the steam control buttons on the unit to adjust steam output if available (refer to control panel diagram).



Figure 5: Illustrates the steam cleaner's effectiveness, showing a close-up of a dirty surface being cleaned by the steam gun.

- **Drain Water:** After each use, or before storing, ensure all remaining water is drained from the water inlet pipe and the machine to prevent mineral buildup and freezing.
- **Clean Remaining Solution:** If detergents were used, clean any remaining solution from the machine after use to prevent residue buildup.
- **Nozzle Check:** Periodically check the nozzle for any blockages. If steam output is reduced or inconsistent, the nozzle may need cleaning.
- **Storage:** Store the steam cleaner in a dry, cool place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam or low steam output.	Nozzle blockage; insufficient water supply; unit not heated sufficiently.	Check and clear any nozzle blockages. Ensure the external water bucket has enough water and the inlet hose is submerged. Allow adequate heating time (approx. 20 seconds).
Unit stops operating after 30 minutes.	Recommended operational pause for nozzle check and to prevent potential overheating.	This is normal operation. Check the nozzle for blockages. If clear, you may resume operation.
Water leakage.	Loose connections; damaged sealing rings.	Ensure all hoses and nozzles are securely connected. Check sealing rings for wear and replace if necessary (spare rings included).

SPECIFICATIONS

Feature	Specification
Brand	Pomya
Model Name	Pomyasgb0rvg5d8-11
Wattage	1700 watts
Power Source	Corded Electric (110V US Plug)
Water Consumption Rate	200-500 ML/Min
Air Pressure	300-350KPa (3.0-3.5 bar)
Max Temperature	230°F (110°C)
Item Weight	13.86 pounds
Package Dimensions	18.11 x 12.2 x 9.84 inches
Date First Available	January 17, 2024

WARRANTY AND SUPPORT

Pomya products are manufactured to high-quality standards. For any questions, technical support, or warranty claims,

please contact Pomya customer service through the retailer's platform or the official Pomya store page on Amazon.
Please retain your purchase receipt as proof of purchase for warranty purposes.
For further assistance, visit the [Pomya Store on Amazon](#).