

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [DREO](#) /

› [DREO PolyFan 704S Pedestal Fan Instruction Manual](#)

## DREO DR-HPF004S

# DREO PolyFan 704S Pedestal Fan Instruction Manual

Model: DR-HPF004S

## INTRODUCTION

---

Thank you for choosing the DREO PolyFan 704S Pedestal Fan. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new fan. Please read all instructions carefully before use and retain this manual for future reference.

## SAFETY INSTRUCTIONS

---

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury. Ensure the fan is placed on a stable, level surface. Do not insert fingers or objects into the grille while the fan is operating. Keep the power cord away from heated surfaces. Unplug the fan before cleaning or maintenance. This appliance is for indoor use only.

## PACKAGE CONTENTS

---

Upon unpacking, please ensure all items listed below are present and in good condition:

- DREO PolyFan 704S Pedestal Fan (Main Unit)
- Base
- Remote Control
- Remote Control Holder
- Power Adapter
- Base Screw & Washer
- Screwdriver (for base assembly)
- User Manual & Quick Start Guide

## SETUP

---

Follow these steps to assemble your DREO PolyFan 704S:

1. **Unpack Components:** Carefully remove all parts from the packaging. Take out the base and the main fan unit. Locate the accessories bag containing the base screw, washer, and screwdriver.

2. **Attach the Base:** Turn the main fan unit upside down. Align the jutting point on the base with the base cutout on the fan's pedestal. Insert the base into the pedestal, ensuring it doesn't move when rotating.
3. **Secure the Base:** Align the flat washer with the hole at the bottom of the base. Insert the base screw through the flat washer and into the fan unit. Fasten the screw securely using the included screwdriver.
4. **Position the Fan:** Turn the fan upright and remove any remaining wraps.
5. **Attach Remote Control Holder:** Snap the remote control holder onto the fan's pedestal at a convenient height.
6. **Adjust Height:** Rotate the adjustment collar counterclockwise to loosen, adjust the pedestal to your desired height (37.5-43 inches), then rotate clockwise to tighten.
7. **Power Connection:** Plug the power adapter into the fan's power port and then into a power outlet.

Your browser does not support the video tag.

**Video:** DREO PolyFan 704S Installation Guide. This video demonstrates the step-by-step assembly process of the DREO PolyFan 704S Pedestal Fan, including attaching the base, securing components, and connecting power.

## OPERATING INSTRUCTIONS

---

Your DREO PolyFan 704S offers multiple control methods for convenience.

### Control Panel & Remote Control

The fan features an intuitive touch control panel on its pedestal and comes with a handy remote control. Both allow you to adjust settings such as power, fan speed, mode, timer, and oscillation.

DREO | TurboPoly™ Fan 7 Series

# Peak Performance. All-in-one Fan.



**Image:** Front view of the DREO PolyFan 704S, highlighting the sleek design and integrated control panel on the pedestal.

## DREO App & Voice Control

Enhance your experience with the DREO app, available for download on your smartphone. The app allows for comprehensive control and customization, including:

- **Mode Selection:** Choose from 6 wind modes: Normal, Auto, Sleep, Natural, Turbo, and Custom.
- **Speed Adjustment:** Select from 9 wind speeds.
- **Omni-directional Oscillation:** Precisely control 150° horizontal and 120° vertical oscillation angles.
- **Schedules:** Set custom schedules for the fan to turn on/off or change settings based on your daily routine.

- **Custom Mode:** Create unique wind speed patterns that adapt to room temperature changes.
- **Voice Control:** Connect with Alexa or Google Assistant for hands-free operation.

Your browser does not support the video tag.

**Video:** DREO Pedestal Fans with Smart Control. This video showcases the smart control capabilities of the DREO PolyFan 704S, demonstrating app integration, mode selection, and oscillation adjustments.

## Modes & Speeds

The fan offers 9 speed levels and 6 distinct modes to suit various preferences and environments:

- **Normal Mode:** Provides a consistent airflow at a fixed speed.
- **Auto Mode:** Adapts fan speed based on the ambient room temperature.
- **Sleep Mode:** Gradually lowers fan speed over time for quiet operation during sleep, reaching as low as 25dB.
- **Natural Mode:** Simulates natural outdoor breezes with changing wind speeds.
- **Turbo Mode:** Delivers maximum airflow for rapid cooling, reaching up to 110 ft.
- **Custom Mode:** Allows you to define specific fan speed changes based on temperature ranges.

## Omni-directional Oscillation

Unlike traditional fans, the PolyFan 704S provides simultaneous 150° horizontal and 120° vertical oscillation, ensuring air circulation reaches every corner of your room.



**Image:** A diagram illustrating the 150-degree horizontal and 120-degree vertical oscillation capabilities of the fan, highlighting its omni-directional airflow.

## Timer Function

Set the fan to automatically turn off after a specified period, up to 12 hours, using the timer function on the control panel, remote, or DREO app.

## Adaptive Brightness & Child Lock

The display automatically dims in low light conditions. A child lock feature can be activated to prevent unintended changes to settings.


## MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your fan.

- **Easy Cleaning:** The front grille and fan blades are designed to be easily detached for thorough

cleaning. Refer to the quick start guide for detailed instructions on disassembly and reassembly.

- **Exterior Cleaning:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.



**Image:** Illustration of the fan's detachable grille and blades being cleaned under running water, emphasizing the easy maintenance.

## TROUBLESHOOTING

If you encounter any issues with your DREO PolyFan 704S, please refer to the following common solutions:

- **Fan not turning on:** Ensure the power adapter is securely plugged into both the fan and a working power outlet. Check if the power button has been pressed.
- **No airflow or weak airflow:** Verify the fan speed setting. Ensure the fan grille is not obstructed. Clean the fan blades and grille if dust buildup is present.
- **Unusual noise:** Check for any foreign objects caught in the fan blades or grille. Ensure the fan is placed on a stable, level surface to prevent vibrations.
- **App connectivity issues:** Ensure your smartphone's Bluetooth and Wi-Fi are enabled. Make sure the fan is within range of your Wi-Fi router (2.4 GHz network). Try restarting both the fan and your smartphone.
- **Remote control not working:** Check the battery in the remote control and replace if necessary. Ensure there are no obstructions between the remote and the fan.

## SPECIFICATIONS

<b>Brand</b>	DREO
<b>Model Name</b>	DR-HPF004S
<b>Color</b>	Gold
<b>Product Dimensions</b>	8.7"D x 13.7"W x 43"H
<b>Item Weight</b>	14.08 Pounds
<b>Power Source</b>	DC
<b>Wattage</b>	50 watts

<b>Noise Level</b>	25 Decibels
<b>Number of Speeds</b>	9
<b>Number of Modes</b>	6
<b>Oscillation</b>	150° Horizontal, 120° Vertical
<b>Max Air Flow Capacity</b>	882 Cubic Feet Per Minute (110ft range)
<b>Control Method</b>	App, Remote, Touch, Voice
<b>Timer</b>	12 Hours
<b>Motor Type</b>	Brushless DC

## WARRANTY & SUPPORT

---

For warranty information and customer support, please refer to the warranty card included in your package or visit the official DREO website. You can also find additional support and FAQs within the DREO app.