



[Manuals.plus](#) /

› [Madesa](#) /

› Madesa Agata 03 270cm Integrated Kitchen Cabinet Assembly and User Manual

Madesa Agata 03

Madesa Agata 03 270cm Integrated Kitchen Cabinet Assembly and User Manual

Model: Agata 03 | Brand: Madesa

1. INTRODUCTION

Thank you for choosing the Madesa Agata 03 270cm Integrated Kitchen Cabinet. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new kitchen furniture. Please read these instructions carefully before beginning assembly or use, and keep them for future reference.

Madesa is committed to quality, service, and innovation, providing durable and sustainable products designed to enhance your home.

2. SAFETY INFORMATION

- Always follow the assembly instructions precisely to ensure structural integrity.
- Use appropriate tools for assembly. Do not overtighten screws to avoid damaging the material.
- Ensure the kitchen cabinet is placed on a level and stable surface.
- Keep small parts and hardware out of reach of children during assembly.
- Do not overload shelves or drawers beyond their recommended weight capacity.
- For floor-mounted units, ensure proper anchoring if required for stability, especially in earthquake-prone areas or homes with children.

3. PACKAGE CONTENTS

Before starting assembly, verify that all components and hardware are present. Refer to the included assembly manual for a detailed list of parts. If any parts are missing or damaged, please contact Madesa customer support.



Figure 3.1: Overview of the Madesa Agata 03 270cm Integrated Kitchen Cabinet. This image shows the complete kitchen assembly, including upper and lower cabinets, a tall pantry unit, and space for appliances.

4. SPECIFICATIONS

Feature	Description
Brand	Madesa
Model	Agata 03
Total Width	270cm (approx. 106.3 inches)
Mounting Type	Floor Mounting
Door Style	Slab
Material	High-quality medium-density particleboard from renewable forests.
Finish	Polyester paint with 7 protective layers.

Handles	Bronze-colored aluminum handles.
Drawers	Wide drawers with telescopic slides.
Hinges	Soft-close hinges.
Feet	Adjustable feet with removable baseboards.
ASIN	B0CSKP2CSG




Figure 4.1: Detailed dimensions of the Madesa Agata 03 Integrated Kitchen Cabinet. This diagram illustrates the overall width (270cm), height (225cm), and individual module dimensions, including depths of 52cm for lower cabinets and 31cm for upper cabinets.



Figure 4.2: Madesa Agata 03 Integrated Kitchen Cabinet shown with a person for scale, highlighting the total height of 225cm.

5. SETUP AND ASSEMBLY

The Madesa Agata 03 kitchen cabinet requires assembly. An assembly manual with detailed, easy-to-follow instructions and all necessary hardware is included with your product. Please follow these steps carefully:

1. **Unpack and Inspect:** Carefully unpack all components and check against the parts list in the assembly manual. Report any discrepancies immediately.
2. **Prepare the Area:** Choose a clean, flat, and spacious area for assembly. Protect your floor with a blanket or cardboard.
3. **Assemble Base Units:** Begin by assembling the base cabinets, ensuring all connections are secure.
4. **Install Adjustable Feet:** Attach the adjustable feet to the base units. These allow for leveling on uneven floors.
5. **Assemble Upper Units:** Proceed with the assembly of the upper cabinets and the tall pantry unit.
6. **Mount Units:** Securely mount upper cabinets to the wall according to the instructions. Ensure proper wall anchors are used for your wall type.

7. **Install Drawers and Doors:** Install drawers with their telescopic slides and attach doors using the soft-close hinges.
8. **Attach Handles:** Fasten the bronze-colored aluminum handles to all doors and drawers.
9. **Final Adjustments:** Adjust doors and drawers for proper alignment and smooth operation. Adjust the height of the adjustable feet to level the entire kitchen unit.




Figure 5.1: Key features of the Madesa Agata 03 kitchen, including aluminum handles, reflex glass, 52cm planned kitchen depth, soft-close door hinges, and adjustable/removable feet.

Rodapés removíveis e pés reguláveis



PÉS REGULÁVEIS PARA PEQUENOS DESNÍVEIS



Figure 5.2: Illustration of the removable baseboards and adjustable feet (15cm to 20cm) for the Madesa Agata 03 kitchen, allowing for easy leveling and quick installation.

6. OPERATING INSTRUCTIONS


Your Madesa Agata 03 kitchen cabinet is designed for practical and comfortable use. Here are some guidelines for optimal operation:

- **Drawers:** The wide drawers are equipped with telescopic slides for smooth and full extension. Avoid forcing them if they feel stiff.
- **Doors:** Doors feature soft-close hinges, ensuring a gentle and silent closing action. Do not slam doors.
- **Adjustable Shelves:** The tall pantry unit includes adjustable shelves, allowing you to customize storage space for various items.
- **Weight Distribution:** Distribute weight evenly across shelves and within drawers to prevent warping or damage.

Gavetas
amplas com
corrediças
telescópicas



Figure 6.1: Close-up of a drawer in the Madesa Agata 03 kitchen, demonstrating the wide design and smooth telescopic slides for easy access.



Puxadores elegantes na cor bronze com **alça de alumínio.**

Figure 6.2: Detail of the elegant bronze-colored aluminum handle used on the Madesa Agata 03 kitchen cabinets and drawers.



Torre quente possui prateleira com altura regulável

Figure 6.3: The tall pantry unit of the Madesa Agata 03 kitchen, featuring an adjustable shelf to accommodate items of various heights.

7. MAINTENANCE

Proper care and maintenance will ensure the longevity and appearance of your Madesa Agata 03 kitchen cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Use mild soap if necessary. Avoid abrasive cleaners, harsh chemicals, or solvents, as these can damage the polyester paint finish.
- **Spills:** Clean up spills immediately to prevent staining or moisture damage, especially on particleboard surfaces.
- **Heat and Moisture:** Avoid placing hot items directly on surfaces without protection. Protect the cabinets from excessive moisture and steam.
- **Hardware:** Periodically check all screws and fittings to ensure they are tight. Retighten if necessary, but do not overtighten.
- **Adjustable Feet:** Re-check the leveling of the cabinets periodically, especially after moving or if the floor settles.

8. TROUBLESHOOTING

This section addresses common issues you might encounter with your kitchen cabinet.

Problem	Possible Cause	Solution
Doors or drawers do not close properly.	Misaligned hinges or slides; uneven floor.	Adjust hinges/slides according to the assembly manual. Check and adjust the adjustable feet to level the cabinet.
Cabinet feels wobbly or unstable.	Uneven floor; loose connections; improper wall mounting.	Ensure all adjustable feet are properly set and the cabinet is level. Tighten all assembly screws. Verify wall mounting for upper units.
Drawers are stiff or difficult to open/close.	Debris in slides; misaligned slides; overloaded drawer.	Clean drawer slides. Check for proper alignment of slides. Reduce weight in the drawer.

If you encounter issues not listed here or if the suggested solutions do not resolve the problem, please contact Madesa customer support.

9. WARRANTY AND SUPPORT

Madesa products are manufactured with high-quality materials and undergo rigorous quality control. For specific warranty details, please refer to the warranty card included with your product or visit the official Madesa website.

For customer support, missing parts, or technical assistance, please contact Madesa directly. Keep your purchase receipt and product model information (Agata 03, ASIN: B0CSKP2CSG) handy when contacting support.

You can visit the Madesa store on Amazon for more information: [Madesa Store](#)