

[Manuals.plus](#) /

- › [Harman Kardon](#) /
- › Harman Kardon Aura Studio 4 Bluetooth Home Speaker User Manual

Harman Kardon Aura Studio 4

Harman Kardon Aura Studio 4 Bluetooth Home Speaker User Manual

Model: Aura Studio 4 | Brand: Harman Kardon

1. INTRODUCTION

The Harman Kardon Aura Studio 4 is a Bluetooth home speaker designed to deliver 360-degree audio with integrated ambient light effects. It combines a distinctive design with advanced audio technology for a comprehensive listening experience.



Image: Harman Kardon Aura Studio 4 Bluetooth Home Speaker.



This speaker is constructed using 100% recycled fabric, 100% recycled aluminum, and 85% recycled plastic. Packaging is made from FSC-certified paper with soy-based inks.

Video: An overview of the Harman Kardon Aura Studio 4 speaker, showcasing its design and features.

2. WHAT'S IN THE BOX

Verify that all components are present in the packaging:

- Aura Studio 4 Speaker Unit
- Power Cable
- Quick Start Guide
- Safety Sheet
- Warranty Card



WHAT'S IN THE BOX

Image: Contents of the Harman Kardon Aura Studio 4 package, including the speaker, power cable, and documentation.

Video: A quick unboxing of the Aura Studio 4, showing the speaker and included accessories.

3. SETUP

1. **Placement:** Place the Aura Studio 4 on a stable, flat surface. For optimal 360-degree audio, position it centrally in your listening area.
2. **Power Connection:** Connect the provided power cable to the power input port on the speaker and then plug it into a wall outlet.
3. **Power On:** Press the power button located on the top of the speaker to turn it on. The ambient lighting will illuminate.

4. OPERATING INSTRUCTIONS

4.1 Bluetooth Pairing

1. Ensure the speaker is powered on.
2. Press the **Bluetooth button** (⌂) on the front of the speaker. The indicator light will flash, indicating it is in pairing mode.
3. On your mobile device (smartphone, tablet, or laptop), go to the Bluetooth settings.
4. Select "Harman Kardon Aura Studio 4" from the list of available devices.
5. Once connected, the Bluetooth indicator light on the speaker will become solid.



Image: The Aura Studio 4 speaker connected wirelessly via Bluetooth to a mobile device.

4.2 Volume Control

Adjust the volume using the **+** and **-** buttons located on the front of the speaker, or directly from your connected device.

4.3 Ambient Lighting Control

The transparent dome of the Aura Studio 4 features five distinct diamond-effect lighting patterns and colors. Use the **light button** (⌂) on the front of the speaker to cycle through the available lighting themes.

AMBIENT LIGHTING

Unique diamond-effect lighting that dances to the music




Image: Close-up view of the ambient diamond-effect lighting on the Aura Studio 4.

4.4 Advanced Sound Customization (Bass/Treble)

To adjust bass and treble levels, use the following button combinations:

- **Adjust Bass:** Press and hold the **+** button, then simultaneously press the **Bluetooth button** (Ⓜ). Continue holding **+** and press **Bluetooth** repeatedly to increase bass.
- **Adjust Treble:** Press and hold the **+** button, then simultaneously press the **light button** (Ⓛ). Continue holding **+** and press **light** repeatedly to increase treble.

Video: A detailed review and demonstration of the Harman Kardon Aura Studio 4, including sound adjustments and lighting effects.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Avoid abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the speaker with care to prevent damage to the transparent dome or internal

components.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable not connected or outlet not working.	Ensure the power cable is securely connected to both the speaker and a working power outlet.
Cannot pair via Bluetooth	Speaker not in pairing mode or device too far.	Press the Bluetooth button on the speaker to enter pairing mode. Ensure your device is within 10 meters (33 feet) of the speaker.
No sound	Volume too low, device not connected, or incorrect source.	Increase volume on both the speaker and your device. Verify Bluetooth connection.
Lighting not working	Lighting feature may be off or malfunctioning.	Press the light button to activate or change lighting themes. If the issue persists, contact support.

7. SPECIFICATIONS

Feature	Detail
Brand	Harman Kardon
Model Name	Aura Studio 4
Model Number	Aura Studio 4
Speaker Maximum Output Power	100 Watts
Connectivity Technology	Bluetooth
Audio Output Mode	360-degree audio
Mounting Type	Tabletop Mount
Speaker Type	Portable Bluetooth Speaker
Subwoofer Diameter	13.21 Centimeters (5.2 Inches)
Color	Black
Is Waterproof	FALSE
Control Method	App
Bluetooth Range	10 Meters
Specific Uses For Product	Home, Portable Use
Number of Audio Channels	7.1
Audio Driver Type	Dynamic Driver

Feature	Detail
Item Weight	7.93 Pounds
Compatible Devices	Smartphone, Tablet, Laptop
Power Source	Corded Electric
Number of Batteries	1 12V batteries required. (included)
UPC	657768939327

SUPERIOR SOUND PERFORMANCE

Your music is reproduced with pinpoint accuracy, thanks to the speaker's distinct channels and dedicated amplifiers, reproducing every sonic detail with breathtaking clarity.



Dimension (H x W x D): 11.2" x 9.1" x 9.1"

Image: The Aura Studio 4 speaker highlighting its superior sound performance and dimensions (H x W x D): 11.2" x 9.1" x 9.1".

8. WARRANTY AND SUPPORT

The Harman Kardon Aura Studio 4 comes with a **90 days limited warranty**. For technical support, service, or warranty claims, please refer to the contact information provided in the Warranty Card included in your package or visit the official Harman Kardon support website.

