

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [WOLTU](#) /

› WOLTU SSK007hov 8-Drawer Dresser with Charging Station User Manual

WOLTU SSK007hov

WOLTU SSK007hov 8-Drawer Dresser with Charging Station User Manual

Model: SSK007hov

1. INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your WOLTU SSK007hov 8-Drawer Dresser with Charging Station. Please read this manual thoroughly before assembly and use to ensure safe and correct operation. Keep this manual for future reference.



Image 1.1: The WOLTU SSK007hov 8-Drawer Dresser with Charging Station, featuring a rustic brown and black design, suitable for various room settings.

2. SAFETY INFORMATION

- Always follow the assembly instructions carefully.
- Do not overload drawers or shelves. Refer to the specifications for weight limits.
- Secure the dresser to the wall using the provided anti-tip kit to prevent accidental tipping, especially in households with children or pets.
- Ensure the charging station is connected to a properly grounded electrical outlet. Do not use if the power cord is damaged.
- Keep liquids away from the charging station to prevent electrical hazards.
- Do not allow children to climb on the dresser.



Image 2.1: Anti-tip device for wall mounting, essential for stability.



Image 2.2: Integrated charging station with two USB ports and two power outlets.

3. PACKAGE CONTENTS

Before assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Metal Frame Components
- Wooden Top Panels and Shelves
- 8 Fabric Drawers with Wood-Look Fronts
- Charging Station Unit (2 USB ports, 2 outlets, 2m power cable)
- 2 Side Hooks
- Assembly Hardware (screws, bolts, Allen wrench)
- Anti-Tip Kit
- Instruction Manual

4. SETUP AND ASSEMBLY

Follow these step-by-step instructions for assembling your WOLTU SSK007hov dresser. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

1. **Assemble the Metal Frame:** Connect the vertical and horizontal metal bars using the provided screws and Allen wrench. Ensure all connections are secure.
2. **Attach Wooden Panels:** Place the wooden top and side panels onto the assembled metal frame. Secure them with the designated screws.
3. **Install Charging Station:** Insert the charging station unit into its designated slot on the top panel. Secure it with screws if applicable.
4. **Assemble Fabric Drawers:** Fold the fabric drawers into shape and insert the bottom panel. Attach the wood-look front panel and handle to each drawer.
5. **Insert Drawers:** Slide the assembled fabric drawers into their respective compartments in the dresser frame.
6. **Attach Hooks and Anti-Tip Kit:** Secure the two side hooks to the metal frame. Install the anti-tip kit to the back of the dresser and to a wall stud for stability.

Easy to Install

Detailed instructions and numbered parts are included




Image 4.1: Visual guide for the six-step assembly process of the dresser.

5. OPERATING INSTRUCTIONS

5.1 Drawer Usage

The dresser features 8 fabric drawers designed for various storage needs. Each drawer is equipped with a sturdy handle for easy opening and closing.

- **Capacity:** Each drawer can hold approximately 60-80 pairs of socks, 15-18 T-shirts, or 8-11 pairs of jeans.
- **Smooth Operation:** Ensure drawers are properly aligned within their compartments for smooth gliding.



Each drawer can hold:



10-15



5-10



30-40



Image 5.1: Drawer capacity demonstration for clothing items.



Image 5.2: Detail of the sturdy drawer handle.

5.2 Charging Station

The integrated charging station provides convenient power access for your electronic devices.

- **Power Connection:** Plug the 2-meter power cable into a standard wall outlet.
- **USB Ports:** Use the two USB ports to charge smartphones, tablets, earphones, and other USB-powered devices.
- **Power Outlets:** The two two-pin outlets are suitable for charging laptops, desk lamps, or other small appliances.

5.3 Side Hooks

The two side hooks offer additional storage for hanging items.

- Use the hooks to hang keys, bags, scarves, or other lightweight accessories.
- Do not exceed the weight limit of the hooks to prevent damage.



Image 5.3: Detail of the practical side hooks for hanging items.

6. MAINTENANCE

6.1 Cleaning

- **Wooden and Metal Surfaces:** Wipe clean with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals that may damage the finish.
- **Fabric Drawers:** Spot clean with a mild detergent and a damp cloth. Allow to air dry completely. Do not machine wash.



Image 6.1: The water-resistant surface is easy to clean with a damp cloth.

6.2 General Care

- Periodically check all screws and connections to ensure they remain tight. Retighten as necessary.
- Ensure the dresser is placed on a level surface. The adjustable feet can be used to compensate for uneven floors.



Image 6.2: Adjustable feet allow for leveling on uneven surfaces.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Dresser is wobbly.	Uneven floor; loose screws; anti-tip kit not installed.	Adjust the leveling feet; tighten all assembly screws; install the anti-tip kit securely to the wall.
Drawers do not slide smoothly.	Drawer not properly inserted; contents overloaded; fabric drawer deformed.	Re-insert the drawer correctly; reduce the weight of contents; ensure the fabric drawer is fully expanded and its bottom panel is flat.
Charging station not working.	Power cable not plugged in; wall outlet not active; device not compatible.	Ensure the power cable is securely plugged into both the charging station and a working wall outlet. Test the outlet with another device. Verify device compatibility.

8. SPECIFICATIONS

- **Brand:** WOLTU
- **Model Number:** SSK007hov
- **Color:** Rustic Vintage Wood Look and Black
- **Product Dimensions (L x W x H):** 132 x 29 x 88 cm (52 x 11.4 x 34.6 inches)
- **Material:** Wood, Metal, Fabric
- **Item Weight:** 17.14 kg (37.78 lbs)
- **Number of Drawers:** 8
- **Charging Station:** 2 USB ports, 2 two-pin power outlets, 2m power cable
- **Drawer Load Capacity:** 5 kg (11 lbs) per drawer
- **Top Surface Load Capacity:** 40 kg (88 lbs)



Image 8.1: Detailed dimensions and weight capacities of the WOLTU SSK007hov dresser.

9. WARRANTY AND SUPPORT

WOLTU products are designed for quality and durability. For any questions regarding assembly, missing parts, or product defects, please contact WOLTU customer support. Please have your model number (SSK007hov) and purchase information ready when contacting support.

Warranty information may vary by region and retailer. Please refer to your purchase documentation for specific warranty terms and conditions.