

HZGAMER A01SP021307003

User Manual: HZGAMER Tesla Phone Mount

Model: A01SP021307003



INTRODUCTION

Thank you for choosing the HZGAMER Tesla Phone Mount. This manual provides detailed instructions for the proper installation, operation, and maintenance of your new phone mount. Please read this manual thoroughly before use to ensure optimal performance and safety.

PRODUCT OVERVIEW

The HZGAMER Tesla Phone Mount is specifically designed for the central touch screen of Tesla Model 3 and Model Y vehicles, offering a secure and convenient way to hold your smartphone while driving.

Key Features

- **Tesla-Specific Design:** Engineered for seamless integration with the central touch screen of Tesla Model 3/Y, featuring an adjustable knob for easy installation on screen corners.
- **Foldable Design:** Allows the mount to be discreetly hidden when not in use.
- **Strong Magnetic Hold:** Equipped with powerful magnets to ensure your phone remains secure even on uneven terrain, enhancing driving safety.
- **One-Handed Operation:** Effortless attachment and detachment of your phone with a single hand.
- **Universal Phone Compatibility:** Compatible with iPhone 15, 14, 13, and 12 series (MagSafe functionality). For non-MagSafe phones, a provided magnetic ring can be attached to the phone's back or case exterior.
- **Signal Integrity:** Designed not to interfere with mobile phone signals, ensuring normal and fluent use of navigation and other functions.
- **Flexible Viewing:** Features a 360° ball joint for seamless adjustment between horizontal and vertical orientations.
- **Driver Comfort:** Positioned on the dashboard to avoid blocking the driver's view, promoting safer driving by keeping the device within easy sight.

What's in the Box

- Central control screen Mount
- Magnetic Ring (for non-MagSafe phones)



Image: The HZGAMER Tesla Phone Mount, showcasing its sleek design and magnetic phone attachment point.

SETUP AND INSTALLATION

Follow these steps to properly install your HZGAMER Tesla Phone Mount:

1. **Prepare the Mount:** Unfold the mount and identify the screen locking mechanism and adjustment knobs.
2. **Position on Screen:** Place the mount on the corner of your Tesla's central touch screen. The mount is designed to securely grip the edge of the screen.
3. **Lock in Place:** Turn the Screen Locking Knob (labeled '1' in the diagram below) to firmly secure the phone holder in place at the edge of the screen. Ensure it is tight enough to prevent movement but do not overtighten to avoid damage to the screen.
4. **Adjust Angle:** Turn the Angle Adjustment Knob (labeled '2' in the diagram below) to set the desired viewing angle for the phone holder.
5. **Adjust Distance:** Turn the Distance Adjustment Knob (labeled '3' in the diagram below) to adjust the distance between the magnetic head and the edge of the screen, optimizing placement for your phone.
6. **Final Adjustment:** The magnetic head and the stand are connected by a ball joint (labeled '4' in the diagram

below), allowing for full rotational movement. Adjust this joint for precise phone positioning.



Image: Step-by-step diagram illustrating the adjustment knobs and their functions for installation.



Image: Close-up view of the mount's contact points with the Tesla screen, highlighting the shock absorption and anti-slip silicone for

OPERATING INSTRUCTIONS

Once installed, using your HZGAMER Tesla Phone Mount is straightforward:

- **Attaching Your Phone:** Simply bring your MagSafe-compatible iPhone (or a non-MagSafe phone with the magnetic ring attached) close to the magnetic surface of the mount. The strong magnets will automatically secure your phone in place.
- **Detaching Your Phone:** Gently pull your phone away from the magnetic surface. The design allows for easy one-handed removal.
- **Adjusting Phone Orientation:** The 360° ball joint allows you to rotate your phone to either a vertical (portrait) or horizontal (landscape) orientation as needed for navigation or other applications.



Image: A hand demonstrating the ease of attaching a phone to the magnetic mount, emphasizing one-handed operation.

360° Vertical & Horizontal



Image: Illustrates the 360° rotational capability of the mount, showing a phone in both vertical and horizontal orientations on the Tesla screen.

DEVICE COMPATIBILITY

The HZGAMER Tesla Phone Mount is designed for broad compatibility:

- **For iPhone 12/13/14/15 Series:** These models feature built-in MagSafe technology and can directly attach to the mount without any additional accessories.
- **For Other Phones (iPhone 11 & Below, Android Phones, etc.):** For phones without MagSafe functionality or non-magnetic cases, a magnetic ring is included. Attach this ring to the back of your phone or the exterior of your phone case to enable magnetic attachment to the mount.

Work for iPhone

Work for iPhone 15/14/13/12 Series or MagSafe case without Magnetic ring



iPhone 15 14 13 12 series works directly



▲ Magnetic Ring

Work for Other Phone

iPhone 11 & Below Series, Android Phones, Unofficial Case with Magnetic ring



Non-magnet case

Image: A visual guide demonstrating compatibility for iPhone 12-15 series (direct use) and other phones (requiring the magnetic ring).

SPECIFICATIONS

Attribute	Detail
Brand	HZGAMER
Model Number	A01SP021307003
Mounting Type	Central Control Screen Mount
Compatible Devices	All Phones
Compatible Phone Models	iPhone 12/12 Mini/12 Pro/12 Pro Max/SE/11/11 Pro/11 Max/Xs/Xs Max/XR/X/8/8 Plus/7/7 Plus/6/6S/6S Plus, Samsung Galaxy S22/S22+/S22 Ultra/S21 FE/S21 5G/S21+ 5G/S21 Ultra 5G/S20 FE/S20/S20+/S20 5G/Note20/Note10/Note10+/S10/S10+/S10E/S9/S9+/S8/S8+/Note 8/S7/S7 Edge/S6, Google/LG/Motorola/OnePlus/SONY/HTC and more
Special Features	Adjustable
Color	Black
Item Weight	6.7 ounces
Package Dimensions	6.46 x 3.5 x 3.23 inches
Country of Origin	China

TROUBLESHOOTING

If you encounter any issues with your HZGAMER Tesla Phone Mount, please refer to the following common solutions:

- **Phone Not Holding Securely:**
 - Ensure the magnetic ring is properly attached to the back of your non-MagSafe phone or case.
 - Verify that there are no obstructions (e.g., thick phone cases, pop sockets) between the phone and the

magnetic surface that might weaken the magnetic connection.

- Clean the magnetic surface of the mount and the phone/magnetic ring to ensure optimal contact.

- **Mount Feels Loose or Shaky:**

- Re-tighten the Screen Locking Knob to ensure the mount is firmly secured to the Tesla screen.
- Check and tighten all other adjustment knobs (Angle Adjustment Knob, Distance Adjustment Knob) to prevent unwanted movement during driving.
- Ensure the mount is positioned correctly on the screen's edge, utilizing the anti-slip silicone pads for maximum grip.

- **Difficulty Adjusting Angle/Position:**

- Loosen the relevant adjustment knob slightly before attempting to reposition, then re-tighten once the desired angle is achieved.
- Ensure no debris is obstructing the movement of the ball joint or other adjustable parts.

If the issue persists after attempting these solutions, please contact customer support.

WARRANTY AND CUSTOMER SUPPORT

HZGAMER is committed to providing high-quality products. While specific warranty details are not provided in this manual, please retain your proof of purchase. For any product-related inquiries, technical support, or warranty claims, please contact HZGAMER customer service through the retailer where you purchased the product or visit the official HZGAMER website for contact information.

