

manuals.plus /

> [Outsunny](#) /

> [Outsunny 3-in-1 Portable Fire Pit, Stove, and Coffee Table \(Model 842-340V00BK\) Instruction Manual](#)

Outsunny 842-340V00BK

Outsunny 3-in-1 Portable Fire Pit, Stove, and Coffee Table Instruction Manual

Model: 842-340V00BK

1. IMPORTANT SAFETY INFORMATION

Please read and understand all safety warnings and instructions before assembling, operating, or maintaining this product. Failure to follow these instructions may result in fire, property damage, personal injury, or even death.

- Always use this fire pit in a well-ventilated outdoor area.
- Keep children and pets at a safe distance from the fire pit at all times.
- Never leave the fire unattended.
- Ensure the fire pit has completely cooled down before disassembling, moving, or storing it.
- Always use a fire screen (if included or recommended) to prevent sparks or embers from escaping.
- Do not use gasoline, kerosene, diesel fuel, lighter fluid, or alcohol to start or restart a fire.
- Place the fire pit on a stable, non-combustible surface.
- Keep combustible materials at a safe distance from the fire pit.

2. PRODUCT OVERVIEW

The Outsunny 3-in-1 Portable Fire Pit is a versatile outdoor appliance designed for various uses. It functions as a wood-burning fire pit, a stove for cooking, and a convenient coffee table. Its compact design and quick assembly make it suitable for camping, picnics, backyard use, and patio gatherings.

3-IN-1

Fire Pit



Stove



Coffee Table



Image: The Outsunny 3-in-1 Fire Pit demonstrating its three primary functions: a fire pit, a stove, and a coffee table.

3. PACKAGE CONTENTS

Before assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Fire Pit Side Panels (4 pieces)
- Bottom Plate with Vents
- Top Grate/Table Surface
- Waterproof Carrying Bag

4. SETUP AND ASSEMBLY

This fire pit features a quick, tool-free assembly process. Follow these steps:

1. Unpack all components from the carrying bag.
2. Identify the four side panels and the bottom plate.
3. Interlock the side panels by sliding their tabs into the corresponding slots. Ensure they form a stable

rectangular structure.

4. Insert the bottom plate into the assembled side panels, ensuring it rests securely at the base.
5. Place the top grate/table surface onto the assembled structure.



Image: A visual representation of the fire pit's plug-in assembly, highlighting the individual components that fit together without tools.

5. OPERATING INSTRUCTIONS

5.1 As a Fire Pit

To use as a fire pit for warmth or ambiance:

1. Ensure the fire pit is assembled correctly and placed on a safe, non-combustible surface away from flammable materials.
2. Remove the top grate/table surface.
3. Place a small amount of kindling and dry wood or charcoal onto the bottom plate.
4. Carefully ignite the kindling. The vents on the bottom and side panels are designed to ensure sufficient oxygen supply for combustion.
5. Add more wood or charcoal as needed, ensuring not to overload the pit.

6. Always supervise the fire.



Image: The portable fire pit in use, with a wood fire burning, creating a cozy atmosphere outdoors.

5.2 As a Stove

To use for cooking or heating beverages:

1. Follow steps 1-4 for using as a fire pit to establish a stable fire.
2. Once the fire is burning steadily, place the top grate/table surface back onto the fire pit.
3. Place your pot, kettle, or pan directly onto the grate for heating.
4. Monitor cooking closely and adjust fuel as necessary.



Image: The fire pit configured as a stove, with a kettle placed on its top surface for heating water.

5.3 As a Coffee Table

When not in use for burning, the unit can serve as a small coffee table:

1. Ensure there is no fire or embers present and the unit is completely cool.
2. Place the top grate/table surface securely on the fire pit structure.
3. Use the flat surface to hold drinks, snacks, or other small items.



Image: The fire pit functioning as a coffee table, holding two cups and a jar of snacks in an outdoor patio setting.

6. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and safe operation of your fire pit.

- **Cleaning:** After each use, once the fire pit is completely cool, remove any ash or debris. Wipe down the steel surfaces with a damp cloth. Avoid abrasive cleaners that could damage the powder coating.
- **Cooling:** Always allow the fire pit to cool down completely before attempting to clean, disassemble, or store it. This can take several hours.
- **Inspection:** Periodically inspect all components for signs of wear, rust, or damage. Replace any damaged parts immediately.
- **Material:** The steel surface is treated with a water and high-temperature-resistant powder coating for durability.

POWDER-COATED STEEL PLATE

Withstand high temperature
and weather elements



MULTIPLE VENTS

Ensure sufficient oxygen
supply and full combustion

Image: Detail of the fire pit's construction, showing the powder-coated steel plate and the multiple vents designed for optimal airflow and combustion.

7. STORAGE

For convenient storage and transport:

1. Ensure the fire pit is completely cool and clean.
2. Disassemble the fire pit by reversing the assembly steps.
3. Place all components into the provided waterproof carrying bag.
4. Store the bag in a dry, protected area.



PORTABLE CARRYING BAG

Compact to store and transport

Image: A hand placing the compact, waterproof carrying bag containing the disassembled fire pit into the trunk of a car, demonstrating its portability.

8. TROUBLESHOOTING

If you encounter issues with your fire pit, consider the following:

- **Difficulty Starting Fire:** Ensure wood or charcoal is dry. Check for proper airflow; clear any obstructions from the vents. Use appropriate kindling.
- **Excessive Smoke:** This often indicates wet or green wood. Use only dry, seasoned wood. Ensure adequate airflow.
- **Instability:** Re-check assembly to ensure all panels are securely interlocked. Ensure the fire pit is placed on a flat, stable surface.

9. SPECIFICATIONS

Feature	Detail
Model Number	842-340V00BK

Feature	Detail
Overall Dimensions	16.25" L x 11.75" W x 8.75" H
Material	Alloy Steel
Finish Type	Powder Coated
Item Weight	11 Pounds
Fuel Type	Wood
Color	Black
Carry Bag Size	16.5" W x 11" D




Image: Technical drawing illustrating the length, width, and height dimensions of the assembled fire pit.

10. WARRANTY AND SUPPORT

For warranty information, replacement parts, or customer support, please contact Outsunny directly through their official website or the retailer from whom the product was purchased. Please have your model number (842-340V00BK) and purchase date available when contacting support.