

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VOSFEEL](#) /

› [VOSFEEL Camping Fan F6 User Manual](#)

VOSFEEL F6

VOSFEEL Camping Fan F6 User Manual

Model: F6 | Brand: VOSFEEL

INTRODUCTION

This manual provides detailed instructions for the operation, maintenance, and troubleshooting of your VOSFEEL F6 Camping Fan. Please read this manual thoroughly before using the product to ensure safe and optimal performance.



Image: The VOSFEEL F6 Camping Fan, showcasing its fan and LED lantern features, along with charging capabilities for mobile devices and a remote control.

PACKAGE CONTENTS

Ensure all items are present upon unboxing:

- VOSFEEL F6 Camping Fan
- Remote Control
- USB Type-C Charging Cable
- User Manual (this document)
- Built-in Lithium Ion Battery (20000mAh)

SETUP AND CHARGING

Before first use, fully charge the fan. The fan supports fast charging via its Type-C port.

1. **Initial Charge:** Connect the provided USB Type-C cable to the fan's Type-C input port and a compatible 5V/3A charger (not included). The battery indicator lights will show charging progress.
2. **Placement:** Place the fan on a stable, flat surface. For hanging, utilize the rotatable and foldable hook located at the bottom of the fan. It can be hung from tent tops or tree branches.
3. **Remote Control Setup:** Ensure the remote control's battery is inserted. The remote is pre-paired with the fan.



Image: The VOSFEEL F6 Camping Fan showing its remote control and adjustable head (45°-90° vertical rotation, 270° horizontal rotation) for versatile positioning.

OPERATING INSTRUCTIONS

Fan Operation

The fan features 4 adjustable wind speeds. Use the control panel buttons or the remote control.

- **Power On/Off:** Press the power button on the fan or the OFF button on the remote.
- **Adjust Fan Speed:** Press the fan speed button on the control panel or the fan speed +/- buttons on the remote to cycle through 4 speeds (1-Breeze, 2-Soft Wind, 3-Comfort, 4-Strong Wind).
- **Oscillation:** Press the oscillation button on the fan or remote to activate automatic rotation (45° or 90°). Press again to stop.
- **Timer Function:** Set the fan to turn off automatically after 1, 2, 4, or 8 hours using the timer button on the fan or remote.



Image: The VOSFEEL F6 Camping Fan highlighting its 20000mAh battery capacity and approximate runtimes: Speed 1 (58 hours), Speed 2 (32 hours), Speed 3 (19 hours), Speed 4 (12 hours).

LED Lantern Operation

The integrated LED lantern has 3 brightness settings.

- **Turn On/Off Light:** Press the light button on the fan or the light button on the remote.

- **Adjust Brightness:** Press the light button repeatedly to cycle through Low, Medium, and High brightness modes.
- **Sleep Mode:** Press the moon icon button on the fan or remote to turn off all indicator lights for undisturbed sleep. The fan will continue to operate.



Image: The VOSFEEL F6 Camping Fan demonstrating its three LED light brightness modes: Low, Medium, and High, suitable for various lighting needs.

Power Bank Function

The fan's 20000mAh battery can also serve as a power bank with two output ports (USB-A and USB-C).

- **Charging Devices:** Connect your mobile phone, laptop, or other USB-powered devices to the fan's USB-A or Type-C output ports using your device's charging cable. The fan supports 15W fast charging for connected devices.
- You can use the fan function simultaneously while charging external devices.



Image: The VOSFEEL F6 Camping Fan connected via USB-C and USB-A ports to charge a smartphone and a laptop, demonstrating its power bank functionality.

Usage Scenarios

The portable design and multiple features make this fan suitable for various environments:

- **Outdoor Activities:** Ideal for camping, picnics, hiking, fishing, and beach trips.
- **Indoor Use:** Perfect for home, office, or garage use, especially during power outages.



Image: Collage showing the VOSFEEL F6 Camping Fan being used in different settings: camping, beach, jobsite, and office, highlighting its versatility.

Official Product Videos

Watch these official videos for a visual guide on product features and usage:

Camping fan review and walkthrough

Your browser does not support the video tag.

Video Description: A detailed review and walkthrough of the VOSFEEL F6 Camping Fan, demonstrating its features and functionality in a home setting.

Outdoor Must Have!

Your browser does not support the video tag.

Video Description: This video showcases the VOSFEEL F6 Camping Fan as an essential outdoor item, highlighting its portability

and utility in an outdoor environment.

MAINTENANCE AND CARE

Proper maintenance ensures the longevity and performance of your fan.

- **Cleaning:** Use a soft, dry cloth to wipe the fan's exterior. Do not use abrasive cleaners or immerse the fan in water.
- **Storage:** Store the fan in a cool, dry place when not in use. Ensure it is fully charged before long-term storage to preserve battery health.
- **Battery Care:** Avoid fully discharging the battery frequently. Recharge when the battery indicator is low.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	Low battery; Power button not pressed correctly.	Charge the fan fully; Ensure the power button is pressed firmly.
Light is not working.	Light function is off; Low battery.	Press the light button to turn on; Charge the fan.
Remote control not working.	Remote battery is dead; Obstruction between remote and fan.	Replace remote battery; Ensure clear line of sight.
Cannot charge external devices.	Low fan battery; Incorrect cable or device.	Charge the fan; Use appropriate charging cable for your device.

SPECIFICATIONS

Feature	Detail
Brand	VOSFEEL
Model Name	F6
Color	Black and Orange
Power Source	Battery Powered

Feature	Detail
Battery Capacity	20000mAh Lithium Ion (included)
Product Dimensions	8.9"D x 11.4"W x 4.6"H
Item Weight	3.27 pounds
Noise Level	29 dB
Number of Fan Speeds	4
Light Type	LED (3 brightness settings)
Control Method	Remote, Touch (Push Button)
Connector Type	USB Type C (Input/Output), USB Type A (Output)
Wattage	15 watts
Oscillation	45°, 90°
Timer Settings	1H, 2H, 4H, 8H
Indoor/Outdoor Usage	Outdoor, Indoor

WARRANTY AND SUPPORT

VOSFEEL products are designed for reliability and performance. For warranty information, technical support, or customer service inquiries, please refer to the contact information provided on the product packaging or visit the official VOSFEEL website.

Please retain your proof of purchase for warranty claims.