

## Prolink DL-7202-D

# Prolink DL-7202 4G LTE Mobile Wi-Fi User Manual

Model: DL-7202-D | Brand: Prolink

## PRODUCT OVERVIEW

The Prolink DL-7202 is a portable mobile Wi-Fi device designed to provide fast, uninterrupted wireless connectivity. It supports speeds of up to 300Mbps, making it suitable for use while on the move. Equipped with a durable 3000mAh battery, it offers continuous power for up to 12 hours. The device also features app support for the latest version (P/N: LTE-DL7202-D, S/N starting from "230801").

## Key Features

- **Fast Connection Anywhere:** Enjoy high-speed connectivity of up to 150Mbps with a secure LTE connection.
- **Long-lasting Battery Life:** 3000mAh battery capacity provides up to 12 hours of connectivity.
- **Multi-user Access:** Allows up to 16 users to access the Internet simultaneously.
- **USB2.0 Type-C Port:** Features a modern USB Type-C port for charging and connectivity.
- **Smooth Wireless Network:** Provides high-speed up to 300Mbps connectivity via Wi-Fi hotspot.
- **mProMifi App Support:** Available for compatible versions for enhanced control and configuration.

## 4G LTE Mobile Wi-Fi

DL-7202



Continuous  
Wi-Fi access



Up to 185  
Countries



Multi-User

MyRepublic

Singtel

SIMBA eight



Compatible with:



mProMifi



**Singapore  
IMDA Approved  
DB02133**

\*App support is available for latest version,  
P/N: LTE-DL7202-D, S/N starting from "230801"

This infographic highlights the Prolink DL-7202's continuous Wi-Fi access for up to 12 hours, support for up to 185 countries, multi-user capability for 16 users, and compatibility with the mProMifi app.




Product quick facts detailing Wi-Fi hotspot capabilities, multi-device sharing, automatic APN, 4G network, travel-friendly design, battery life, and compact size.

## SETUP GUIDE

Follow these steps to set up your Prolink DL-7202 Mobile Wi-Fi device:


1. **Insert SIM Card:** Open the back cover of the device. Insert a Nano SIM card into the designated SIM card slot. Ensure it is correctly oriented.
2. **Insert Battery:** Place the detachable battery into its compartment.
3. **Power On:** Close the back cover. Press and hold the power button until the device powers on and the display lights up.
4. **Automatic APN:** The device features Auto APN, which automatically determines and selects the correct APN info based on the inserted SIM card, supporting up to 185 countries worldwide.
5. **Connect Devices:** Once powered on, the device will create a Wi-Fi hotspot. Look for the Wi-Fi network name (SSID) and password displayed on the device's screen or on a label inside the battery compartment. Connect your Wi-Fi enabled devices (smartphones, tablets, laptops) to this network.



## SIMPLE CONNECTIVITY IN SECONDS

Insert a data SIM card first, then power on device.  
Your high speed hotspot will be ready in seconds

An exploded view of the Prolink DL-7202 showing the Nano SIM card slot, microSD card slot, detachable battery, and USB Type-C charging port for simple connectivity.



## AUTO APN FOR PLUG & PLAY

Support up to 185 countries worldwide

Illustration of the Auto APN feature, demonstrating how a Nano SIM card enables plug-and-play internet access for devices like laptops, supporting global connectivity.

### OPERATION

Operating your Prolink DL-7202 Mobile Wi-Fi device is straightforward:

- **Wi-Fi Hotspot:** The device functions as a portable Wi-Fi hotspot, allowing up to 16 devices to connect simultaneously. The Wi-Fi network name (SSID) and password are displayed on the device's screen.
- **Web-GUI Functionality:** For advanced settings and management, access the device's web-based Graphical User Interface (Web-GUI). This allows for network configuration, file sharing from an inserted microSD card (not included), and sending/receiving SMS messages. Refer to the device's display for the IP address to access the Web-GUI.
- **Battery Life:** The 3000mAh battery provides up to 12 hours of continuous usage. Monitor the battery level on the device's display.
- **App Support:** For compatible models (P/N: LTE-DL7202-D, S/N starting from "230801"), download the mProMifi app from the App Store or Google Play for convenient management and monitoring of your device.



Share Wi-Fi Connection With A Secured Password



## WI-FI SHARING ACROSS 16 DEVICES

Share Internet connection amongst tablets, laptops, and mobile phones simultaneously up to 300Mbps

Illustration of Wi-Fi sharing, showing multiple users connecting their devices like laptops and smartphones to the Prolink DL-7202 hotspot.



File sharing  
from SD card



Send and  
receive SMS



Network and  
Wi-Fi configuration



## WEB-GUI FUNCTIONALITY

Support web-based configuration

Visual representation of the Web-GUI functionality, including file sharing from an SD card, SMS capabilities, and network configuration options.



11AM

11PM

prolink

3000mAh

Battery life may vary due to different user usage and environment.

**ALL DAY SHAREABLE 4G ACCESS  
UP TO 12 HOURS**

This image demonstrates the Prolink DL-7202's extended battery life, supporting up to 12 hours of continuous use for all-day connectivity.

## MAINTENANCE

To ensure the longevity and optimal performance of your Prolink DL-7202 Mobile Wi-Fi device, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the device. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store the device in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. If storing for extended periods, charge the battery to about 50% and recharge every few months.
- **Avoid Drops and Impacts:** Handle the device with care to prevent physical damage.

## TROUBLESHOOTING



If you encounter issues with your Prolink DL-7202, try the following troubleshooting steps:

- **No Network Signal:**

- Ensure the SIM card is correctly inserted.
- Check if your SIM card has an active data plan.
- Move to an area with better network coverage.
- Restart the device.

- **Cannot Connect to Wi-Fi:**

- Verify the Wi-Fi password (SSID and password are on the device screen or under the battery).
- Ensure Wi-Fi is enabled on your connecting device.
- Restart both the DL-7202 and your connecting device.
- Check if the maximum number of connected users (16) has been reached.

- **Slow Internet Speed:**

- Check network signal strength on the device display.
- Reduce the number of connected devices.
- Ensure no background applications are consuming excessive bandwidth on connected devices.

- **Device Not Powering On:**

- Ensure the battery is charged. Connect the device to a power source using the provided USB Type-C cable.
- Check if the battery is properly inserted.

## TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	Prolink
Model	DL-7202-D
Model Name	DL-7202 Mobile Wi-Fi
Compatible Devices	Gaming Console, Wi-Fi devices, Tablet, Smartphone
Special Features	Support 185 countries SIM card, LCD screen
Mounting Hardware	Router, battery pack, charging cable
Number of items	2
Voltage	5 Volts
Data Transfer Rate	300 Megabits Per Second
Wireless Type	802.11n, 802.11b, 802.11g
Number of Ports	1

Connector Type	Wi-Fi, LTE
Product Dimensions	1.6 x 1.3 x 9.3 cm; 100 g
Item model number	DL-7202-D
Colour	Black
Frequency band class	Dual-Band
Wireless communication standard	802.11n, 802.11b, 802.11g
Recommended product uses	Travel, Outdoor, Small Gathering
Included components	Router, battery pack, charging cable



## COMPACT SIZE

The Prolink DL-7202's compact size, with dimensions of 93 x 60 x 13mm and an approximate weight of 100g, making it highly portable.

### WARRANTY INFORMATION

The Prolink DL-7202 Mobile Wi-Fi device comes with a **3-year warranty**. For specific details regarding warranty claims and service, please refer to the official Prolink warranty policy or contact Prolink customer support. Additionally, the product is subject to a **15-day refund/replacement return policy** from the date of purchase, as per Amazon's terms.

## SUPPORT

For further assistance and support:

- **mProMifi App:** Download the official mProMifi app for compatible devices for easy management and configuration.
- **Online Resources:** Visit the [Prolink Official Store on Amazon](#) for product information and updates.
- **Customer Service:** Contact Prolink customer service for technical support or warranty inquiries.