

SMARTKLIK ddc06

SMARTKLIK ddc06 Digital Camera User Manual

FHD 4K 44MP with 64GB SD Card, 16X Digital Zoom

1. INTRODUCTION

Welcome to the SMARTKLIK ddc06 Digital Camera user manual. This guide provides essential information for setting up, operating, and maintaining your new camera. Please read through these instructions carefully to ensure optimal performance and longevity of your device. The SMARTKLIK ddc06 is designed for ease of use, capturing high-quality 44MP photos and 4K FHD videos, making it ideal for beginners and enthusiasts alike.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x SMARTKLIK ddc06 Digital Camera
- 1 x 64GB SD Card
- 2 x Rechargeable Batteries (1200mAh)
- 1 x Type-C USB Cable
- 1 x Camera Bag
- 1 x Cleaning Cloth
- 2 x Lanyards (Wrist and Neck)
- 1 x User Manual (this document)

The best gift is saving every sweet memory with you




Image: All components included in the SMARTKLIK ddc06 Digital Camera package.

3. SETUP

3.1. Battery and SD Card Installation

To power your camera and store your photos/videos, you need to install the battery and SD card.

1. Locate the battery compartment cover on the bottom of the camera.
2. Slide the cover release latch and open the compartment.
3. Insert the provided 64GB SD card into the SD card slot until it clicks into place. Ensure the metal contacts face the correct direction as indicated by the diagram inside the compartment.
4. Insert a fully charged battery into the battery compartment, matching the orientation shown inside the compartment.
5. Close the battery compartment cover until it latches securely.




Image: Step-by-step guide for inserting the battery and SD card into the camera.

Video: Visual instructions on how to correctly insert the battery and memory card into the SMARTKLIK ddc06 Digital Camera.

3.2. Charging the Battery

Connect the camera to a power source using the provided Type-C USB cable. The charging indicator light will illuminate during charging and turn off when fully charged. It is recommended to fully charge the battery before first use.

4. OPERATING INSTRUCTIONS

4.1. Basic Controls

Familiarize yourself with the main buttons and their functions:




Image: An overview of the SMARTKLIK ddc06 Digital Camera's buttons and their respective functions.

- **Power Button:** Long press to turn the camera on/off.
- **Shutter Button:** Half-press to focus, full-press to capture a photo.
- **W/T (Zoom) Button:** Press 'W' to zoom out, 'T' to zoom in (up to 16X digital zoom).
- **Mode Button:** Switch between Photo, Video, and Playback modes.
- **OK Button:** Confirm selections in menus.
- **Menu/Settings Button:** Access camera settings and options.

- **DISP Button:** Toggle display information on/off.
- **Flash Button (Up):** Cycle through flash modes (Auto, On, Off).
- **Timer Button (Left):** Set self-timer (3s, 5s, 10s).
- **Continuous Shooting Button (Right):** Enable/disable continuous shooting.
- **Delete Button (Down):** Delete selected photos or videos in Playback mode.

4.2. Photo Mode

In Photo Mode, you can capture still images. Use the Menu button to adjust settings like photo resolution (up to 44MP), white balance, and exposure compensation.




Image: Demonstrates the camera's ability to capture clear 44MP photos and apply various filters.

4.3. Video Mode

Switch to Video Mode to record 4K FHD videos. The camera supports a pause function during recording, allowing for seamless video creation.



Video: Demonstrates the 4K video recording capabilities and pause function of the SMARTKLIK ddc06 Digital Camera.

4.4. Special Features

- **16X Digital Zoom:** Use the W/T button to zoom in on distant subjects.
- **Self-Timer:** Set a delay of 3, 5, or 10 seconds before a photo is taken, perfect for group shots.
- **Flashlight:** The built-in flash bulbs provide brighter illumination for clear photos in low-light conditions.
- **Filters and Scene Modes:** Experiment with various filters and scene modes to add creative effects to your photos.




Image: Visual representation of the camera's 16X digital zoom functionality.

Package Includes

- 1 x 4K digital camera
- 1 x Cleaning cloth
- 1 x 64GB SD card
- 1 x Type-C cable
- 1 x User manual
- 1 x Camera bag
- 2 x Lanyard
- 2 x Rechargeable battery



Image: Displays the self-timer options available on the camera (3, 5, and 10 seconds).



Image: Illustrates the different color filters and white balance settings to enhance photos.

4.5. Webcam Functionality

The SMARTKLIK ddc06 can be used as a webcam for live streaming or video calls. Connect the camera to your computer using the USB cable and select 'PC Camera' mode from the camera's menu.



Image: The camera can function as a webcam for live streaming or video conferencing when connected to a computer.

5. MAINTENANCE

5.1. Cleaning

Use the provided cleaning cloth to gently wipe the camera lens and screen. Avoid using liquid cleaners or abrasive materials that could damage the surfaces.

5.2. Storage

When not in use, store the camera in its protective bag in a cool, dry place away from direct sunlight and extreme temperatures. Remove the battery if storing for extended periods.

6. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Blurry Pictures:** Ensure the camera is set to its highest resolution (44M) in settings. Half-press the shutter button to allow the camera to autofocus before fully pressing to capture the image.
- **Camera Not Turning On/Working Only When Plugged In:** Check that the battery is correctly installed and making proper contact. The battery might be depleted; try replacing it with a fully charged one.

Anytime Anywhere To Capture A Different Beauty

7 Kinds of Exposure Compensation



5 Filters & 5 White Balances




Image: Common troubleshooting steps for image clarity and power-related problems.

7. SPECIFICATIONS

Brand	SMARTKLIK
Model Name	ddc06
Effective Still Resolution	44 MP
Video Resolution	2160p (4K FHD)
Digital Zoom	16 x
Screen Size	2.8 Inches
Memory Storage Capacity	64 GB (SD Card Included)
Connectivity Technology	HDMI, USB, Wi-Fi
Special Features	Autofocus, Self-timer, Continuous Shooting, Filters, Webcam Function, Built-in Microphone
Item Weight	3.68 Ounces

8. WARRANTY AND SUPPORT

8.1. Warranty Information

The SMARTKLIK ddc06 Digital Camera comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or external causes.

8.2. Customer Support

For technical assistance, warranty claims, or any questions regarding your SMARTKLIK ddc06 Digital Camera, please refer to the contact information provided on the official SMARTKLIK website or your purchase documentation. Please have your model number (ddc06) and proof of purchase ready when contacting support.