

Kawai CA701

Kawai CA701 Digital Concert Piano User Manual

Model: CA701 | Brand: Kawai

INTRODUCTION

The Kawai CA701 Digital Concert Piano is designed to replicate the experience of playing a grand piano. This manual provides essential information for setting up, operating, and maintaining your instrument to ensure optimal performance and longevity.



Image: The Kawai CA701 Digital Concert Piano in Satin Black, showcasing its elegant upright cabinet and 88-key keyboard.

KEY FEATURES

- 88-key Digital Piano with Grade-weighted Hammer-action Wooden Keys
- Built-in Speakers for rich audio output
- Grand Feel Pedal System for realistic pedal response
- 256-note Polyphony for complex musical passages
- Onboard Effects to enhance sound customization

SETUP

Careful setup ensures the best performance and safety of your Kawai CA701. Due to its weight, it is recommended to have assistance during assembly and placement.

Unpacking and Placement

- The piano weighs approximately 242 pounds. Ensure adequate support and assistance when moving.
- Product dimensions are 62 x 29 x 28 inches. Plan your space accordingly.
- Place the piano on a stable, level surface away from direct sunlight, heat sources, and excessive humidity.

Connectivity

- **Power:** Connect the provided power adapter to the DC input and a suitable power outlet.
- **Headphones:** Utilize the 3.5mm Jack for private practice.
- **External Devices:** The piano supports USB and MIDI connectivity for integration with computers or other musical equipment.

OPERATING INSTRUCTIONS

The Kawai CA701 offers a range of functions to enhance your playing experience.

Sound Selection

Explore the various piano samples and instrument voices available. The Progressive Harmonic Imaging XL sound engine recreates the sounds of renowned Shigeru Kawai SK-EX and Kawai EX concert grand pianos, K60 upright piano, and other premium instruments.

Customizing Sounds with Virtual Piano Artisan

The Virtual Piano Artisan feature allows for detailed customization of piano sounds, including voicing, touch curve, damper noise, and string resonance. This enables users to fine-tune the instrument to their personal preferences.

Saving Custom Sounds

After customizing a sound, you can save your personalized settings for future use. This allows for quick recall of your preferred instrument configurations.

Recording Modes

The CA701 supports various recording modes, allowing you to capture your performances directly onto a USB stick or via line-out to an external audio interface for computer recording.

MAINTENANCE

Regular care will preserve the appearance and functionality of your digital piano.

- **Cleaning:** Use a soft, dry cloth to wipe down the cabinet and keys. Avoid abrasive cleaners or solvents.
- **Key Care:** Keep the keys free from dust and debris. If necessary, gently wipe with a slightly damp cloth and dry immediately.
- **Environment:** Maintain a stable room temperature and humidity level to prevent damage to the wooden components.

TROUBLESHOOTING

This section addresses common issues you might encounter with your Kawai CA701.

Problem	Possible Cause	Solution
No Sound	Volume too low; headphones connected; power issue.	Increase master volume; disconnect headphones; check power connections.
Keys Not Responding	Dust or debris under keys; internal malfunction.	Gently clean around keys; if issue persists, contact support.

Problem	Possible Cause	Solution
Distorted Sound	Volume too high; faulty cables; speaker issue.	Lower volume; check and replace cables; contact support if speakers are faulty.

SPECIFICATIONS

Feature	Detail
Model Name	CA701
Number of Keys	88
Key Action	Grade-weighted Hammer-action Wooden Keys
Polyphony	256-note
Connectivity	USB, MIDI, 3.5mm Jack
Power Source	Corded Electric
Item Weight	242 Pounds
Product Dimensions	62 x 29 x 28 inches
Body Material	Wood







WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official Kawai website or the documentation included with your purchase. Keep your proof of purchase for warranty claims. You can also visit the [product page on Amazon](#) for additional resources and customer service contacts.



© 2024 Kawai. All rights reserved.

Related Documents - CA701

	<p>Kawai CA901/CA701 System Software Update Guide</p> <p>Instructions for updating the system software of the Kawai CA901 and CA701 digital pianos, including requirements, procedures, and changelog.</p>
	<p>Kawai CA701 Digital Piano Operation Manual: Features, Functions, and Settings</p> <p>Explore the Kawai CA701 digital piano with this comprehensive operation manual. Learn about its controls, playing modes (Dual, Split, Four Hands), metronome, recorder, lesson functions, sound settings, Virtual Technician, and Bluetooth connectivity for an enhanced musical experience.</p>
	<p>Kawai CA901/CA701 Digital Piano Software Update Guide</p> <p>Instructions for updating the system software of Kawai CA901 and CA701 digital pianos, covering update requirements, step-by-step procedures, and a changelog of software versions.</p>
	<p>Kawai CA901/CA701 Digital Piano Owner's Manual</p> <p>Comprehensive owner's manual for the Kawai CA901 and CA701 digital pianos, covering important safety instructions, preparation, basic operation, adjustments, settings, and troubleshooting.</p>
	<p>Kawai CA/NV LCD Touch Panel Software Update Instructions</p> <p>Detailed instructions for updating the LCD touch panel software on Kawai CA and NV series digital and hybrid pianos, including requirements, step-by-step procedures, and version changelogs.</p>
	<p>KAWAI CP119 Quick Start Guide: Learn Your Digital Piano</p> <p>Get started with your KAWAI CP119 Concert Performer digital piano. This Quick Start Guide provides essential instructions on sounds, styles, recording, and USB usage for new users.</p>

