



[Manuals.plus](#) /

› [Tastyle](#) /

› Tastyle Mini Single Serve Coffee Maker User Manual (Model: Tastyle Mini)

## Tastyle Tastyle Mini

# Tastyle Mini Single Serve Coffee Maker User Manual

Model: Tastyle Mini

## 1. INTRODUCTION

---

Thank you for choosing the Tastyle Mini Single Serve Coffee Maker. This appliance is designed for convenient brewing of both hot and iced coffee using K-cups or ground coffee. Please read this manual thoroughly before use to ensure safe and optimal operation.

# Over Iced & Hot Brew in One

Create your own iced coffee bliss  
with recipe book included



*Image 1.1: The Tastyle Mini Single Serve Coffee Maker, showcasing its ability to prepare both hot and iced coffee beverages.*

## 2. IMPORTANT SAFEGUARDS

---

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.

- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

### 3. PRODUCT OVERVIEW

---

Familiarize yourself with the components of your Tastyle Mini Coffee Maker.



*Image 3.1: Overview of the coffee maker's features, including rapid brewing, optimal temperature, water shortage reminder, descaling reminder, and one-button operation.*

### 4. SETUP

---

#### 4.1 Initial Use

1. Unpack the coffee maker and all accessories.
2. Wipe the exterior with a damp cloth.
3. Wash the removable drip tray, K-cup holder, and reusable filter with warm, soapy water. Rinse thoroughly.
4. Perform a cleansing brew cycle: Fill the water reservoir to the MAX line (14 oz) with fresh water. Place an empty mug on the drip tray. Close the lid and press the 'Hot Brew' button to run a cycle without coffee. Discard the water. Repeat this process once more.

#### 4.2 Filling the Water Reservoir

1. Open the water reservoir lid.
2. Fill the reservoir with fresh, cold water up to your desired brew size (6, 8, 10, 12, or 14 oz) indicated by the visible water window. Do not exceed the MAX 14 oz line.
3. Close the water reservoir lid securely.

# Easy Water Filling



Visible water window  
marked 6,8,10,12,14oz



Large opening of  
water tank



*Image 4.1: The water reservoir features clear markings for 6, 8, 10, 12, and 14 oz, and a large opening for easy filling.*

## 5. OPERATION

---

### 5.1 Brewing Hot Coffee (K-Cup)

1. Ensure the water reservoir is filled to your desired level (6-14 oz).
2. Lift the handle to open the K-cup chamber.
3. Insert a K-cup pod into the K-cup holder.
4. Close the handle firmly until it clicks.
5. Place a mug (up to 6 inches tall) on the drip tray.

6. Press the 'Hot Brew' button. The indicator light will illuminate, and brewing will begin.
7. Once brewing is complete, the light will turn off. Carefully remove your mug.



*Image 5.1: Inserting a K-cup pod into the designated holder for brewing.*

## **5.2 Brewing Hot Coffee (Ground Coffee)**

1. Ensure the water reservoir is filled to your desired level (6-14 oz).
2. Lift the handle to open the K-cup chamber.
3. Place the reusable filter into the K-cup holder.
4. Add your desired amount of ground coffee to the reusable filter. Do not overfill.
5. Close the handle firmly until it clicks.
6. Place a mug (up to 6 inches tall) on the drip tray.
7. Press the 'Hot Brew' button. The indicator light will illuminate, and brewing will begin.
8. Once brewing is complete, the light will turn off. Carefully remove your mug.

# Deep Extraction Tech



Use a K-pod:



Iced Coffee: 6~8oz water  
(water: ice=1:1)



Hot Coffee: 10~12oz water

Brew Coffee grounds:

- Less grounds, richer coffee



Image 5.2: The coffee maker supports both K-pods and ground coffee, utilizing deep extraction technology for rich flavor.

## 5.3 Brewing Iced Coffee

1. Fill your serving cup with ice.
2. Fill the water reservoir with fresh, cold water according to the recommended iced coffee ratios (e.g., 6-8 oz water for 6-8 oz ice).
3. Insert a K-cup pod or ground coffee into the reusable filter.
4. Place the ice-filled cup on the drip tray.
5. Press the 'Over Ice' button. The indicator light will illuminate, and brewing will begin.
6. Once brewing is complete, the light will turn off. Carefully remove your iced coffee.




Image 5.3: The coffee maker brewing iced coffee directly into a glass filled with ice.

## 5.4 Brew Size Selection

The coffee maker allows you to select brew sizes from 6 oz to 14 oz. The water reservoir has clear markings to guide your filling. For optimal flavor, especially with iced coffee, follow recommended water-to-ice ratios.



Image 5.4: The coffee maker is designed for both hot and iced coffee brewing, offering versatility.

## 5.5 Video Demonstration

Your browser does not support the video tag.

Video 5.1: This official seller video demonstrates the compact size, hot and cold brewing capabilities, and K-cup/ground coffee compatibility of the Tastyle Mini Single Serve Coffee Maker.

# 6. MAINTENANCE

---

## 6.1 Descaling

The coffee maker features an intelligent descaling notification. When the descaler indicator emits a blinking red light, it's time to descale the unit.

1. Fill the water container with 14 oz of descaling solution (e.g., white vinegar or a commercial descaling agent).
2. Place a large mug on the drip tray.
3. Press both the 'Hot Brew' and 'Over Ice' buttons simultaneously for 2 seconds to activate the automatic

cleaning cycle.

4. The machine will run a descaling cycle. Discard the solution.
5. Run two full cycles with fresh water to rinse the machine thoroughly.



Image 6.1: The descaling indicator light and the two buttons used to initiate the self-cleaning cycle.

## 6.2 General Cleaning

- Always unplug the appliance before cleaning.
- Wipe the exterior with a damp cloth. Do not immerse the coffee maker in water.
- The K-cup holder and reusable filter are removable for easy cleaning. Wash with warm, soapy water and rinse thoroughly.
- The drip tray and drip tray plate can be removed and washed with warm, soapy water.

## 7. TROUBLESHOOTING

---

- **Coffee not brewing:** Ensure the water reservoir is filled, the K-cup or reusable filter is correctly inserted, and the lid is firmly closed. Check if the power cord is securely plugged in.
- **Weak coffee:** Use a bolder coffee blend or increase the amount of ground coffee in the reusable filter. Ensure the correct brew size is selected for your preference.
- **Coffee is not hot enough:** Ensure the 'Hot Brew' setting is selected. Pre-heat your mug with hot water if desired.
- **Descaling indicator blinking:** Follow the descaling instructions in Section 6.1.
- **Water leakage:** Ensure the K-cup or reusable filter is properly seated and the lid is fully closed. Check the water reservoir for any cracks or improper seating.
- **Water shortage reminder:** The machine has a smart water shortage detection system. If the water level is too low, the machine may not start or may stop brewing. Refill the water reservoir.
- **Overheat protection:** The coffee maker is equipped with an anti-overheat system to prevent damage. If the machine overheats, it will automatically shut off. Allow it to cool down before attempting to brew again.

## 8. SPECIFICATIONS

---

Feature	Specification
Brand	Tastyle
Model Name	Tastyle Mini
Capacity	13 ounces (max brew size 14 oz)
Color	Black
Product Dimensions	8.2"D x 4.2"W x 10.3"H
Special Feature	Self Cleaning
Coffee Maker Type	Drip Coffee Machine
Specific Uses	Cappuccino, Espresso, Iced Coffee
Operation Mode	Fully Automatic
Wattage	800 watts
Voltage	120 Volts
Filter Type	Reusable
Material	Plastic
Included Components	Recipe Book

## 9. WARRANTY AND SUPPORT

---

The Tastyle Mini Single Serve Coffee Maker comes with a **One Year Warranty**. For support or warranty claims, please refer to the contact information provided on the product or scan the QR code on the device for quick access to support resources.

You can also reach out via:

- Phone: 1-972-467-4438
- Email: [support@mytastyle.com](mailto:support@mytastyle.com)