

[Manuals.plus](#) /

> [Lenovo](#) /

> [Lenovo Bluetooth Silent Mouse \(WL300\) User Manual](#)

Lenovo 4Y51N41727

Lenovo Bluetooth Silent Mouse (WL300) User Manual

Model: 4Y51N41727 | Brand: Lenovo

INTRODUCTION

The Lenovo Bluetooth Silent Mouse (WL300) is designed for professionals seeking a quiet, comfortable, and efficient pointing device. It features a sculpted grip and silent buttons to enhance productivity in various environments. This manual provides comprehensive instructions for setup, operation, and maintenance.

KEY FEATURES

- **Sleek and Compact:** Compact and lightweight, ideal for on-the-go professionals, powered by a single AA battery.
- **Uncompromised Quality:** Left and right buttons are engineered to last up to 3 million clicks. The scroll wheel is designed to endure up to 300,000 cycles.
- **Sculpted Grip Bluetooth Mouse:** Experience all-day comfort with a sculpted grip that conforms to your hand's natural contours. Effortlessly pair with Bluetooth 5.0 and Microsoft Swift Pair technology.
- **Smooth Navigation:** Features 5 buttons (left click, right click, scroll click, forward, and backward) and an anti-slip scroll wheel. The precise optical sensor offers 3-level DPI adjustment (800, 1200, and 1600 DPI).
- **Silent Efficiency:** Designed to work seamlessly on different surfaces such as wood, leather, fabric, paper, and resin. Offers silent left, right, and scroll wheel buttons for quiet operation.

PACKAGE CONTENTS

- Lenovo Bluetooth Silent Mouse (WL300)
- 1 AA Battery

Please ensure all components are present before proceeding with setup.

SETUP GUIDE

1. Battery Installation

The Lenovo WL300 mouse requires one AA battery for operation. The battery compartment is located on the underside of the mouse.

Sculpted Grip

Crafted for Comfort and Mobility



Compact
Design



Image: Underside view of the Lenovo WL300 mouse, highlighting the AA battery compartment, on/off switch, and Bluetooth pairing button.

1. Gently remove the top cover of the mouse to access the internal components.

2. Insert one AA battery into the designated compartment, ensuring correct polarity (+/-).
3. Replace the top cover, ensuring it clicks securely into place.

2. Power On

Locate the On/Off switch on the underside of the mouse and slide it to the 'On' position. The optical sensor light will illuminate.

3. Bluetooth Pairing

The WL300 mouse utilizes Bluetooth 5.0 and Microsoft Swift Pair for easy connection to your device.



Image: Step-by-step guide for Bluetooth pairing, showing battery installation, pressing the pairing button, opening computer Bluetooth settings, and selecting "Lenovo WL300".

1. With the mouse powered on, press and hold the Bluetooth pairing button on the underside of the mouse for 3-5 seconds until the indicator light flashes, indicating pairing mode.
2. On your computer or device, open Bluetooth settings.
3. Select "Lenovo WL300" from the list of available devices to complete the pairing process.
4. The mouse can pair with up to two devices simultaneously, allowing for quick switching between them.

OPERATING INSTRUCTIONS

Button Functions

Sculpted Grip

Crafted for Comfort and Mobility



Compact
Design



Image: Detailed diagram of the mouse, labeling the Left Click, Right Click, Scroll Wheel/Click, Forward, Backward buttons, On/Off Switch, AA Battery Compartment, and Bluetooth Pairing Button.

- **Left Click:** Primary selection and activation.

- **Right Click:** Accesses contextual menus.
- **Scroll Wheel:** Scrolls vertically. Pressing it functions as a middle click.
- **Forward Button:** Navigates forward in web browsers or file explorers.
- **Backward Button:** Navigates backward in web browsers or file explorers.
- **DPI Adjustment Button:** Located below the scroll wheel, this button allows you to cycle through three DPI settings (800, 1200, 1600) to adjust cursor sensitivity.

Multi-Surface Compatibility

The WL300 features a precise optical sensor designed to work effectively on a variety of surfaces, including wood, leather, fabric, paper, and resin, ensuring consistent performance in diverse work environments.

Works With Multi-Surfaces


Resin



Leather



Fabric



Wood



Paper



Image: Visual representation of the mouse's compatibility with multiple surfaces, including resin, leather, fabric, wood, and paper.

MAINTENANCE

To ensure the longevity and optimal performance of your Lenovo Bluetooth Silent Mouse, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the mouse surface. For stubborn dirt, slightly dampen the cloth with water or

a mild, non-abrasive cleaner. Avoid excessive moisture.

- **Sensor Care:** Keep the optical sensor on the underside of the mouse clean and free from dust or debris to maintain tracking accuracy.
- **Battery Replacement:** Replace the AA battery when the mouse's performance degrades or the indicator light signals low power.
- **Storage:** When not in use for extended periods, turn off the mouse to conserve battery life. Store it in a cool, dry place.

TROUBLESHOOTING

If you encounter issues with your Lenovo Bluetooth Silent Mouse, refer to the following common solutions:

Problem	Possible Cause	Solution
Mouse not responding	Low battery; Mouse is off; Not paired; Out of range.	Replace AA battery; Turn on mouse; Re-pair via Bluetooth settings; Move mouse closer to device.
Erratic cursor movement	Dirty optical sensor; Unsuitable surface.	Clean the optical sensor; Use on a clean, uniform surface (e.g., mouse pad).
Cannot pair via Bluetooth	Mouse not in pairing mode; Bluetooth on device is off; Interference.	Press and hold pairing button; Ensure Bluetooth is enabled on your device; Move away from other wireless devices.
Buttons or scroll wheel not working	Software issue; Physical damage.	Restart your computer; Check for driver updates; If physically damaged, contact support.

SPECIFICATIONS

Feature	Detail
Brand	Lenovo
Model Number	4Y51N41727 (WL300 Grey)
Connectivity Technology	Bluetooth 5.0
Movement Detection Technology	Optical
DPI Settings	800, 1200, 1600
Number of Buttons	5 (Left, Right, Scroll Click, Forward, Backward)
Battery Type	1 x AA Battery
Average Battery Life	Up to 6 months
Item Weight	4.6 ounces
Product Dimensions (LxWxH)	4.21 x 2.48 x 0.1 inches
Operating System Compatibility	Windows (and generally compatible with other Bluetooth-enabled OS)

WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries regarding your Lenovo Bluetooth Silent Mouse (WL300), please visit the official Lenovo support website or refer to the warranty card included with your product. You can also visit the [Lenovo Store on Amazon](#) for additional product information and resources.