

[manuals.plus](#) /

› [PocBuds](#) /

› [PocBuds Bluetooth Headphones Wireless Earbuds User Manual](#)

**PocBuds PocBuds**

# PocBuds Bluetooth Headphones Wireless Earbuds User Manual

Model: PocBuds

Brand: PocBuds

## INTRODUCTION

Thank you for choosing PocBuds Bluetooth Headphones Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your new earbuds. Designed for comfort and performance, these earbuds feature an 80-hour playtime with the charging case, Hi-Fi sound, IPX7 waterproof rating, and a secure over-ear earhook design, making them ideal for sports and daily use.



Image: PocBuds Bluetooth Headphones Wireless Earbuds in Black and Mint Green.

## WHAT'S IN THE BOX

Please check the contents of your package to ensure all items are present:

- Earbuds (Left and Right)
- Eartips (Multiple Sizes)
- Charging Case
- User Manual
- Type-C Charging Cable

Note: A power adapter is not included.

# Dual LED Battery Display

Remaining Power of  
Charging Case



Charging Status  
of Earbud



Image: Package Contents of PocBuds Earbuds.

## SETUP

### Charging the Earbuds and Case

The PocBuds earbuds and charging case are designed for extended use. The charging case features a dual LED digital display to show the remaining power of the case and the charging status of each earbud.

- **Earbuds:** Place the earbuds into the charging case. They will begin charging automatically. Each earbud provides up to 8 hours of listening time on a single charge.

- **Charging Case:** The case can be charged via the included Type-C cable or wirelessly using a Qi-certified charging pad (not included). A full charge of the case provides multiple recharges for the earbuds, extending total playtime to up to 80 hours.

## 80hrs Long Battery Life

80  
Hrs  
with charging case



8  
Hrs  
single charge



Image: Dual LED Battery Display on the Charging Case.

# Dual LED Battery Display

Remaining Power  
of Charging Case



Charging Status  
of Earbud



Image: 80 Hours Long Battery Life Illustration.



Image: Wireless Charging Feature.

## Pairing with Your Device

The earbuds feature automatic power-on and connection for seamless pairing.

1. Open the charging case. The earbuds will automatically power on.
2. On your device (smartphone, tablet, laptop, etc.), enable Bluetooth.
3. Search for available Bluetooth devices and select "PocBuds" (or similar model name if specified by your device).
4. Once connected, you will hear an audio prompt, and the earbuds will be ready for use.

They are compatible with most Bluetooth-enabled devices, including smartphones, TVs, computers, laptops, and smartwatches.

# 80hrs Long Battery Life



Image: One-Step Pairing Process.

## OPERATING INSTRUCTIONS

### Wearing the Earbuds

The PocBuds earbuds are designed with flexible and soft ear hooks to ensure a secure and comfortable fit, especially during physical activity. Rotate the earbud to find the perfect spot for a secure and comfortable fit that won't budge.



Image: Proper Wearing of Earbuds.

## One-Button Control

Manage your music, calls, and voice assistant effortlessly with the multi-function button on each earbud.

Action	Function
Long Press (L/R)	Power On/Off
Press twice (L/R)	Next Track / Previous Track
Press once (L/R)	Play/Pause Music / Answer/End Call

Action	Function
Press thrice (L/R)	Activate Voice Assistant
Press and hold for 2 seconds (L/R)	Reject Call



Image: Earbud Control Functions.

## Multi-Using Mode

The earbuds support both binaural and mono modes:

- **Binaural Mode:** Use both earbuds for stereo surround sound, ideal for immersive music listening.
- **Mono Mode:** Use either the left or right earbud independently, allowing you to stay aware of your surroundings while enjoying audio.

## MAINTENANCE

### Cleaning and Care

To ensure the longevity and optimal performance of your earbuds:

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water if necessary, ensuring they are completely dry before reattaching.
- Avoid using abrasive cleaners, solvents, or harsh chemicals.

### Water Resistance (IPX7)

The earbuds are IPX7 waterproof, meaning they can withstand submersion in up to 1 meter of water for 30 minutes. This makes them resistant to sweat and rain, but they are not designed for swimming or prolonged water immersion.

- Ensure the earbuds are dry before placing them back into the charging case to prevent damage.
- Do not charge the earbuds or case if they are wet.



Image: IPX7 Sweat-resistant Feature.

## Storage

When not in use, store the earbuds in their charging case to protect them from dust and damage.

## TROUBLESHOOTING

If you encounter any issues with your PocBuds earbuds, please refer to the following common solutions:

- **Earbuds not pairing:**

- Ensure both earbuds are charged.
- Turn off Bluetooth on your device, then turn it back on.
- Forget the device in your Bluetooth settings and try pairing again.
- Place both earbuds back into the charging case, close the lid, wait a few seconds, then open it again to reset.

- **Only one earbud working:**

- Ensure both earbuds are charged.
- Place both earbuds back into the charging case, close the lid, and then take them out simultaneously.
- Check if the earbuds are in mono mode.

- **No sound:**

- Check the volume level on both your device and the earbuds.
- Ensure the earbuds are properly connected to your device.
- Try playing audio from a different application or source.

- **Charging issues:**

- Ensure the charging cable is securely connected to both the case and the power source.
- Check if the charging contacts on the earbuds and inside the case are clean and free of debris.
- If using wireless charging, ensure the case is correctly positioned on the charging pad.

If the issue persists, please contact customer support.

## SPECIFICATIONS

Feature	Detail
Model Name	PocBuds
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Bluetooth Range	30 Feet
Playtime (Single Charge)	8 Hours
Total Playtime (with Charging Case)	80 Hours
Water Resistance Level	IPX7 Waterproof
Audio Driver Size	13 Millimeters
Audio Driver Type	Dynamic Driver
Control Type	Media Control (Touch, Voice, Button)
Ear Placement	Over Ear
Form Factor	In Ear

Feature	Detail
Material	Plastic, Silicone
Compatible Devices	Smartphones, TVs, Computers, Laptops, Smartwatches
Included Components	Wireless Charging Case

## WARRANTY AND SUPPORT

PocBuds is committed to providing high-quality products and excellent customer service. Your earbuds come with:

- **Lifetime Warranty:** For peace of mind regarding manufacturing defects.
- **Free Replacement for Lost Earbuds:** Specific terms and conditions may apply; please contact support for details.
- **24 Hours Support:** Dedicated customer support available to assist you with any inquiries or issues.




Image: Warranty and Support Information.

For further assistance, please visit the official PocBuds website or contact their customer support team through the contact information provided in your product packaging or on their official channels.