

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Hatchimals](#) /

› [Hatchimals Alive Mystery Hatch Pufficorn Interactive Toy Instruction Manual](#)

Hatchimals 6069132

Hatchimals Alive Mystery Hatch Pufficorn

INTERACTIVE TOY INSTRUCTION MANUAL

Model: 6069132

Introduction

The Hatchimals Alive Mystery Hatch Pufficorn offers an engaging interactive experience. This toy features a unique hatching process involving mist, lights, and over 100 sounds and reactions. This manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your Hatchimals Alive Mystery Hatch Pufficorn.

Safety Information

- Recommended for ages 5 years and up.
- Adult supervision is recommended during play, especially during the hatching process.
- Keep away from water to prevent damage to electronic components.
- Do not attempt to open or modify the toy's internal components.
- Ensure batteries are inserted correctly and dispose of used batteries responsibly.

What's Included

- 1 Hatchimals Alive Mystery Hatch Pufficorn Egg
- 1 Hatchimals Pufficorn character (inside the egg)
- 1 Pair of Hatchi-Wings

- 1 Quick Start Guide
- 1 Instruction Sheet
- 4 AA Batteries (pre-installed)



Image: The Hatchimals Alive Mystery Hatch Pufficorn product box, featuring an egg with eyes peeking out, alongside two hatched Pufficorn characters (one pink, one purple) with rainbow wings.

Setup

1. **Unboxing:** Carefully remove the Hatchimals Alive Mystery Hatch Pufficorn egg from its packaging.
2. **Battery Check:** The toy comes with 4 AA batteries pre-installed. If replacement is needed, locate the battery compartment on the bottom of the egg, open it with a screwdriver, and insert new batteries according to polarity markings.
3. **Attach Hatchi-Wings:** Locate the small heart-shaped wings accessory. Gently insert the Hatchi-Wings into the designated slots at the base of the egg.



Image: The Hatchimals Alive Mystery Hatch Pufficorn egg, showing the base with a separate pink heart-shaped wing accessory, ready for attachment.

Operating Instructions

The Magical Hatching Experience

1. **Nurture the Egg:** Hold and cuddle the egg. Listen for a heartbeat. Tap, lift, and gently rock the egg to encourage your Hatchimal to react inside.
2. **Observe Lights and Sounds:** The egg will rock and light up, and you will hear your Hatchimal making sounds from within. Continue nurturing until the egg glows with rainbow colors.
3. **Mist and Hatch:** Once the egg glows rainbow, magical mist will appear, signaling that your Hatchimal is about to hatch. Your Pufficorn will then sing 'Hatchi-Birthday' as it emerges from the egg.



MAGICAL HATCHING EXPERIENCE MIST, LIGHTS & SOUNDS!

Image: Two young girls excitedly watching a glowing Hatchimals egg emit mist and colorful lights, indicating the hatching process is underway.



NEEDS YOUR LOVE TO HATCH

Image: Two young girls observing a Hatchimals egg as its top shell cracks open, revealing the toy's eyes and head emerging from within.

Interactive Play Modes

Your Hatchimals Pufficorn has over 100 sounds and reactions and can engage in various interactive play modes:

- **Feed:** Gently touch its mouth or nose to 'feed' your Pufficorn.
- **Pet:** Stroke its head or back to elicit happy sounds and reactions.
- **Tickle:** Gently tickle its tummy for playful responses.
- **Teach to Talk:** Speak to your Pufficorn, and it may repeat phrases or make unique sounds.
- **Play Peek-a-Boo:** Cover and uncover its eyes to play peek-a-boo.
- **Flutter Wings & Dance:** Your Pufficorn can flutter its wings and dance to music. Interact with it to discover these movements.



**Feed, Dance, Teach Your
HATCHIMAL TO TALK & MORE!**

Image: A child interacting with a purple Hatchimals Pufficorn, touching its nose. The toy features large, glittery eyes and a glowing heart on its chest.



100+ SOUNDS & REACTIONS

Image: A child interacting with a pink Hatchimals Pufficorn, touching its chest where a heart-shaped light glows. The toy has large, glittery eyes and rainbow wings.

Maintenance

- **Cleaning:** Wipe the toy with a soft, damp cloth. Do not submerge in water.
- **Storage:** Store the Hatchimal in a dry, cool place away from direct sunlight.
- **Battery Care:** Remove batteries if the toy will not be used for an extended period to prevent leakage.

Troubleshooting

- **No Power/No Reaction:** Ensure batteries are correctly installed and not depleted. Replace with fresh AA batteries if necessary.
- **Hatching Issues:** If the egg is not hatching, ensure you are providing consistent interaction

(cuddling, tapping, rocking). The hatching process requires continuous engagement.

- **Mist Not Appearing:** Check if the mist reservoir (if applicable and accessible) is empty or blocked. Refer to the Quick Start Guide for specific instructions on mist functionality.
- **Unexpected Behavior:** Try turning the toy off and on again to reset its functions.

Specifications

Product Dimensions	6.07 x 6.07 x 7.87 inches
Item Weight	2.56 pounds
Item Model Number	6069132
Manufacturer Recommended Age	5 years and up
Batteries	4 AA batteries required (included)
Release Date	October 1, 2024
Manufacturer	Spin Master

Warranty and Support

This product is covered by the Spin Master Care Commitment. For full details regarding warranty, product support, or any inquiries, please refer to the official Spin Master website or contact their customer service directly. Information can typically be found on the product packaging or the included instruction sheet.