

Zebra Technologies 4-Slot Charge-Only Cradle

Zebra 4-Slot Charge-Only Cradle User Manual

MODEL: 4-SLOT CHARGE-ONLY CRADLE

Brand: Zebra Technologies

1. Introduction

This manual provides essential instructions for the safe and efficient use of your Zebra 4-Slot Charge-Only Cradle. Please read this manual thoroughly before operating the device and retain it for future reference.

Package Contents:

- 1 x 4-Slot Charge-Only Cradle
- 1 x Power Supply
- 1 x DC Line Cord
- 1 x AC Line Cord (US)



Image 1.1: The Zebra 4-Slot Charge-Only Cradle shown with its power supply, DC line cord, and AC line cord.

2. Safety Information

Please observe the following safety precautions to prevent injury or damage to the device:

- Use only the power supply and cords provided with the cradle.
- Do not expose the cradle to water or excessive moisture.
- Ensure proper ventilation around the cradle during operation.
- Do not attempt to disassemble or modify the cradle. Refer all servicing to qualified personnel.
- Keep the cradle away from heat sources and direct sunlight.
- Place the cradle on a stable, flat surface to prevent accidental falls.

3. Setup

Follow these steps to set up your 4-Slot Charge-Only Cradle:

1. **Unpack Components:** Carefully remove the 4-Slot Charge-Only Cradle, power supply, DC line cord, and AC line cord from their packaging.
2. **Connect DC Line Cord:** Connect the DC line cord to the power supply. Ensure a secure connection.
3. **Connect AC Line Cord:** Attach the AC line cord (US) to the power supply.
4. **Connect Power Supply to Cradle:** Plug the DC line cord from the power supply into the power input port on the back of the 4-Slot Charge-Only Cradle.
5. **Connect to Power Outlet:** Plug the AC line cord into a standard electrical wall outlet. The cradle is now ready for use.

Ensure all connections are firm before plugging into a power source.

4. Operating the Charge-Only Cradle

The Zebra 4-Slot Charge-Only Cradle is designed to charge up to four compatible Zebra devices simultaneously.

1. **Prepare Device:** Ensure your Zebra device (e.g., Zebra EC5X series or compatible tablets) is powered off or in a charging-ready state.
2. **Insert Device:** Gently slide your device into an available slot on the cradle. Ensure it is seated correctly and makes full contact with the charging connectors.
3. **Verify Charging:** The device should indicate that it is charging (e.g., via an LED indicator on the device itself). The cradle provides power to the device for charging.
4. **Remove Device:** Once charging is complete, carefully lift the device out of the slot.

The cradle is compatible with various Zebra tablets and specifically mentioned models like the Zebra EC5X series.

5. Maintenance

To ensure the longevity and optimal performance of your cradle, follow these maintenance guidelines:

- **Cleaning:** Disconnect the cradle from the power outlet before cleaning. Use a soft, dry, lint-free cloth to wipe the exterior surfaces. Do not use abrasive cleaners, solvents, or spray directly onto the cradle.
- **Storage:** When not in use for extended periods, store the cradle in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the power cords and connectors for any signs of damage. If damage is found, discontinue use and contact support.

6. Troubleshooting

If you encounter issues with your Zebra 4-Slot Charge-Only Cradle, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cradle is not powering on.	Power cords are not properly connected or power outlet is not active.	Ensure the AC and DC line cords are securely connected to the power supply and cradle. Verify the AC line cord is plugged into a working electrical outlet.
Device is not charging when placed in a slot.	Device not properly seated, device is incompatible, or charging contacts are obstructed.	Remove and re-insert the device, ensuring it is fully seated in the slot. Check if the device is compatible with the cradle (e.g., Zebra EC5X or compatible tablets). Inspect charging contacts on both the device and cradle for debris.
Slow charging.	Using a non-standard power supply or multiple devices drawing power.	Ensure you are using the original Zebra power supply. Charging multiple devices simultaneously may result in slightly longer charge times.

If the problem persists after trying these solutions, please contact Zebra Technologies customer support.

7. Specifications

Feature	Detail
Brand	Zebra Technologies
Model	4-Slot Charge-Only Cradle
Package Dimensions	15.1 x 9.6 x 7.2 inches

Feature	Detail
Item Weight	5.19 pounds
Connector Type	AC & DC Line Cord (US)
Compatible Devices	Tablets
Compatible Phone Models	Zebra EC5X
Included Components	1 x 4-Slot Charge-Only Cradle, 1 x Power Supply, 1 x DC Line Cord, 1 x AC Line Cord (US)
Input Voltage	12 Volts (DC)
Total USB Ports	4 (charging slots)
Number of Items	1 (cradle unit)

8. Warranty and Support

For information regarding the product warranty, please refer to the warranty card included with your purchase or visit the official Zebra Technologies website. For technical support, service, or to report issues, please contact Zebra Technologies customer service directly.

Zebra Technologies Official Website: www.zebra.com