

Nintiue F1378

Nintiue Dimmable Floor Lamp F1378 Instruction Manual

Model: F1378

INTRODUCTION

Thank you for choosing the Nintiue Dimmable Floor Lamp F1378. This modern arc floor lamp is designed to provide versatile lighting with its three adjustable heads and dimmable functionality. Please read this manual carefully before assembly and use to ensure safe and optimal performance.

SAFETY INFORMATION

- Ensure the lamp is unplugged before assembly, cleaning, or changing bulbs.
- Do not operate the lamp with a damaged cord or plug.
- This lamp is for indoor use only. Do not expose to water or high humidity.
- Use only E26 base bulbs, not exceeding 60 watts.
- Keep children and pets away from the lamp during assembly and ensure it is placed on a stable, level surface. The weighted base is designed for stability.
- Avoid touching the bulb directly when hot.

PACKAGE CONTENTS

Please check the package to ensure all components are present:

- Lamp Base
- Lamp Pole Sections

- Arc Branches (3)
- Lampshades (3)
- E26 LED Bulbs (3)
- Power Cord with Rotary Dimmer Switch
- Assembly Hardware (screws, washers)
- Instruction Manual



Image: All components of the Nintue Dimmable Floor Lamp laid out before assembly.


ASSEMBLY INSTRUCTIONS

No extra tools or parts are needed for assembly. Follow these steps:

1. **Attach the Base:** Securely screw the lowest pole section into the weighted lamp base.
2. **Assemble the Pole:** Connect the remaining pole sections by screwing them together clockwise until tight. Ensure the power cord runs freely through the pole.
3. **Install Arc Branches:** Attach the three arc branches to the top section of the lamp pole. Ensure they are securely fastened.
4. **Prepare Lampshades:** Carefully unfold each beige linen lampshade. Attach the metal rings to form the cylindrical shape of the shade.
5. **Attach Lampshades:** Screw each lampshade onto the bulb sockets at the end of each arc branch.
6. **Insert Bulbs:** Screw the provided E26 LED bulbs into each socket.
7. **Position the Lamp:** Place the assembled lamp in your desired location. The weighted base ensures stability.



0% – 100% Stepless Dimming Brightness



Rotary Dimmer Switch

Image: A person assembling the main pole sections of the Nintue Dimmable Floor Lamp.



Image: A person attaching a lampshade to one of the arc branches of the Nintue Dimmable Floor Lamp.

OPERATING INSTRUCTIONS

- **Power On/Off:** Plug the lamp into a standard 120V AC outlet. Turn the rotary dimmer switch located on the lamp pole to turn the lamp on or off.
- **Dimming Function:** Rotate the dimmer switch knob clockwise to increase brightness (up to 1000 lumens per bulb) and counter-clockwise to decrease brightness (down to 0%). This allows for customizable lighting from ambient to bright.
- **Adjustable Arc Branches:** The three arc branches are rotatable by 360 degrees. Gently adjust each branch to direct light where needed, expanding the lighting range in your room.



Image: Illustration of the Nintiue Dimmable Floor Lamp's rotary dimmer switch and various brightness levels (10%, 50%, 100%).

MAINTENANCE

- **Cleaning:** Unplug the lamp before cleaning. Wipe the lamp pole and base with a soft, dry cloth. For lampshades, use a lint roller or a soft brush to remove dust. Do not use liquid cleaners or abrasive materials.
- **Bulb Replacement:** Ensure the lamp is unplugged and bulbs are cool before replacing. Unscrew the old E26 bulb and screw in a new E26 base bulb (maximum 60 watts). The included LED bulbs are 2700K warm white and 1000 lumens.

TROUBLESHOOTING

- **Lamp Not Turning On:**
 - Check if the power cord is securely plugged into the wall outlet.
 - Ensure the dimmer switch is turned to the 'on' position and rotated to increase brightness.
 - Verify that the bulbs are screwed in tightly and are not burnt out. Replace if necessary.
- **Flickering Lights:**
 - Ensure bulbs are fully screwed into the sockets.
 - Check if the bulbs are compatible with dimming functionality.
 - Try replacing the bulbs with new ones.

SPECIFICATIONS

Feature	Detail
Model Name	F1378
Brand	Nintiue
Product Dimensions	15"D x 46"W x 80"H
Item Weight	17 Pounds
Material	Metal
Finish Type	Painted
Shade Material	Linen
Shade Color	Beige
Light Source Type	LED
Bulb Base	E26
Number of Light Sources	3
Maximum Compatible Wattage	60 Watts
Brightness	1000 Lumens (per bulb)
Color Temperature	2700 Kelvin (Warm White)
Switch Type	Rotary
Special Feature	3 lights, Arc Floor Lamp, Corded, Dimmable, Multi head
Power Source	AC adapter
Voltage	120 Volts
Assembly Required	Yes

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Nintiue customer service directly. Keep your purchase receipt for any warranty claims.

© 2026 Nintiue. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question