

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Aigostar](#) /

› [Aigostar Ceramic Table Lamp H325mm User Manual](#)

Aigostar H325mm

Aigostar Ceramic Table Lamp H325mm User Manual

Model: H325mm

1. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions carefully before assembly and use.
- Ensure the power supply is disconnected before installation, cleaning, or bulb replacement.
- Use only E14 base bulbs with a maximum wattage of 40W. Exceeding this limit may cause overheating and fire hazard.
- Do not expose the lamp to water or excessive moisture.
- Keep the lamp away from flammable materials.
- Do not attempt to modify or repair the lamp yourself. Contact qualified personnel for service.
- Place the lamp on a stable, flat surface to prevent tipping. The non-slip mat on the base helps secure it.
- This product is for indoor use only.

2. PRODUCT OVERVIEW

The Aigostar Ceramic Table Lamp H325mm features a ceramic owl-shaped body and a fabric shade, designed for ambient lighting in various indoor settings. It uses an E14 bulb (not included) and has an inline switch for easy operation.



Image: Fully assembled Aigostar Ceramic Table Lamp H325mm.

Dimensions:



Image: Product dimensions (Height: 32.5cm, Width: 20cm).

Key Features:

- **Ceramic Body:** Owl-shaped design for a unique aesthetic.
- **Fabric Shade:** Softens light, reduces glare, and protects eyes.
- **E14 Socket:** Compatible with E14 base incandescent, energy-saving, and LED bulbs up to 40W.
- **Inline Switch:** Convenient on/off control on the 1.7-meter cable.
- **Non-slip Base:** Ensures stability on various surfaces.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged upon opening the package.

- 1 x Ceramic Lamp Base (Owl design)
- 1 x Fabric Lampshade
- 1 x Fixing Ring (pre-installed or separate)
- 1 x Power Cable with Inline Switch (1.7 meters)

- Note: E14 bulb is not included.



Image: Unpacked components of the Aigostar Ceramic Table Lamp.

4. SETUP AND INSTALLATION

Follow these steps to assemble your Aigostar Ceramic Table Lamp:

1. **Prepare the Base:** Place the ceramic lamp base on a stable, flat surface.
2. **Remove Fixing Ring:** Locate the lamp holder on top of the ceramic base. Unscrew and remove the fixing ring from the lamp holder.
3. **Position Lampshade:** Carefully place the fabric lampshade onto the lamp holder, ensuring it sits evenly.
4. **Secure Lampshade:** Screw the fixing ring back onto the lamp holder, over the lampshade, and tighten it securely to hold the shade in place. Do not overtighten.
5. **Install Bulb:** Screw an E14 base bulb (max. 40W, not included) into the lamp holder. Ensure the bulb is fully seated.
6. **Connect Power:** Plug the power cord into a suitable electrical outlet.

Easy Installation



1 Take off the fixing ring



2 Put on the lampshade



3 Tighten the fixing ring



4 Install a E14 bulb (bulb is not included)

Image: Step-by-step installation guide for the lamp.

Bulb Recommendation:

This lamp requires an E14 base bulb with a maximum wattage of 40W. The type of bulb (incandescent, energy-saving, or LED) and its color temperature (warm white, cool white) will affect the lighting ambiance. Choose a bulb that suits your preference.



Recommended Bulbs

(Bulbs are not included)



Image: Examples of compatible E14 bulbs.

5. OPERATING INSTRUCTIONS

To operate the Aigostar Ceramic Table Lamp:

- Ensure the lamp is properly assembled and plugged into a functioning power outlet.
- Locate the inline switch on the power cable.
- Press the switch to the "ON" position to illuminate the lamp.
- Press the switch to the "OFF" position to turn off the lamp.



Image: Demonstrating the use of the inline switch.

6. MAINTENANCE

Cleaning:

- Always unplug the lamp from the power outlet before cleaning.
- Wipe the ceramic base with a soft, dry cloth. Do not use abrasive cleaners or harsh chemicals.
- For the fabric shade, gently dust with a soft brush or a lint roller. Avoid using wet cloths, which may stain or damage the fabric.

Bulb Replacement:

- Ensure the lamp is unplugged and the bulb has cooled down completely before attempting to replace it.
- Carefully unscrew the old E14 bulb counter-clockwise.
- Screw in a new E14 bulb (max. 40W) clockwise until it is securely seated.
- Plug the lamp back in and test its operation.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	<ul style="list-style-type: none">◦ Lamp not plugged in.◦ Bulb is loose or burnt out.◦ Power outlet is not functioning.◦ Inline switch is off.	<ul style="list-style-type: none">◦ Ensure the power cord is securely plugged into a live outlet.◦ Tighten or replace the E14 bulb.◦ Test the outlet with another appliance.◦ Ensure the inline switch is in the "ON" position.
Lamp flickers.	<ul style="list-style-type: none">◦ Loose bulb connection.◦ Faulty bulb.	<ul style="list-style-type: none">◦ Tighten the bulb.◦ Replace the bulb with a new one.
Lampshade is wobbly.	<ul style="list-style-type: none">◦ Fixing ring is loose.	<ul style="list-style-type: none">◦ Unplug the lamp, then tighten the fixing ring securely.

8. SPECIFICATIONS

Brand:	Aigostar
Model:	H325mm
Product Dimensions (D x W x H):	7.87" x 7.87" x 12.8" (20cm x 20cm x 32.5cm)
Shade Color:	Beige
Lamp Base Material:	Ceramic
Shade Material:	Fabric
Bulb Base:	E14
Max. Wattage:	40W
Number of Light Sources:	1
Cable Length:	1.7 meters
Item Weight:	1.76 pounds

Batteries Required:	No
ASIN:	B0CSSL8L8

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact Aigostar customer service directly. Keep your purchase receipt for warranty claims.

For further assistance, visit the official Aigostar website or contact their support channels.