

Nedis BTHKB10BK

Nedis SmartLife Key Box Model BTHKB10BK Instruction Manual

1. INTRODUCTION

The Nedis SmartLife Bluetooth Key Box provides secure and convenient key storage for both personal and professional use. This smart key box offers flexibility, allowing for fixed wall installation or portable use with its integrated shackle for door handles. It accommodates house keys, credit cards, and car keys. A key feature is its password management system, enabling remote access via the Nedis Smartlife application. Users can generate one-time or temporary access codes for visitors and monitor access logs. The box can be unlocked remotely via the app, or locally using a permanent access code or a temporary code. Constructed from high-quality, durable SPCC metal, it is resistant to scratches, freezing, and prying. With an IPX5 waterproof rating, it withstands various weather conditions. The key box operates on two AA batteries, providing up to one year of power. For emergencies, a bottom Type-C interface allows for temporary power supply to replace batteries.

2. SAFETY INFORMATION

- Read all instructions carefully before use.
- Do not expose the device to extreme temperatures or direct sunlight for prolonged periods.
- Ensure proper battery installation. Do not mix old and new batteries, or different types of batteries.
- Keep the device away from children to prevent unauthorized access or injury.
- Do not attempt to disassemble or modify the key box. This will void the warranty and may compromise security.
- Always keep your access codes confidential.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Nedis SmartLife Key Box (L1)
- Shackle (for portable use)
- Battery Cover

- Screwdriver
- Quick Start Guide

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your Nedis SmartLife Key Box.



Figure 1: Interior View. This image displays the interior of the Nedis SmartLife Key Box when open. It shows a set of keys hanging on a hook inside the upper compartment and the battery compartment with two AA batteries installed in the lower section.



Figure 2: Front View (Closed). A front view of the closed Nedis SmartLife Key Box, highlighting its numeric keypad for code entry. The box has a sleek black finish.




Figure 3: Front View with Shackle. This image shows the Nedis SmartLife Key Box from the front, featuring its numeric keypad and the integrated shackle (handle) in the upright position, allowing for portable attachment to door handles or railings.

5. INSTALLATION

5.1 Wall Mounting

1. Choose a suitable, secure location for installation.
2. Open the key box and mark the drilling points through the pre-drilled holes on the back panel.
3. Drill holes in the wall at the marked positions.
4. Insert wall plugs (not included) if necessary for your wall type.
5. Secure the key box to the wall using appropriate screws (not included).

5.2 Portable Use (Shackle)

For temporary or portable use, attach the shackle to the top of the key box. The shackle allows the key box to be hung on door handles, fences, or other suitable fixtures. Ensure the shackle is securely locked before leaving the key box unattended.

6. BATTERY INSTALLATION

1. Open the key box.
2. Locate the battery compartment at the bottom interior of the box.
3. Use the provided screwdriver to remove the battery cover.
4. Insert two (2) AA batteries (not included) according to the polarity markings (+/-).
5. Replace the battery cover and secure it with the screw.
6. The key box will emit a sound or light indicator to confirm successful battery installation.

Emergency Power: In case of battery depletion, a Type-C USB port is located at the bottom of the key box. Connect a Type-C cable to an external power source (e.g., power bank) to temporarily power the device and gain access to replace the batteries.

7. APP SETUP AND PAIRING

1. **Download the App:** Search for "Nedis Smartlife" in your smartphone's app store (iOS or Android) and download the application.
2. **Register/Log In:** Open the app and create a new account or log in with an existing one.
3. **Add Device:** In the app, tap the "+" icon or "Add Device" to begin the pairing process.
4. **Select Device Type:** Choose the appropriate device category, typically "Security & Sensor" or "Lock".
5. **Enable Bluetooth:** Ensure Bluetooth is enabled on your smartphone.
6. **Pairing Mode:** Follow the on-screen instructions in the app to put the key box into pairing mode. This usually involves pressing a specific button on the keypad or inside the box.
7. **Connect:** The app will detect the key box. Select it to complete the pairing process.
8. **Device Renaming:** Once paired, you can rename your key box for easier identification within the app.

8. OPERATING INSTRUCTIONS

8.1 Unlocking via Nedis Smartlife App

1. Open the Nedis Smartlife app on your smartphone.
2. Select your paired key box from the device list.
3. Tap the "Unlock" button within the app interface. The key box will unlock.

8.2 Unlocking via Keypad (Permanent Code)

1. Enter your pre-set permanent access code on the numeric keypad.
2. Press the 'Check' (✓) button to confirm.
3. The key box will unlock.

8.3 Generating Temporary/One-Time Codes

The Nedis Smartlife app allows you to generate various types of access codes:

- **One-Time Codes:** Valid for a single use.
- **Temporary Codes:** Valid for a specified duration (e.g., hours, days, weeks).
- **Recurring Codes:** Valid at specific times or days.

To generate a code:

1. In the Nedis Smartlife app, select your key box.
2. Navigate to the "Code Management" or "Generate Code" section.
3. Choose the desired code type and set its parameters (e.g., validity period).
4. Generate the code and share it with the intended user.

8.4 Viewing Access Logs

The Nedis Smartlife app maintains a record of all access events. To view access logs:

1. Open the Nedis Smartlife app.
2. Select your key box.
3. Navigate to the "Logs" or "History" section to view a timeline of who accessed the box and when.

9. MAINTENANCE

- **Cleaning:** Wipe the exterior of the key box with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the low battery indicator appears in the app or on the device, or approximately once a year. Refer to Section 6 for battery installation instructions.
- **Firmware Updates:** Periodically check the Nedis Smartlife app for available firmware updates for your key box to ensure optimal performance and security.

10. TROUBLESHOOTING

- **Key box not responding:** Check battery levels. Use the Type-C emergency power if batteries are depleted.
- **Cannot connect to app:** Ensure Bluetooth is enabled on your phone and the key box is within range. Try restarting the app and the key box (by temporarily removing and reinserting batteries).
- **Keypad not working:** Ensure batteries are properly installed and charged. Clean the keypad surface if dirty.
- **Code not accepted:** Verify the code entered is correct. Check if the temporary code has expired. Ensure the key box is not in a locked state from too many incorrect attempts.
- **Difficulty pressing '0' on keypad:** Some users have reported this. Try pressing firmly or using a different finger. If persistent, contact support.

11. SPECIFICATIONS





Manufacturer	Nedis
Model Number	BTHKB10BK
Dimensions (L x W x H)	2 x 7.5 x 11 cm
Weight	940 grams
Color	Black
Material	SPCC Metal

Water Resistance	IPX5
Power Source	2x AA Batteries (not included)
Emergency Power	Type-C USB Port
Lock Type	Electronic Keypad / Smart Lock
Connectivity	Bluetooth
Mounting Type	Wall Mount / Portable (Shackle)
International Article Code	05412810438600

12. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official Nedis website. Keep your proof of purchase for warranty claims.

Related Documents - BTHKB10BK

 <p>SmartLife Smartwatch Safety Instructions BSW30BK</p>	<p>Nedis SmartLife Smartwatch BSW30BK Safety Instructions</p> <p>Essential safety instructions and intended use information for the Nedis SmartLife Smartwatch, model BSW30BK. Learn about its features, warnings, and proper handling.</p>
 <p>Zigbee Radiator Thermostat Installation ZBHTR20WT</p>	<p>Nedis Zigbee Radiator Thermostat ZBHTR20WT Installation Guide</p> <p>Step-by-step installation guide for the Nedis Zigbee Radiator Thermostat (model ZBHTR20WT). Learn how to install, set up, and connect your smart thermostat using the Nedis SmartLife app for efficient home heating control.</p>
 <p>WIFICO20CWT</p> <p>Outdoor IP camera</p>	<p>Nedis WIFICO20CWT Outdoor IP Camera Quick Start Guide</p> <p>A quick start guide for the Nedis WIFICO20CWT Outdoor IP Camera, detailing setup, usage, safety, and maintenance in multiple languages.</p>
	<p>Nedis ZBSM10WT Zigbee Motion Sensor Quick Start Guide</p> <p>Quick start guide for the Nedis ZBSM10WT Zigbee motion sensor, covering setup, installation, and automation with the Nedis SmartLife app.</p>


Zigbee
Radiator
Thermostat
Safety Instructions
ZBHTR20WT



[Nedis Zigbee Radiator Thermostat ZBHTR20WT Safety Instructions](#)

Safety instructions and user guide for the Nedis Zigbee Radiator Thermostat (ZBHTR20WT), covering intended use, warnings, and disposal.

Zigbee Curtain
/ Shutter
Switch
Safety Instructions
ZBCSN10RD



[Nedis ZBCSN10RD Zigbee Curtain/Shutter Switch Safety Instructions & User Guide](#)

Essential safety instructions and user guide for the Nedis ZBCSN10RD Zigbee Curtain/Shutter Switch. Learn about intended use, warnings, disposal, and compliance.