

Outsunny 84C-404V00DB

Outsunny 10' x 19.5' Pop Up Canopy Tent with Sidewalls

MODEL: 84C-404V00DB

Your comprehensive guide to assembly, operation, and maintenance.

1. Safety Information

Please read and understand all safety warnings and instructions before assembling or using this product. Failure to follow these instructions may result in serious injury or property damage.

- **Weather Conditions:** NEVER leave your portable canopy unattended. Take it down before a major storm, strong winds, heavy rain, or snow rolls through. This canopy is designed for temporary use and is not intended as a permanent structure.
- **Anchoring:** Always use both the included stakes and guy ropes to secure the canopy to the ground. For additional stability, especially on hard surfaces like concrete, consider using leg weight bags (sandbags) filled with sand or other heavy material.
- **Assembly:** A minimum of 2-3 people are required for safe and efficient installation. Ensure all locking mechanisms are fully engaged before use.
- **Site Selection:** Measure your site before purchase and assembly to ensure adequate space and clearance from obstacles. Avoid setting up near open flames or heat sources.
- **Drainage:** The canopy features drainage holes to prevent water accumulation on the roof. However, it is recommended to take down the canopy if heavy rain is expected to prevent excessive water weight.

2. Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Canopy Frame (Pre-assembled pop-up design)
- Canopy Cover (Dark Blue, UPF 30+)
- Sidewalls (6 pieces with cathedral-style windows and two zippered doors)

- Leg Weight Bags (for stability)
- Stakes and Guy Ropes (for ground anchoring)
- Wheeled Carry Bag (for transport and storage)

3. Setup Instructions

Follow these steps for quick and easy assembly of your pop-up canopy. It is recommended to have 2-3 people for installation.

1. **Unfold the Frame:** Place the folded canopy frame in the desired location. With a partner, gently pull the outer legs of the frame outwards until it begins to expand.
2. **Attach the Canopy Cover:** Drape the canopy cover over the expanded frame. Ensure the corners are aligned with the frame's corners. Secure the cover to the frame using the attached Velcro straps or clips.
3. **Extend the Legs:** Push up on the push-button control system located on each leg to raise and lock the canopy frame into its initial height setting.
4. **Adjust Height:** To customize the height, press the red button on each leg and extend or retract the inner leg to one of the three available height settings. Ensure all legs are locked at the same height.
5. **Add Sidewalls:** Attach the sidewalls to the canopy frame using the Velcro fasteners. The sidewalls feature cathedral-style windows and two zippered doors for flexible configuration.
6. **Secure the Canopy:** Use the provided stakes and guy ropes to anchor the canopy to soft ground. For hard surfaces, fill the leg weight bags with sand and place them around the base of each leg for added stability.

EASY SETUP POP UP DESIGN



STEP 1:

Open the canopy frame

STEP 2:

Push up on the push-button control system to raise and lock the canopy frame

STEP 3:

Adjust the height for preferred shade coverage

STEP 4:

Add sidewalls




Figure 1: Visual guide for the easy pop-up setup process.

3-LEVEL ADJUSTABLE HEIGHT



Figure 2: Detail of the push-button height adjustment system.

Your browser does not support the video tag.

Video 1: Official Outsunny video demonstrating the pop-up canopy setup and features.

4. Operating Instructions

Your Outsunny canopy is designed for versatility and ease of use.

- **Height Adjustment:** The canopy features three height settings. To adjust, press the red button on each leg and slide the inner leg to the desired position. Ensure all four legs are set to the same height for stability.
- **Sidewall Usage:** The six included sidewalls can be attached or removed as needed. They provide protection from wind, sun, and offer privacy. The cathedral-style windows allow natural light, and the two zippered doors provide easy access. For increased airflow, some or all sidewalls can be removed.
- **UV Protection:** The canopy cover offers UPF 30+ protection, providing shade and reducing exposure to harmful UV rays.



Figure 3: The canopy with sidewalls, highlighting the windows and doors.

5. Maintenance

Proper maintenance will extend the life of your canopy.

- **Cleaning:** Clean the canopy fabric and sidewalls with mild soap and water. Do not use harsh chemicals or abrasive cleaners, as this may damage the fabric or its UV coating. Allow all components to dry completely before storage to prevent mold and mildew.
- **Frame Care:** The high-strength alloy steel frame is powder-coated for rust resistance. Inspect the frame periodically for any signs of damage or corrosion. Clean any dirt or debris from the frame.
- **Storage:** When not in use, disassemble the canopy and store all components in the wheeled carry bag in a cool, dry place, away from direct sunlight and extreme temperatures.

6. Troubleshooting

Here are solutions to common issues you might encounter:

- **Instability:** Ensure all legs are fully extended and locked at the same height. Always use stakes, guy

ropes, and leg weight bags to secure the canopy, especially in windy conditions.

- **Water Pooling on Roof:** The canopy is designed with drainage holes. If water still pools, ensure the canopy fabric is taut and properly attached to the frame. Adjust the height if necessary to create proper tension.
- **Difficulty with Assembly/Disassembly:** Ensure you have 2-3 people assisting. Refer to the setup instructions and ensure all buttons and locking mechanisms are pressed correctly. Do not force components.

7. Specifications

Feature	Detail
Brand	Outsunny
Model Number	84C-404V00DB
Overall Dimensions	232.25" L x 117" W x 112.25" H
Folded Size	45.75" L x 13.75" W x 7.75" H
Material	Alloy Steel (Frame), Fabric (Canopy/Sidewalls)
Color	Dark Blue
Item Weight	68 Pounds
UV Protection	UPF 30+
Water Resistance Level	Water Resistant
Height Settings	3 adjustable levels
Included Accessories	Sidewalls, Leg Weight Bags, Stakes, Guy Ropes, Wheeled Carry Bag





Figure 4: Detailed dimensions of the canopy in both set up and folded states.

MULTIPLE STABILIZATION FEATURES



Multiple drain holes



Coated steel frame



Ground nails and ropes








Leg sandbags


Figure 5: Key stabilization features including drain holes, coated frame, and anchoring accessories.

8. Warranty and Support

For warranty information or customer support, please refer to the documentation included with your purchase or contact Outsunny customer service directly. General customer support is available through the retailer.

Customer Support: For assistance, please visit the [Aosom Direct seller page](#) or contact their support team.

	<p>Outsunny 84C-159 Canopy Tent Assembly Instructions and User Guide</p> <p>Comprehensive assembly instructions and user guide for the Outsunny 84C-159 canopy tent. Includes parts list, step-by-step assembly, and important safety information.</p>
	<p>Outsunny 12' x 12' Pop-Up Gazebo Assembly and Care Instructions</p> <p>This guide provides detailed instructions for assembling, using, and disassembling your Outsunny 12' x 12' pop-up gazebo. Includes safety warnings, care tips, and contact information for support.</p>
	<p>Outsunny 84C-037, 84C-051, 84C-269 Gazebo Assembly Instructions and Safety Guide</p> <p>This document provides comprehensive assembly instructions, parts list, hardware details, and safety precautions for the Outsunny 84C-037, 84C-051, and 84C-269 gazebo. It is designed for easy understanding and safe installation.</p>
	<p>Outsunny Hexagonal Gazebo Assembly Instructions</p> <p>Step-by-step guide for assembling the Outsunny hexagonal gazebo, including parts list and assembly diagrams.</p>
	<p>Outsunny 84C-120 Folding Pavilion - Assembly Instructions & User Guide</p> <p>Comprehensive assembly instructions and user guide for the Outsunny 84C-120 folding pavilion. Learn how to safely set up, use, and maintain your sun shelter. Includes parts list and step-by-step guidance.</p>



[Outsunny 84C-020 Tent Assembly & Instruction Manual](#)

Comprehensive assembly and instruction manual for the Outsunny 84C-020 tent. Includes safety warnings, parts list, hardware details, and step-by-step assembly guidance.