

Shark FA220UK

Shark FlexBreeze High-Velocity 12-in-1 Fan User Manual

Model: FA220UK

1. INTRODUCTION

Welcome to the Shark FlexBreeze High-Velocity 12-in-1 Fan user manual. This versatile fan is designed to provide powerful and quiet cooling for both indoor and outdoor environments. With its unique 12-in-1 design, you can easily switch between corded and cordless operation, and transform it from a pedestal fan to a tabletop unit. The included InstaCool Misting Attachment further enhances outdoor cooling. Please read this manual thoroughly before use to ensure safe and optimal performance of your new fan.

Your browser does not support the video tag.

Video: Overview of the Shark FlexBreeze fan, demonstrating its transformation from pedestal to tabletop mode, corded and cordless capabilities, and the misting attachment. It highlights the fan's powerful and quiet operation.

2. IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury. This fan is designed for both indoor and outdoor use and is UV & water-resistant (materials UV-resistant per UL746C, excludes remote control). However, avoid submerging the unit in water.

- Read all instructions before using the fan.
- Do not operate any fan with a damaged cord or plug.
- Keep the fan away from children and pets.
- Ensure the fan is placed on a stable, level surface.
- Do not insert fingers or foreign objects into the grille.
- Unplug the fan from the power outlet when not in use or before cleaning.
- When using the misting attachment, ensure proper hose connection and avoid spraying directly at electrical outlets or devices.



MISTING ATTACHMENT FOR ON-DEMAND COOLING

InstaCool mister cools outdoor spaces by up to 5°C.*
Simply connect it to the fan, attach a hose pipe and twist to bring the mist.

*Based on temperature reduction in controlled environment at 32°C, 2.7m from fan and up to 50%RH. Performance will vary with environmental factors.

Image: The Shark FlexBreeze fan positioned outdoors, demonstrating its UV and water-resistant design for reliable performance in various weather conditions.

3. WHAT'S INCLUDED

Your Shark FlexBreeze fan package includes the following components:

- FlexBreeze Fan Head
- Pedestal Pole
- Pedestal Base
- Charging Cable
- Remote Control
- InstaCool Misting Attachment
- Fan Cover



UP TO 24 HOURS OF CORDLESS RUNTIME*

Go cordless and bring serious power to any setting,
from indoor to outdoor.

*Based on fan speed 1 without oscillation.

Image: A detailed view of the Shark FlexBreeze fan, highlighting its main components and key features such as the control panel, 12-in-1 versatility, and included remote control.



Image: The Shark FlexBreeze fan displayed in both its full-height pedestal mode and compact tabletop mode, showcasing its adaptable design.

4. ASSEMBLY AND TRANSFORMATION

4.1. Pedestal Fan Assembly

1. Insert the pedestal pole into the pedestal base, ensuring it clicks securely into place.
2. Align the fan head with the top of the pedestal pole and push down firmly until it locks.
3. Ensure all connections are secure before operating the fan.

4.2. Transforming to Tabletop Fan

The Shark FlexBreeze fan can be easily converted from a pedestal fan to a compact tabletop fan:

1. Locate the release button on the back of the fan head, near the connection point to the pedestal pole.
2. Press and hold the release button while gently lifting the fan head upwards to detach it from the pedestal pole.
3. Extend the integrated tripod legs from the base of the fan head until they are fully open and stable.
4. Place the fan head on a flat, stable surface.



**LIFT TO TRANSFORM
FROM PEDESTAL TO TABLETOP**

5. OPERATING INSTRUCTIONS

5.1. Powering On/Off and Speed Control

The fan can be operated using the control panel on the fan head or the included remote control.

- **Power:** Press the power button to turn the fan ON or OFF.
- **Fan Speeds:** Cycle through 5 fan speeds by pressing the speed button. The LED display will indicate the current speed setting.
- **Breeze Modes:** Some models may feature gentle breeze or strong breeze settings for varied airflow patterns.

5.2. Oscillation and Tilt

- **Oscillation:** Press the oscillation button to activate or deactivate the 180-degree oscillation feature, distributing air across a wider area.
- **Tilt:** Manually adjust the fan head's tilt up to 55 degrees to direct airflow precisely where needed.

5.3. Remote Control

The magnetic remote control conveniently docks on the back of the fan head. It allows you to control power, fan speed, oscillation, and set a timer from a distance.



KEEP YOUR COOL WITH FULL CONTROL
Want to customise your comfort? Grab the magnetic remote and take control from a distance.

Image: A user operating the Shark FlexBreeze fan with its magnetic remote control, emphasizing convenient control from a distance.

5.4. InstaCool Misting Attachment (Outdoor Use)

For enhanced outdoor cooling, attach the InstaCool Misting Attachment:

1. Clip the misting attachment onto the front grille of the fan.
2. Connect a standard garden hose to the attachment.
3. Twist the attachment to activate the misting function. The mist can be felt up to 3 meters away and can lower outdoor temperatures by up to 5°C.



SLEEK STYLING FOR THE INDOORS
Minimalist design enhances any decor, making
FlexBreeze the perfect indoor essential.

Image: The Shark FlexBreeze fan with its misting attachment in use outdoors, providing a refreshing cool mist for users.



STORAGE COVER

Need a break from the breeze?
Avoid the dust with our cover.

Image: A close-up view of the InstaCool Misting Attachment, showing its components and how it connects to the fan and a garden hose.

6. CHARGING AND BATTERY LIFE

The Shark FlexBreeze fan can operate corded or cordless, thanks to its long-lasting rechargeable battery.

- **Charging:** Connect the charging cable to the fan and a suitable power outlet. The charging port is accessible in both pedestal and tabletop modes.
- **Battery Runtime:** Enjoy up to 24 hours of battery runtime on a single charge (based on fan speed 1 without oscillation).
- **Battery Indicator:** The LED display on the control panel shows the current battery level.



Indoor & Outdoor

Outdoor tough and indoor sleek. UV and water-resistant* design. **Materials UV-resistant per UL746C. Excludes remote control.*

Included Remote

Magnetic remote docks on the back of the fan head. Remote can power on/off, change speed settings and Breeze modes, set a timer for up to 5 hours, move the head from left to right and enable oscillation.

Corded & Cordless

Plug in for endless power or go cordless for up to 24 hours of battery runtime**. Charging cable connects in both pedestal and tabletop modes.

***Based on fan speed 1 without oscillation.*

Control Panel & LED Display

Individual controls for oscillation, fan speed and power. LED display shows current speed setting, battery level and oscillation.

12-in-1 design

Use in 12 different combinations of corded or cordless, outdoors or indoors, desktop or pedestal fan or with or without the mister attachment.

GET TO KNOW THE SHARK FLEXBREEZE

High-Velocity Cordless & Corded Fan

Image: The Shark FlexBreeze fan operating cordlessly in an outdoor setting, emphasizing its extended battery life for portable use.

7. CARE AND MAINTENANCE

7.1. Cleaning

- Always unplug the fan before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- For the fan blades, use a soft brush or vacuum cleaner with a brush attachment to remove dust.
- Ensure the fan is completely dry before plugging it back in or storing.

7.2. Storage

When not in use, especially during off-season, store your fan in a cool, dry place. Use the provided fan cover to protect it from dust and debris.



Instacool
Misting Attachment



Storage
Cover



Remote
Control

SO MUCH MORE INCLUDED:
The included Shark FlexBreeze accessories
unlock so much more versatility.

Image: The Shark FlexBreeze fan protected by its custom-fit storage cover, ideal for keeping it dust-free when not in use.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply; Battery depleted; Power button not pressed.	Ensure the power cable is securely plugged in or the battery is charged. Press the power button firmly.
Weak airflow.	Fan speed too low; Air intake/outlet blocked; Dirty blades.	Increase fan speed. Check for obstructions around the fan. Clean the fan blades and grilles.
Fan is noisy.	Fan not on a level surface; Loose parts; Obstruction.	Place the fan on a flat, stable surface. Check for any loose components or foreign objects.

Problem	Possible Cause	Solution
Misting attachment not working.	Hose not connected; Water supply off; Attachment not twisted correctly.	Ensure garden hose is connected and water supply is on. Twist the attachment to activate mist.

9. TECHNICAL SPECIFICATIONS

Model: FA220UK

Product Dimensions: 35D x 35W x 94H cm (Pedestal mode)

Item Weight: 5.5 kg

Power Source: Battery Powered / Corded

Battery Type: 1 Lithium Ion battery (included)

Wattage: 36 watts

Special Features: Hybrid Indoor & Outdoor Fan, Convertible Desktop & Pedestal Fan, Corded or Cordless Use, Remote Control, Misting Attachment, UV & Water-Resistant.

10. WARRANTY AND SUPPORT

Your Shark FlexBreeze fan comes with a **2-year guarantee** upon registration with Shark (UK & ROI only). For warranty claims, technical support, or to register your product, please visit the official Shark website or contact their customer service.

For more information and support, visit the [Shark Store on Amazon](#).