

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [bmani](#) /

› [bmani Wireless Earbuds T16 Bluetooth Headphones User Manual](#)

bmani T16

bmani Wireless Earbuds T16 Bluetooth Headphones User Manual

Model: T16

1. INTRODUCTION

Thank you for choosing the bmani Wireless Earbuds T16. These earbuds are designed to provide a high-quality audio experience with convenience and comfort, especially for active lifestyles. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

2. PRODUCT FEATURES

- Dual LED Displays:** The charging case features LED displays to clearly show the battery percentage of the case and the individual charging status of each earbud.
- Bluetooth 5.2 Connectivity:** Ensures a stable and smooth wireless connection with a range of up to 33 feet.
- Hi-Fi Stereo Sound:** Equipped with 10mm coil speakers for rich, clear audio.
- Built-in Microphone:** Provides crystal clear call quality for hands-free communication.
- One-Button Control:** Simplifies operations for music playback, calls, and voice assistant activation.
- Automatic Pairing:** Earbuds automatically connect to the last paired device upon removal from the charging case.
- Ergonomic Design with Earhooks:** Soft earfins and adjustable silicone earhooks ensure a secure and comfortable fit, ideal for sports and extended wear.
- Water Resistant:** Suitable for workouts and outdoor activities, even in light rain.
- Compact Charging Case:** Easily fits into your bag or pocket for convenient portability.

3. PACKAGE CONTENTS

- bmani Wireless Earbuds (2 sets, Pink and Green)

- Charging Case
- USB Charging Cable
- Ear Caps (3 pairs: S, M, L)
- User Manual

4. GETTING STARTED

4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. The LED display on the case will indicate the charging status and battery levels. During charging, the LED indicator light will flash.



Image: The charging case features a dual LED digital display, showing the charging case capacity on the left and individual earbud power levels (R and L) on the right.

48Hrs Long Battery Life



Image: An illustration showing the 48 hours long battery life, with 8 hours music time per bud (50mAh each) and 40 hours listening time from the 600mAh charging case.

4.2 Initial Pairing

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for "T16" in the list of available Bluetooth devices and select it to connect.
5. If prompted, confirm the pairing.
6. Once connected, the earbuds will automatically pair with this device in the future when taken out of the case.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically

power off and begin charging.

5.2 Music Control



Image: An illustration detailing the button controls on the earbuds: single press for play/pause, double press for next/previous track, and triple press/hold for power/voice assistant.

- **Play/Pause:** Single-tap the button on either earbud.
- **Next Track:** Double-tap the button on the right earbud.
- **Previous Track:** Double-tap the button on the left earbud.
- **Volume Up:** Single-tap the '+' button on the earbud.
- **Volume Down:** Single-tap the '-' button on the earbud.

5.3 Call Control

- **Answer/End Call:** Single-tap the button on either earbud.
- **Reject Call:** Press and hold the button on either earbud for 2 seconds.

5.4 Voice Assistant

- **Activate Voice Assistant:** Triple-tap the button on either earbud.

6. MAINTENANCE

- Clean the earbuds and charging case regularly with a soft, dry cloth.
- Avoid using abrasive cleaners or solvents.
- Keep the charging contacts on both the earbuds and the case clean to ensure proper charging.
- Store the earbuds in their charging case when not in use to protect them and maintain battery life.
- Avoid exposing the earbuds to extreme temperatures or direct sunlight for prolonged periods.

7. TROUBLESHOOTING

7.1 Earbuds Not Pairing or Connecting

If you experience issues with pairing or connection, try resetting the earbuds:

1. On your device, go to Bluetooth settings and "forget" or "unpair" the "T16" earbuds. Then, turn off Bluetooth on your device.
2. Place both Bluetooth earbuds into the charging case and ensure they are being charged (LED indicators should be active).
3. Quickly quadruple-tap the button on both earphones.
4. After the reset, take both earbuds out of the charging case. Observe the LED lights: one earbud should flash red and blue quickly, while the other flashes blue slowly. This indicates successful pairing between the two earbuds.
5. Turn on Bluetooth on your device again, search for "T16", and pair.
6. If a pop-up window appears to confirm pairing, select "pair". If you accidentally select "cancel", you will need to delete the earbuds from your device's Bluetooth history and re-pair them.

7.2 No Sound or Low Volume

- Check the volume levels on both your device and the earbuds.
- Ensure the earbuds are properly connected to your device.
- Clean any debris from the earbud speakers.

7.3 Charging Issues

- Ensure the charging cable is securely connected to both the case and a power source.
- Clean the charging contacts on the earbuds and inside the case.
- Try using a different charging cable or power adapter.

8. SPECIFICATIONS

Feature	Detail
Model Name	T16 (2 Sets Wireless Earbuds)
Brand	bmani
Connectivity Technology	Wireless (Bluetooth 5.2)

Bluetooth Range	Up to 33 Feet
Audio Driver Type	Dynamic Driver (10mm coil)
Control Type	Button Control, Touch Control, Media Control
Ear Placement	Over Ear
Form Factor	In Ear
Water Resistance Level	Water Resistant
Material	Silicone (ear caps), Plastic or aluminum (carrying case)
Carrying Case Weight	1.6 Ounces
Color	Pink, Green
Compatible Devices	Any Bluetooth-enabled device
Recommended Uses	Exercising, Running, Sport
Noise Control	None

9. PRODUCT OVERVIEW




Image: A pair of bmani wireless earbuds in a pink charging case, with the lid open revealing the earbuds and their LED battery indicators.





Image: A pair of bmani wireless earbuds in a green charging case, with the lid open revealing the earbuds and their LED battery indicators.

10mm Speakers for HiFi Stereo Sound



Image: A close-up of a green earbud, illustrating the 10mm speakers that deliver HiFi stereo sound, with small figures representing an audience.



Designed for Sports

Image: A woman wearing a green bmani earbud during a workout, highlighting the flexible earhooks and showing different ear cap sizes (L, M, S).

10. OFFICIAL PRODUCT VIDEO

Video: Official product video demonstrating the features and design of the bmani Wireless Earbuds, including LED displays, button controls, and ergonomic fit.

11. WARRANTY AND SUPPORT

Your bmani Wireless Earbuds T16 come with a standard manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or contact bmani customer support. If you encounter any issues or have questions not covered in this manual, please reach out to our customer service team for assistance.

For further information, you may also visit the product detail page on Amazon: [Amazon Product Page](#)

