

MESWAO MES-B2

MESWAO 14-inch Android Tablet User Manual

Model: MES-B2

INTRODUCTION

Thank you for choosing the MESWAO 14-inch Android Tablet. This manual provides essential information to help you set up, operate, and maintain your device. Please read it carefully to ensure optimal performance and longevity of your tablet.

WHAT'S IN THE BOX

Your MESWAO Tablet package includes the following items:

- 1*MESWAO 14 inch Android Tablet
- 1*Power Adapter & 1*Type C Cable
- 1*User Manual
- 1*Type-C to USB adapter
- 1*Stuck pin



Image: The MESWAO 14-inch Android Tablet, highlighting its large screen, Android 14 OS, 1TB expandable storage, and 12000mAh battery.

SETUP GUIDE

1. Device Layout and Components

12000 mAh Long-lasting Battery


Dawn-to-Dusk Productivity

8^H
Video

12^H
Music

10^H
Browsing

720^H
Standby



 **Type-C**
Connection

 **5V/3A**
Support 18W Fast Charging

 **4 Stereo**
Speakers

Image: A detailed diagram illustrating the location of stereo speakers, front camera, 32MP rear camera with flash, power button, volume buttons, Type-C port, and TF card slot on the MESWAO tablet.

- **Power Button:** Located on the side, used to turn the device on/off or wake/sleep the screen.
- **Volume Buttons:** Adjust the audio volume.
- **Type-C Port:** For charging and data transfer.
- **TF Card Slot:** Insert a microSD card for expandable storage up to 1TB.
- **Front Camera (5MP):** For video calls and selfies.
- **Rear Camera (32MP):** For high-resolution photos and videos, includes a flash.
- **Stereo Speakers:** Provide audio output.

2. Initial Charging

Before first use, fully charge your tablet using the provided power adapter and Type-C cable. The 12000mAh battery supports up to 8 hours of video playback.

3. Power On/Off

- **To Power On:** Press and hold the Power button until the MESWAO logo appears.
- **To Power Off:** Press and hold the Power button until a power-off menu appears, then select "Power

off".

- **To Restart:** Press and hold the Power button until a power-off menu appears, then select "Restart".

OPERATING INSTRUCTIONS

1. Android 14 Operating System

Your tablet runs on the upgraded Android 14 system, offering a personalized, secure, and user-friendly experience. It supports online system updates (OTA).



Image: The MESWAO tablet showcasing its Android 14 interface with various pre-installed and downloadable applications, emphasizing privacy and security features.

2. Wi-Fi Connectivity

To connect to a Wi-Fi network:

1. Go to **Settings > Network & internet > Internet**.
2. Turn on Wi-Fi.
3. Select your desired network from the list and enter the password if required.

The tablet supports fast and stable 2.4G/5G Wi-Fi for undisturbed streaming, gaming, or browsing.

3. App Installation and Storage

You can install applications from the Google Play Store. Your tablet comes with 128GB of internal storage and supports expansion up to 1TB via a microSD card (sold separately).



Image: A visual representation of the MESWAO tablet's storage capabilities, highlighting 6GB RAM, 128GB ROM, and 1TB expandable memory, with various app icons suggesting ample space for media and applications.

4. Camera Usage

The tablet features a 5MP front camera and a 32MP rear camera with flash. Open the Camera app to capture photos and videos.

Seize Every Precious Life Memory

32MP Rear camera + **5MP** Front camera



Image: The MESWAO tablet highlighting its 32MP rear camera and 5MP front camera, with example photos demonstrating its photography capabilities.

5. Bluetooth Connectivity

The tablet supports Bluetooth 5.0 for connecting to high-fidelity headphones, keyboards, and other accessories.

1. Go to **Settings** > **Connected devices** > **Connection preferences** > **Bluetooth**.
2. Turn on Bluetooth.
3. Select the device you wish to pair from the list.

6. Battery Life

The 12000mAh battery provides long-lasting power:

- Up to 8 hours of video playback.
- Up to 12 hours of music playback.
- Up to 10 hours of browsing.
- Up to 720 hours of standby time.



Image: An infographic illustrating the 12000mAh long-lasting battery of the MESWAO tablet, showing estimated usage times for video, music, browsing, and standby, along with Type-C connection and 18W fast charging support.

MAINTENANCE

1. Cleaning the Device

Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid using harsh chemicals or abrasive materials that could damage the surface.

2. Software Updates

Regularly check for system updates to ensure your tablet has the latest features and security patches. Go to **Settings > System > System update** to check for and install updates.

3. Battery Care

- Avoid exposing the tablet to extreme temperatures.
- Do not let the battery completely drain frequently.
- Use only the provided charger or a certified compatible charger.

TROUBLESHOOTING

If you encounter issues with your MESWAO tablet, please refer to the following common solutions:

Problem	Possible Solution
Tablet won't turn on	Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. If it still doesn't turn on, try holding the power button for 10-15 seconds.
Apps are crashing or freezing	Close the problematic app and reopen it. Clear the app's cache (Settings > Apps > [App Name] > Storage & cache > Clear cache). Restart the tablet. Ensure the app is updated to its latest version.
Wi-Fi connection issues	Restart your Wi-Fi router. Forget the network on your tablet (Settings > Network & internet > Internet > [Network Name] > Forget) and reconnect. Ensure you are within range of the Wi-Fi signal.
Slow performance	Close unused apps running in the background. Clear cache and temporary files. Consider uninstalling rarely used apps. Ensure sufficient storage space is available.
Screen not responding	Restart the tablet by holding the power button. If unresponsive, force restart by holding the power button for an extended period (e.g., 20 seconds).

If the issue persists, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	MESWAO
Model Name	MES-B2
Operating System	Android 14
Screen Size	14 Inches
Screen Resolution	1920 x 1200 pixels (FHD IPS)
Processor	MediaTek Helio G99 8-Core CPU, 2.2 GHz
RAM	6 GB DDR3 SDRAM
Internal Storage (ROM)	128 GB
Expandable Storage	Up to 1TB via TF Card (microSD)
Rear Camera	32MP
Front Camera	5MP

Feature	Detail
Battery Capacity	12000mAh
Average Battery Life	8 Hours (Video)
Wireless Type	802.11ac (Wi-Fi 6), Bluetooth 5.0
Item Weight	4.09 pounds
Product Dimensions	12.5 x 8.26 x 0.35 inches

WARRANTY AND SUPPORT

Warranty Information

Please refer to the warranty card included in your product packaging for specific warranty terms and conditions. Generally, MESWAO products come with a limited warranty covering manufacturing defects.

Customer Support

For any questions, issues, or technical assistance, our dedicated support team is available 24/7. You can reach us via email:

support@meswao.com

When contacting support, please provide your product model (MES-B2) and a detailed description of the issue.