

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [EasyKeys](#) /

› [EasyKeys Toolbox Replacement Key for Mac Tools 8059A User Manual](#)

EasyKeys 8059A

EasyKeys Toolbox Replacement Key for Mac Tools 8059A User Manual

Model: 8059A

[Instructions](#) [Product Overview](#) [Maintenance](#) [Key Identification & Setup](#) [Troubleshooting](#) [Specifications](#) [Operating](#) [Warranty & Support](#)

1. PRODUCT OVERVIEW

This manual provides instructions for the EasyKeys Toolbox Replacement Key, specifically designed for Mac Tools Key Series 8001A - 9000A, including the 8059A code. This custom-cut key is compatible with various manufacturers such as Mac Tool, Fort, Craftsman, and Proto. It is a double-sided cut key, cut on a K752 key blank, and is intended for toolbox locks, not Wangtong furniture locks.

Where to Find Your Lock Code



On the Key



On the Lock Face



**On a Label Inside/
Behind the Lock**



**On the
Cabinet/Door Label**



Important Notes

- Order by Manufacturer → Lock codes are manufacturer-specific.
- Key Cuts Differ → Even if codes look similar, they vary by brand.

This image displays the EasyKeys Toolbox Replacement Key, designed for Mac Tools 8059A locks. The key is made of brass and features a standard cut for compatibility with the specified lock series.

2. KEY IDENTIFICATION AND SETUP

To ensure you have the correct replacement key, it is crucial to accurately identify your lock code and manufacturer. Lock codes are manufacturer-specific, and key cuts can differ even if codes appear similar across brands.

Where to Find Your Lock Code:

- **On the Key:** The code may be stamped directly on your existing key (e.g., FR322).
- **On the Lock Face:** The code might be visible on the face of the lock cylinder (e.g., FR322).
- **On a Label Inside/Behind the Lock:** For some toolboxes, the code is found on a label located inside or behind the lock mechanism (e.g., CODE: G38).
- **On the Cabinet/Door Label:** A label on the cabinet or door itself may contain the lock code (e.g., HF321).

Important Notes:

- △ Order by Manufacturer: Lock codes are manufacturer-specific. Always verify your manufacturer.
- △ Key Cuts Differ: Even if codes look similar, key cuts vary significantly by brand.

Before inserting the new key, ensure the lock mechanism is free of obstructions. If you are replacing a lost key, ensure the lock cylinder is in the unlocked position if possible, or consult a professional if the lock is jammed.

3. OPERATING INSTRUCTIONS

Follow these steps to properly use your EasyKeys replacement key:

1. **Insert the Key:** Gently insert the key into the lock cylinder. Do not force the key. If it does not slide in smoothly, check for any obstructions in the keyway.
2. **Turn to Unlock/Lock:** Once fully inserted, turn the key clockwise to unlock or counter-clockwise to lock, depending on your lock mechanism's design. The key should turn smoothly without excessive force.
3. **Remove the Key:** After locking or unlocking, return the key to its original vertical or horizontal position before gently pulling it out.

Note: If the key feels stiff or difficult to turn, do not force it. Forcing the key can damage both the key and the lock. Refer to the Troubleshooting section.

4. MAINTENANCE

Proper maintenance ensures the longevity of your key and lock:

- **Keep Clean:** Keep the key clean and free from dirt, dust, or debris. Wipe it with a soft, dry cloth periodically.
- **Avoid Bending:** Store the key in a way that prevents it from bending or being subjected to heavy pressure.
- **Lubrication (if needed):** If the lock mechanism becomes stiff, a small amount of graphite lubricant or a specialized lock lubricant can be applied to the keyway. Avoid using oil-based lubricants as they can attract dirt.
- **Proper Storage:** Store the key in a secure and easily accessible location, away from extreme temperatures or corrosive materials.

5. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Issue	Possible Cause	Solution
Key does not insert fully.	Obstruction in keyway, incorrect key orientation.	Check for debris in the keyway. Ensure the key is oriented correctly. Do not force.
Key turns but lock does not open/close.	Lock mechanism malfunction, incorrect key.	Verify the key code matches your lock. The lock mechanism may require professional repair.
Key is stiff or hard to turn.	Lack of lubrication, minor misalignment, debris.	Apply a small amount of graphite lubricant to the keyway. Gently wiggle the key while turning.
Key breaks in lock.	Excessive force, worn key/lock.	<i>Do not attempt to remove the broken piece yourself if it's deep inside.</i> Contact a locksmith for professional removal and lock repair/replacement.

6. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	EasyKeys
Model Number	8059A-mactools-key-897911 (Key Code: 8059A)
Compatible Manufacturers	Mac Tool, Fort, Craftsman, Proto
Lock Type	Cam Lock (for toolboxes)
Material	Brass
Special Features	Adjustable Fit, Custom Cut Key, Durable
Item Dimensions (L x W x H)	0.5 x 0.5 x 1 inches
Item Weight	4 ounces
Included Components	1 Key

7. WARRANTY AND SUPPORT

EasyKeys products are designed for reliability and durability. For specific warranty information or technical support, please refer to the EasyKeys official website or contact their customer service directly. Ensure you have your product details, including the model number (8059A), ready when seeking support.

For further assistance, you may visit the [EasyKeys Store on Amazon](#).



