



Manuals.plus /

› EasyKeys /

› EasyKeys XL Locks X1 Toolbox Replacement Key User Manual

EasyKeys X1-xllocks-key-1504148

EasyKeys XL Locks X1 Toolbox Replacement Key User Manual

INTRODUCTION

This manual provides essential information for the EasyKeys XL Locks X1 Toolbox Replacement Key. It covers how to identify your lock code, proper usage, maintenance, and product specifications to ensure correct application and longevity of your key.

PRODUCT OVERVIEW

The EasyKeys XL Locks X1 Replacement Key is designed to provide a precise fit for XL Locks with the X1 code. This custom-cut key is made from durable brass, ensuring reliable operation for your toolbox or other compatible locks.

Where to Find Your Lock Code




On the Key



On the Lock Face



**On a Label Inside/
Behind the Lock**



**On the
Cabinet/Door Label**



Important Notes

- Order by Manufacturer → Lock codes are manufacturer-specific.
- Key Cuts Differ → Even if codes look similar, they vary by brand.

Image: EasyKeys XL Locks X1 Replacement Key, a brass key with a distinctive cut.

IDENTIFYING YOUR LOCK CODE

Before ordering or using your replacement key, it is crucial to accurately identify the code of your existing lock. The X1 key is specifically for XL Locks with the X1 code. Lock codes are typically found in several

locations:

Illustrative Graphic: Where to Find Your Lock Code

This graphic typically shows four common locations for lock codes:

- **On the Key:** The code (e.g., FR322) is often stamped directly on the key itself.
- **On the Lock Face:** For some locks, the code (e.g., FR322) is visible on the front surface of the lock cylinder.
- **On a Label Inside/Behind the Lock:** The code (e.g., G38) may be found on a sticker or label located inside the mechanism or on the back of the lock body.
- **On the Cabinet/Door Label:** For furniture or cabinet locks, the code (e.g., HF321) might be on a label affixed to the inside of the cabinet door or frame.

Note: An illustrative image detailing these locations would be placed here if available.

Important Notes:

- **Order by Manufacturer:** Lock codes are manufacturer-specific. An X1 code from one manufacturer may not be compatible with an X1 code from another. Ensure your lock is an XL Lock.
- **Key Cuts Differ:** Even if codes appear similar, the actual key cuts vary significantly by brand. Always verify the manufacturer.

USAGE INSTRUCTIONS

1. **Verify Compatibility:** Confirm that your lock is an XL Lock and the code matches X1.
2. **Insert Key:** Gently insert the replacement key into the lock cylinder. Do not force the key.
3. **Turn Key:** Turn the key clockwise or counter-clockwise as required to engage or disengage the lock mechanism.
4. **Remove Key:** Once the lock is operated, turn the key back to its original position and gently remove it.

If the key does not turn smoothly, do not apply excessive force. Refer to the Troubleshooting section.

MAINTENANCE

Proper care ensures the longevity and smooth operation of your replacement key:

- **Keep Clean:** Periodically wipe the key with a dry cloth to remove dirt or debris. Avoid using harsh chemicals.
- **Avoid Bending:** Store the key in a manner that prevents it from bending or being subjected to heavy pressure.
- **Lubrication (for lock):** If the lock mechanism becomes stiff, apply a small amount of graphite-based lubricant directly into the lock cylinder, not on the key itself.

TROUBLESHOOTING

Key does not insert fully:

Check for obstructions in the lock cylinder. Ensure the key is oriented correctly. Do not force it.

Key inserts but does not turn:

Verify that the lock code on your key matches the lock. Ensure the lock mechanism is not jammed or

damaged. A small amount of lock lubricant may help.

Key feels loose or wobbly:

This may indicate wear on the lock cylinder or the key itself. If the key is new, re-verify the lock code and manufacturer compatibility.

SPECIFICATIONS

Feature	Detail
Brand	EasyKeys
Model Number	X1-xllocks-key-1504148
Compatible Manufacturer	XL Locks
Lock Type	Cam Lock (compatible)
Material	Brass
Special Feature	Custom Cut Key, Durable
Item Dimensions (L x W x H)	0.5 x 0.5 x 1 inches
Item Weight	4 ounces

SUPPORT AND WARRANTY

For any questions, concerns, or support regarding your EasyKeys XL Locks X1 Replacement Key, please contact EasyKeys customer service. Information regarding specific warranty terms can be obtained directly from EasyKeys or your point of purchase.

You can visit the EasyKeys Store on Amazon for more products and support information.