

## EasyKeys EM624

# EasyKeys Toolbox Replacement Key for Eberhard EM624

## Instruction Manual

### INTRODUCTION

---

This manual provides essential information for the proper identification, use, and care of your EasyKeys replacement key for Eberhard EM624 toolbox locks. This key is specifically designed to replace lost or damaged keys for locks coded EM624, ensuring continued access to your toolbox or cabinet.

### IDENTIFYING YOUR LOCK CODE

---

Before ordering or using your replacement key, it is crucial to verify your lock's code. The code EM624 must match your existing lock for the key to function correctly. Lock codes can typically be found in several locations:



This diagram illustrates the various places where you can locate your lock's code. These include directly on the key itself, etched or printed on the face of the lock cylinder, on a sticker or label found inside or behind the lock mechanism, or on a label affixed to the cabinet or door near the lock.

- **On the Key:** The code may be stamped directly onto your original key.
- **On the Lock Face:** The code can often be found engraved or printed on the visible face of the lock cylinder.
- **On a Label Inside/Behind the Lock:** For some locks, the code is on a sticker or label located within the lock mechanism or on the inside of the door/drawer it secures.
- **On the Cabinet/Door Label:** Occasionally, the lock code is provided on a label attached to the cabinet or door itself.

### COMPATIBILITY

---

This EasyKeys replacement key is specifically cut for Eberhard EM624 lock codes. It is compatible with locks from the Eberhard Key Series EM501 - EM750. Additionally, this key is known to be compatible with locks manufactured by:

- Brockway

- Hudson
- ProTech
- Yale Lock

Always verify that your lock code and manufacturer match the product title and the list above to ensure proper fit and function.

## USAGE

---

To use your replacement key:

1. Gently insert the key into the lock cylinder. Do not force the key.
2. Once fully inserted, turn the key clockwise or counter-clockwise (depending on the lock mechanism) to engage or disengage the lock.
3. Remove the key after locking or unlocking.

## IMPORTANT CONSIDERATIONS

---

Please note the following points to ensure correct key selection and function:

- **Order by Manufacturer:** Lock codes are often manufacturer-specific. An EM624 code from one manufacturer may not be the same as an EM624 code from another, even if the numbers are identical. Always confirm the manufacturer.
- **Key Cuts Differ:** Even if lock codes appear similar across different brands, the actual key cuts (bitting) can vary significantly. This key is cut to the specific bitting for Eberhard EM624 locks.

## PRODUCT SPECIFICATIONS

---

Feature	Detail
Brand	EasyKeys
Model Name	EM624
Manufacturer	Eberhard (for lock compatibility)
Material	Brass
Lock Type	Cam
Special Feature	Custom Cut Key, Durable
Item Dimensions (L x W x H)	0.5 x 0.5 x 1 inches
Item Weight	0.25 Pounds
Included Components	1 Key

## TROUBLESHOOTING

---

- **Key does not insert fully:** Ensure the key is oriented correctly. Do not force it. Check for any obstructions in the lock cylinder.
- **Key inserts but does not turn:** Double-check that the lock code on your key matches the code on your

lock. Verify the lock is an Eberhard EM624 or one of the compatible manufacturers listed. The lock mechanism might be jammed or corroded; consider applying a graphite-based lubricant.

- **Key feels loose or wobbly:** This may indicate wear in the lock cylinder or an incorrect key cut. Re-verify your lock code and manufacturer.

## CARE AND MAINTENANCE

---

To prolong the life of your key and lock:

- Avoid using the key for purposes other than operating the lock (e.g., prying).
- Keep the key clean and free from dirt or debris.
- If the lock mechanism becomes stiff, apply a small amount of graphite lubricant into the keyway, not oil-based lubricants which can attract dust.

## WARRANTY AND SUPPORT

---

EasyKeys provides quality replacement keys. For any issues or questions regarding your replacement key, please contact EasyKeys customer support through the retailer where the product was purchased. Please have your order details and lock code available for faster assistance.