

[Manuals+](#)

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Schonbek](#) /

› [Schonbek Siena RS84151N-22A Chandelier Instruction Manual](#)

Schonbek RS84151N-22A

Schonbek Siena RS84151N-22A Chandelier Instruction Manual

Model: RS84151N-22A

1. INTRODUCTION AND OVERVIEW

This manual provides essential instructions for the safe installation, operation, and maintenance of your Schonbek Siena RS84151N-22A Chandelier. This 17-light, two-tier chandelier features an Heirloom Gold finish and Clear Swarovski Spectra Crystals, designed for indoor use only.

The Siena chandelier is crafted with a durable stainless steel frame, aluminum candle slips, and crystal bobeches. It is adorned with a waterfall of aluminum leaves and crystal beading around fine glass arms, creating a distinctive aesthetic. This fixture is designed and manufactured in the U.S.A.



Image 1.1: The Schonbek Siena RS84151N-22A Chandelier, showcasing its two-tier design, Heirloom Gold finish, and Clear Swarovski Spectra Crystals.

2. SAFETY INFORMATION

WARNING: Risk of electric shock. Disconnect power at the circuit breaker or fuse box before installation or servicing.

- Read all instructions carefully before beginning installation.
- Installation should be performed by a qualified electrician or a certified professional.
- Ensure the mounting surface can support the weight of the fixture (approximately 44 pounds).
- Use only bulbs of the specified type and wattage (E12 base, B10 shape, 120V, 60W max incandescent or LED). Exceeding the maximum wattage may cause overheating and damage.
- Do not connect the fixture to an ungrounded electrical system.
- This fixture is UL, cUL, and CSA rated for indoor locations only. Do not install in damp or wet environments.
- Wear safety glasses and gloves during installation.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Lighting Fixture (Chandelier body with arms and frame)
- Mounting Hardware (Canopy, mounting strap, screws, wire nuts)
- Instruction Sheets
- Manufacturer Warranty Certificate
- Certificate of Authenticity
- Chain (40 inches included, matching finish)

Note: Light bulbs are sold separately and are not included in the package.

4. SETUP AND INSTALLATION

Assembly of the chandelier is required. Follow these steps carefully:

1. **Prepare for Installation:** Ensure power is disconnected at the main circuit breaker. Clear the work area and gather necessary tools (screwdriver, wire strippers, ladder, safety glasses).
2. **Mounting Hardware Installation:** Attach the mounting strap to the electrical junction box in the ceiling. Secure the canopy to the mounting strap, ensuring it is flush with the ceiling.
3. **Chain and Wiring:** The fixture is suspended from the canopy using the included 40-inch chain. The chain length can be adjusted during installation. The fixture includes 180 inches of total wire, allowing for a maximum suspension of up to 235 inches with additional chain (sold separately). Connect the fixture's electrical wires to the house wiring according to local electrical codes (typically black to black, white to white, and ground to ground).
4. **Fixture Assembly:** Carefully unpack the chandelier body. Attach any arms or components that may have been detached for shipping, following the specific diagrams in the included instruction sheets.
5. **Crystal Dressing:** The chandelier features a waterfall of aluminum leaves and crystal beading, along with multifaceted crystal drops. Carefully attach all crystal elements as indicated in the detailed instruction sheets. Handle crystals with care to avoid damage or fingerprints.
6. **Bulb Installation:** Install 17 E12 base, B10 shape light bulbs (sold separately) into the sockets. Do not exceed 60 watts per bulb.
7. **Final Check:** Ensure all connections are secure and all components are properly installed. Restore power at the circuit breaker.

Slope Ceiling Compatibility: This fixture can be installed on a slope ceiling with an angle of up to 45 degrees.





Image 4.1: Detail of the Siena Chandelier's crystal bobeches, candle slips, and crystal drops, which require careful assembly.

5. OPERATING INSTRUCTIONS

The Schonbek Siena Chandelier operates via a standard wall switch connected to the fixture's electrical circuit.

- **Turning On/Off:** Use the wall switch to control the power supply to the chandelier.
- **Dimming Functionality:** The fixture is designed for smooth and continuous dimming when used with compatible dimmer switches and dimmable E12 LED or incandescent bulbs. Consult your dimmer switch manufacturer's instructions for proper operation.

The control method is listed as 'Touch' in some specifications, which typically refers to the compatibility with modern touch-sensitive dimmer switches, not a direct touch control on the fixture itself.

6. MAINTENANCE

Regular cleaning and maintenance will preserve the beauty and longevity of your chandelier.

- **Cleaning Crystals:** Gently wipe crystals with a soft, lint-free cloth dampened with distilled water or a specialized crystal cleaner. Avoid abrasive cleaners or harsh chemicals.
- **Cleaning Metal Components:** Dust the Heirloom Gold finish with a dry, soft cloth. Do not use abrasive cleaners or polishes that could damage the finish.
- **Bulb Replacement:** Ensure power is disconnected before replacing any bulbs. Allow bulbs to cool completely before handling. Replace with E12 base, B10 shape, 120V, 60W max incandescent or LED bulbs.
- **Periodic Inspection:** Periodically check all connections and components for tightness and wear.

7. TROUBLESHOOTING

If your chandelier is not functioning correctly, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Light does not turn on	No power to the fixture Loose wiring connection Faulty bulb(s)	Check circuit breaker or fuse. Verify all wire connections are secure (ensure power is off first). Replace bulb(s) with new ones.
Lights flicker or dim incorrectly	Incompatible dimmer switch Loose bulb connection Incorrect bulb type	Ensure dimmer is compatible with LED/incandescent bulbs. Tighten bulbs in sockets. Use only dimmable bulbs if a dimmer is installed.
Chandelier appears crooked	Improper mounting Uneven chain length	Re-check mounting hardware and ensure it is level. Adjust chain links to ensure the fixture hangs evenly.

If issues persist after troubleshooting, contact a qualified electrician or Schonbek customer support.

8. SPECIFICATIONS

Brand	Schonbek
Model Name	Siena
Item Model Number	RS84151N-22A
Product Dimensions	40.5"L x 40.5"W x 50.5"H
Item Weight	44 Pounds
Material	Stainless Steel (frame), Crystal (shade, embellishment)
Color	Heirloom Gold
Style	Clear Swarovski Spectra Crystals
Light Fixture Form	Chandelier
Number of Light Sources	17
Light Source Type	LED (compatible)
Bulb Base	E12
Voltage	120 Volts
Maximum Compatible Wattage	1020 Watts (60W per bulb x 17)
Brightness	7140 Lumen (with compatible bulbs)
Color Temperature	3000 Kelvin (with compatible bulbs)
Color Rendering Index (CRI)	100.00 (with compatible bulbs)
Average Life	50000 Hours (with compatible LED bulbs)
Finish Type	Powder Coated
Indoor/Outdoor Usage	Indoor
Specific Uses For Product	Indoor use only
Assembly Required	Yes
Certifications	UL, cUL, CSA rated
UPC	771857613254

9. WARRANTY AND SUPPORT

Your Schonbek Siena RS84151N-22A Chandelier includes a Manufacturer Warranty Certificate. Please refer to this document for specific terms, conditions, and duration of the warranty.

For technical assistance, replacement parts, or warranty claims, please contact Schonbek customer support directly. Contact information can typically be found on the manufacturer's website or on the warranty certificate

provided with your product.