

CANMOV B0CSVCP655

CANMOV Faux Leather Manual Loveseat Recliner

Model: B0CSVCP655

1. INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your CANMOV Faux Leather Manual Loveseat Recliner. Please read these instructions carefully before use and retain them for future reference.

Important Safety Information

- All foam and upholstered surfaces meet flammability standards.
- Keep the recliner away from open flames or high heat sources.
- Supervise children and pets to avoid entrapment risks within the reclining mechanism.
- Do not stand on the footrest when it is extended.
- Ensure sufficient clearance around the recliner when operating the reclining function.

2. PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present. The package typically includes:

- Loveseat Backrest Section
- Loveseat Base Section (with armrests and reclining mechanism)
- Assembly Hardware (bolts, washers, etc.)
- Instruction Manual

Note: Some components may be packed within the base section for shipping. Please check all packaging materials carefully.

3. ASSEMBLY INSTRUCTIONS

Assembly of your CANMOV Loveseat Recliner is designed to be straightforward. No special tools are typically required.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent damage.
2. **Attach Backrest:** Align the metal brackets on the backrest with the corresponding slots on the loveseat base. Slide the backrest down firmly until it locks into place. You should hear a click.
3. **Secure Backrest (if applicable):** If your model includes additional securing bolts, insert and tighten them as indicated in the included diagram.
4. **Verify Stability:** Once assembled, gently rock the loveseat to ensure all connections are secure and stable.



Figure 3.1: Product dimensions for reference during assembly. The loveseat measures approximately 37"D x 64"W x 40"H.

Product Details



Figure 3.2: Detailed view of the overstuffed headrest, comfortable armrest, manual opening lever, and firm footrest support.

4. OPERATING INSTRUCTIONS

Your manual loveseat recliner offers comfortable reclining positions for relaxation.

Reclining the Loveseat:

1. **Extend Footrest:** Locate the manual lever on the side of the loveseat (typically on the outer side of the armrest). Pull the lever to release and extend the footrest.
2. **Recline Backrest:** Once the footrest is extended, lean back gently against the backrest. The chair will adjust to your desired reclining position. You can achieve a maximum opening angle by continuing to lean back.

Returning to Upright Position:

1. **Retract Footrest:** Sit upright in the loveseat. Apply pressure with your heels to the center of the footrest to push it back into its closed position.
2. **Engage Lock:** Ensure the footrest is fully retracted and the backrest is in the upright position. The mechanism will lock into place.

Adjust to fit your need

fully relax your body and mood, better to enjoy your favorite entertainment or rest



Figure 4.1: The loveseat recliner can be adjusted to various positions for reading, watching TV, or napping.

PRODUCT FUNCTION



Figure 4.2: The recliner's function allows for comfortable positions suitable for reading, watching TV, and napping.

Your browser does not support the video tag.

Video 4.1: An official CANMOV video demonstrating the comfort and use of a CANMOV recliner chair, highlighting its relaxing features.

5. MAINTENANCE

To ensure the longevity and appearance of your faux leather recliner, follow these maintenance guidelines:

- **Regular Cleaning:** Dust the surface regularly with a soft, dry cloth.
- **Spot Cleaning:** For spills, immediately blot with a clean, dry cloth. For tougher stains, use a mild soap solution and a damp cloth, then wipe dry. Avoid harsh chemicals or abrasive cleaners.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading and cracking of the faux leather. Position the recliner away from direct sun exposure.
- **Mechanism Care:** Periodically check and tighten any loose bolts. The reclining mechanism is designed for durability but can benefit from occasional inspection.

6. TROUBLESHOOTING

If you encounter any issues with your recliner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Recliner does not recline smoothly.	Mechanism obstruction or loose connections.	Check for any objects obstructing the mechanism. Ensure all assembly bolts are tightened.
Footrest does not stay extended or retracts too easily.	Mechanism not fully engaged or worn springs.	Ensure you are sitting upright and applying firm pressure to retract. If the issue persists, contact customer support.
Loveseat feels unstable or wobbly.	Loose assembly bolts or uneven floor.	Check and tighten all assembly bolts. Ensure the loveseat is on a flat, even surface.

7. SPECIFICATIONS

Brand: CANMOV

Model: B0CSVCP655

Type: Loveseat Recliner

Color: Nut Brown

Upholstery Fabric Type: Faux Leather

Product Dimensions (D x W x H): 37" x 64" x 40"

Reclined Length: 39 Inches

Weight Limit: 350 Pounds

Seating Capacity: 2

Frame Material Type: FSC-Certified Wood

Fill Material: Sponge, Foam

Item Firmness Description: Medium

Reclining Position Count: 2 Position

Assembly Required: Yes

8. WARRANTY AND SUPPORT

Your CANMOV Faux Leather Manual Loveseat Recliner comes with a limited warranty. For specific warranty details, please refer to the documentation included with your purchase or contact CANMOV customer service.

Customer Support:

If you have any questions, concerns, or require assistance with assembly or use, please contact CANMOV customer service. We are committed to providing helpful, prompt, and friendly support. Every message is typically responded to within 24 hours.

For further information, you may visit the official CANMOV store: [CANMOV Store on Amazon](#)