

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ZEBRONICS](#) /

› [ZEBRONICS Zeb-Chime Wireless Earbuds User Manual](#)

ZEBRONICS Zeb-Chime

ZEBRONICS Zeb-Chime Wireless Earbuds User Manual

Model: Zeb-Chime

INTRODUCTION

Thank you for purchasing the ZEBRONICS Zeb-Chime Wireless Earbuds. This manual provides essential information for the proper setup, operation, and maintenance of your device. Please read it carefully before use to ensure optimal performance and longevity.

PACKAGE CONTENTS

- ZEBRONICS Zeb-Chime Wireless Earbuds
- Charging Case
- Ear Cushions (various sizes)

Please ensure all items are present. If any components are missing or damaged, contact customer support.

PRODUCT OVERVIEW

The Zeb-Chime earbuds offer wireless stereo sound with 13mm drivers, providing a rich audio experience. They feature touch controls, voice assistant support, and are splash-proof for versatile use. The charging case extends battery life up to 30 hours.



Image: ZEBRONICS Zeb-Chime Wireless Earbuds and Charging Case. The earbuds are black, with one earbud placed outside the open charging case, which also holds the other earbud. The case has the ZEBRONICS logo and a small LED indicator.

SETUP

1. Charging the Earbuds and Case

1. Place both earbuds into the charging case.
2. Connect a Type-C charging cable (not included) to the charging port on the case and to a compatible USB power source.
3. The LED indicator on the charging case will show charging status. Ensure the case and earbuds are fully charged before first use.

A full charge provides up to 30 hours of total playback time with the charging case.

2. Pairing with a Bluetooth Device

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your smartphone or Bluetooth-enabled device, navigate to the Bluetooth settings.
3. Search for available devices and select "ZEB-Chime" from the list.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

The earbuds support Bluetooth v5.3 for stable and efficient wireless connectivity.

OPERATING INSTRUCTIONS

Touch Controls

The Zeb-Chime earbuds feature intuitive touch controls on each earbud. Refer to the table below for common functions:

Action	Function
Single Tap (Left/Right)	Play/Pause Music, Answer/End Call
Double Tap (Right)	Next Track
Double Tap (Left)	Previous Track
Triple Tap (Left/Right)	Activate Voice Assistant
Long Press (2 seconds)	Reject Call



Image: ZEBRONICS Zeb-Chime Earbuds in their charging case, with a graphic overlay indicating "Extended playtime". The background shows people enjoying outdoor activities, highlighting the long battery life.

Voice Assistant

Triple tap either earbud to activate your device's voice assistant (e.g., Siri, Google Assistant). This allows for hands-free control of music, calls, and other functions.



Image: ZEBRONICS Zeb-Chime Earbuds next to a smartphone displaying an incoming call. This illustrates the call function and voice assistant support.

MAINTENANCE AND CARE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Water Resistance:** The earbuds are splash-proof. Avoid submerging them in water or exposing them to heavy rain. Dry them thoroughly if they get wet.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds and case frequently. Charge them regularly.

TROUBLESHOOTING

Earbuds not pairing:

Ensure both earbuds are in the charging case and fully charged. Open the case to activate pairing mode. On your device, forget "ZEB-Chime" from your Bluetooth list and try pairing again.

No sound from one earbud:

Place both earbuds back into the charging case, close the lid, and then open it again. This often re-syncs them. Check device audio settings to ensure balance is centered.

Charging issues:

Verify the Type-C cable and power adapter are working correctly. Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.

Voice assistant not responding:

Ensure the earbuds are properly connected to your device. Check your device's settings to confirm the voice assistant is enabled and configured correctly.

SPECIFICATIONS

Model Name	CHIME
Item Model Number	ZEB -SOUND BOMB 2
Connectivity Technology	Wireless (Bluetooth v5.3)
Driver Size	13mm
Speaker Impedance	32 Ohms
Playback Time	Up to 7.5 hours (earbuds), Up to 30 hours (with charging case)
Control Type	Touch, Voice Control
Special Features	Splash Proof, Fast Charging, Sweatproof, Built-In Microphone
Battery Type	Lithium Polymer (Rechargeable)
Charging Interface	Type-C
Weight	300 g (Package Weight)



Image: Graphic displaying key features of ZEBRONICS Zeb-Chime: Voice Assistant support, Bluetooth v5.3, Splash Proof, Touch Control, Call Function, and up to 30 hours of backup.

WARRANTY INFORMATION

The ZEBRONICS Zeb-Chime Wireless Earbuds come with a **6-month warranty** from the date of purchase. This warranty covers manufacturing defects. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

To claim warranty service, please retain your proof of purchase and contact ZEBRONICS customer support.

CUSTOMER SUPPORT

For technical assistance, warranty claims, or product inquiries, please contact ZEBRONICS customer support:

- Manufacturer Contact:** 044 4000 0004
- Online Support:** Visit the official ZEBRONICS website for FAQs and support resources.

 User Manual www.zebronics.com	<p><u>Zebronics ZEB-MIST Wireless Earbuds User Manual</u></p> <p>User manual for Zebronics ZEB-MIST wireless earbuds, covering features, specifications, pairing, charging, and usage instructions for a seamless audio experience.</p>
 User Manual www.zebronics.com	<p><u>Zebronics ZEB-CHIME Wireless Earbuds User Manual</u></p> <p>User manual for Zebronics ZEB-CHIME TWS wireless earbuds, detailing features, specifications, usage instructions, pairing, and charging.</p>
 User Manual www.zebronics.com	<p><u>Zebronics ZEB-PODS B15 Wireless Earbuds User Manual Features, Specifications, and Usage Guide</u></p> <p>Comprehensive user manual for Zebronics ZEB-PODS B15 wireless earbuds. Find detailed information on features, technical specifications, pairing instructions, usage controls, charging methods, and warranty policy.</p>
 User Manual www.zebronics.com	<p><u>Zebronics ZEB-FORCE Smart Watch User Manual</u></p> <p>Comprehensive user manual for the Zebronics ZEB-FORCE Smart Watch with BT Calling, detailing features, specifications, setup, and usage. Learn how to connect, charge, and use its various functions.</p>



[Zebronics ZEB-PODS O Wireless Earbuds User Manual](#)

User manual for Zebronics ZEB-PODS O Open-ear Wearable Stereo Earbuds, covering features, specifications, and usage instructions.



[Zebronics ZEB-SOUND BOMB 7 Wireless Earbuds User Manual](#)

User manual for the Zebronics ZEB-SOUND BOMB 7 Wireless Earbuds, covering features, specifications, product representation, and usage instructions.

Documents - ZEBRONICS – Zeb-Chime



[Zebronics ZEB-CHIME Wireless Earbuds User Manual](#)

User manual for Zebronics ZEB-CHIME TWS wireless earbuds, detailing features, specifications, usage instructions, pairing, and charging.

lang: score:44 filesize: 2.25 M page_count: 6 document date: 2024-03-23



[Zebronics ZEB-CHIME R Wireless Earbuds User Manual](#)

Explore the Zebronics ZEB-CHIME R Wireless Earbuds with this comprehensive user manual. Learn about features, specifications, pairing instructions, and usage guidelines for optimal audio experience.

lang: score:19 filesize: 6.18 M page_count: 6 document date: 2025-07-29