

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Walfront](#) /

› [Walfront 61-Key Hand-Rolled Electronic Piano User Manual](#)

### Walfront WALFRONTok9q6dvp32

# Walfront 61-Key Hand-Rolled Electronic Piano User Manual

Model: WALFRONTok9q6dvp32

## 1. INTRODUCTION

Thank you for choosing the Walfront 61-Key Hand-Rolled Electronic Piano. This portable and versatile instrument is designed for beginners and enthusiasts alike, offering a wide range of tones, rhythms, and features in a compact design. This manual provides essential information for the safe and effective use of your new electronic piano.

### Package Contents:

- 1 x 61-Key Hand-Rolled Piano
- 1 x Sustain Pedal
- 1 x USB Cable
- 1 x English User Manual





Image 1.1: The Walfront 61-Key Hand-Rolled Electronic Piano with its included accessories: sustain pedal, USB cable, and user manual.

## 2. SETUP

### 2.1 Charging the Piano

1. Before first use, fully charge the built-in lithium battery.
2. Connect the provided USB cable to the piano's charging port and a suitable USB power adapter (not included) or computer USB port.
3. A **red LED indicator** will illuminate during charging.
4. The LED indicator will turn **green** when the battery is fully charged.

## 2.2 Powering On/Off

Press the power button located on the control panel to turn the piano on or off.

## 2.3 Connecting the Sustain Pedal

Insert the sustain pedal's plug into the designated sustain pedal jack on the piano's control unit.



Image 2.1: The included sustain pedal, which connects to the main unit for extended note duration.

## 2.4 Wireless Connection (Bluetooth)

The piano supports Bluetooth connectivity, allowing wireless connection with mobile phone software, such as the 'Bubble Piano' application, and other compatible devices.



This electronic piano can be wirelessly connected with mobile phone software, such as the bubble piano software, as well as the phone.



Image 2.2: The electronic piano can be wirelessly connected to mobile devices for enhanced functionality and learning.

## 2.5 MIDI and External Device Connection

The hand-rolled piano can be connected to a microphone, speakers, other power amplifier devices, computers, tablets, and mobile phones via its MIDI function.

## 3. OPERATING INSTRUCTIONS

---



Image 3.1: The control panel of the hand-rolled piano, featuring various function buttons and a digital display.

### 3.1 Basic Playback

Once powered on, you can begin playing the piano by pressing the keys. The piano simulates a realistic piano sound through its high-fidelity stereo speakers.

## 3.2 Tone Adjustment

Press the **Tone** key to cycle through the 128 available tones. The screen will display a number indicating the currently selected tone.

## 3.3 Rhythm Adjustment

Press the **Rhy** key to select from the available rhythms. The screen will display a number indicating the currently selected rhythm.

## 3.4 Demo Songs

Press the **Demo** key to play pre-recorded demonstration songs. The screen will display a number indicating the current demo song.

## 3.5 Sound Effects

The piano includes sustain, vibrato, and drum sound effects. Refer to the control panel for specific buttons to activate these features.

# 4. MAINTENANCE

To ensure the longevity and optimal performance of your Walfront 61-Key Hand-Rolled Electronic Piano, follow these general maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the piano. Avoid using abrasive cleaners or solvents, as they may damage the finish.
- **Storage:** When not in use, roll up the piano gently and store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid sharp objects or excessive force on the keys and control panel.



Image 4.1: The hand-rolled piano in its compact, rolled-up state, ideal for storage and portability.

# 5. TROUBLESHOOTING

## 5.1 Low Battery Indication and Automatic Shutdown

The built-in lithium battery has a protection function. If the voltage drops below 2.9V, the piano may not turn on, or it may automatically shut down shortly after being turned on. This is to protect the lithium battery from deep discharge.

**Solution:** If this occurs, immediately connect the piano to a power source using the USB cable and charge it fully. Refer to Section 2.1 for charging instructions.

## 6. SPECIFICATIONS

Feature	Detail
Item Type	61-Key Hand-Rolled Electronic Piano
Brand	Walfront
Model Name	WALFRONTok9q6dvp32
Material	ABS+Silicone+Electronic Components
Number of Keyboard Keys	61
Tones	128
Rhythms	128
Sound Effects	Sustain, Vibrato, Drum Sounds
Connectivity	Bluetooth, MIDI
Power Supply Type	USB External Power Supply / Lithium Battery
Lithium Battery Capacity	1000mAh (Built-in)
Item Weight	2.86 pounds
Package Dimensions	12.6 x 9.06 x 3.54 inches

## 7. WARRANTY AND SUPPORT

Information regarding product warranty and customer support is not available in the provided product data. Please refer to the seller's or manufacturer's website for details on warranty coverage and how to obtain support for your Walfront 61-Key Hand-Rolled Electronic Piano.

