

[Manuals.plus](#) /

> [CASANOOKK](#) /

> CASANOOKK Magnetic Mesh Pen Holder Instruction Manual

CASANOOKK Magnetic Pencil Holder

CASANOOKK Magnetic Mesh Pen Holder Instruction Manual

1. PRODUCT OVERVIEW

The CASANOOKK Magnetic Mesh Pen Holder is designed to provide convenient storage for pens, markers, pencils, and other small office or household items. Its strong magnetic backing allows for easy attachment to various magnetic surfaces, such as whiteboards, blackboards, refrigerators, and metal lockers. Constructed from durable metal mesh, it offers visibility of contents and promotes air circulation.



Image 1.1: The CASANOOKK Magnetic Mesh Pen Holder shown on a desk, holding various markers and pens.

2. SETUP AND INSTALLATION

The magnetic pen holder requires no assembly. Simply attach it to any suitable magnetic surface.

1. **Identify a Magnetic Surface:** Ensure the desired surface (e.g., refrigerator, whiteboard, metal cabinet) is magnetic and clean.
2. **Position the Holder:** Place the back of the pen holder directly onto the magnetic surface. The integrated magnets will secure it in place.
3. **Test Stability:** Gently tug on the holder to ensure it is firmly attached before placing items inside.



Image 2.1: The magnetic pen holder displayed on both a refrigerator and a whiteboard, illustrating its versatile application.

Can be adsorbed on the blackboard



Image 2.2: The magnetic pen holder securely attached to a blackboard, demonstrating its use in an educational or office setting.

3. OPERATING INSTRUCTIONS

Once installed, the magnetic pen holder is ready for use.

- **Storage:** Place pens, markers, pencils, erasers, small notebooks, or other desk accessories into the compartments of the holder.
- **Organization:** Utilize the multiple compartments to separate different types of items for better organization.
- **Relocation:** To move the holder, simply lift it off the magnetic surface and re-attach it to a new desired location.



Image 3.1: The magnetic pen holder on a refrigerator, demonstrating its capacity to hold various items for easy access.



Image 3.2: A detailed view of the pen holder's contents, including writing instruments and small paper pads.

4. MAINTENANCE

To ensure the longevity and appearance of your magnetic pen holder, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the holder with a soft, damp cloth. For stubborn marks, a mild soap solution can be used, followed by drying thoroughly.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish.
- **Inspect Magnets:** Periodically check the magnets on the back for any signs of damage or detachment.



Image 4.1: A close-up view highlighting the strong magnetic points on the rear of the pen holder, responsible for secure attachment.

5. TROUBLESHOOTING

If you encounter any issues with your magnetic pen holder, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Holder slides down or falls off.	<ul style="list-style-type: none">• Surface is not sufficiently magnetic.• Holder is overloaded.• Magnets are dirty or damaged.	<ul style="list-style-type: none">• Ensure the surface is made of a strong magnetic material.• Reduce the weight of items stored in the holder.• Clean the magnets and the magnetic surface. If magnets are damaged, contact customer support.
Items fall out of the holder.	<ul style="list-style-type: none">• Holder is tilted or not level.• Items are too tall or unstable.	<ul style="list-style-type: none">• Re-position the holder to ensure it is level.• Arrange items carefully, placing taller items in the back or more stable positions.

6. SPECIFICATIONS

- **Model:** Magnetic Pencil Holder
- **Brand:** CASANOOKK
- **Material:** Metal, Stainless Steel
- **Color:** Black
- **Finish Type:** Polished
- **Product Dimensions:** 4.7"D x 7"W x 4.7"H (11.9 cm D x 17.8 cm W x 11.9 cm H)
- **Item Weight:** 8.1 ounces (0.23 Kilograms)
- **Number of Compartments:** 2
- **Shape:** Rectangular




Image 6.1: Dimensional diagram of the magnetic pen holder, indicating its width, depth, and height.

7. WARRANTY AND SUPPORT

This product is designed for durability and functionality. For specific warranty information or customer support inquiries, please refer to the product packaging or contact CASANOOKK customer service directly through their official channels. Contact details are typically provided with your purchase or on the manufacturer's website.