



[Manuals.plus](#) /

› [ULANZI Select](#) /

› ULANZI MG-002 Magnetic Phone Selfie Stick Tripod User Manual

## ULANZI Select MG-002

# ULANZI MG-002 Magnetic Phone Selfie Stick Tripod User Manual

Model: MG-002 | Brand: ULANZI Select

## 1. INTRODUCTION

Thank you for choosing the ULANZI MG-002 Magnetic Phone Selfie Stick Tripod. This versatile accessory is designed to enhance your mobile photography and videography experience, offering stability, extended reach, and convenient remote control. Please read this manual carefully before using the product to ensure proper operation and to maximize its potential.



Figure 1: ULANZI MG-002 Magnetic Phone Selfie Stick Tripod

This image displays the ULANZI MG-002 Magnetic Phone Selfie Stick Tripod in three states: folded for portability, extended as a handheld selfie stick with a phone, and fully deployed as a tripod supporting a phone. A small remote control is also visible.

## 2. SAFETY INFORMATION

- Do not expose the product to extreme temperatures, direct sunlight, or high humidity.
- Keep the product away from water and other liquids.
- Avoid dropping or subjecting the product to strong impacts.
- Do not attempt to disassemble or modify the product. This will void the warranty.
- Ensure the tripod legs are fully extended and stable on a flat surface before mounting a device.
- Verify your phone is securely attached to the magnetic mount before use.

- Keep the remote control away from small children.

### 3. WHAT'S IN THE BOX

The ULANZI MG-002 package includes the following items:

- 1 x ULANZI MG-002 Magnetic Phone Selfie Stick Tripod
- 1 x Detachable Bluetooth Remote Control
- 1 x User Manual (this document)

### 4. PRODUCT COMPONENTS

Familiarize yourself with the main parts of your ULANZI MG-002:

1. **Magnetic Phone Mount:** Features a strong 54N magnet for secure phone attachment.
2. **Extendable Pole:** 7-section adjustable pole, extending from 450mm (17.7in) to 1640mm (64.5in).
3. **Tripod Legs:** Foldable legs that provide stable support when deployed.
4. **Bluetooth Remote Control:** Detachable remote for wireless photo and video capture.
5. **Rotation Joint:** Allows 360° rotation for portrait and landscape modes.
6. **Base Button:** Button at the base to release and fold the tripod legs.



Figure 2: Aluminum Alloy Construction

This image highlights the durable aluminum alloy construction of the tripod's base, indicating robust build quality.

## Aluminum Alloy Built



Figure 3: Anti-slip Silicone Rubber Feet

This image shows the anti-slip silicone rubber pads on the tripod feet, designed to provide enhanced stability on various surfaces.

## 5. SETUP GUIDE

### 5.1 Unfolding the Tripod

1. Hold the main body of the selfie stick.
2. Press the "PUSH" button located at the bottom of the handle.
3. Gently pull the legs outwards until they fully extend and lock into place, forming a stable tripod base.

# Max Height up to 1.64m

7-section extendable pole allows for flexible height adjustment to suit your needs.





Figure 4: Expanding the Tripod and Extending the Pole

This diagram illustrates the process of deploying the tripod legs by pressing the base button and extending the telescopic pole to its maximum height of 1.64 meters.

## 5.2 Extending the Pole

1. With the tripod legs folded or unfolded, grasp the top section of the pole.
2. Pull upwards to extend the pole sections. The pole can be extended in 7 sections to your desired height, up to 64.5 inches (1640mm).
3. Ensure all sections are fully extended and stable before use.

## 5.3 Attaching Your Phone

1. Ensure your iPhone (12 series or newer) or other MagSafe-compatible smartphone/case is ready.
2. Align the back of your phone with the magnetic phone mount on the tripod.
3. The strong 54N magnet will securely attach your phone instantly.

# Swift Attachment and Removal

Reinforced N52 magnets can support weights of up to 5kg, ensuring a secure and stable attachment.



Figure 5: Swift Magnetic Attachment

This image demonstrates the quick and secure magnetic attachment of a smartphone to the tripod mount, highlighting the strong N52 magnets capable of supporting weights up to 5kg.

**Ulanzi x MG-002**

## 64.5in Magnetic Phone Selfie Stick

Selfie | Video | Streaming

- Magnetic Connection
- Remote Controller
- Portable Storage
- 360° Rotation

Figure 6: Strong Magnetic and Wide Compatibility

This visual confirms the strong magnetic connection for iPhone 12, 13, 14, and 15 series, and wide compatibility with other smartphone models when used with a MagSafe-compatible case.

#### 5.4 Pairing the Bluetooth Remote Control

1. Locate the detachable Bluetooth remote control, usually stored in a slot on the tripod handle.
2. Press and hold the button on the remote until the indicator light starts blinking, indicating it's in pairing mode.
3. On your smartphone, go to Bluetooth settings and search for available devices.
4. Select "ULANZI Remote" or a similar name from the list to pair.
5. Once paired, the indicator light on the remote will stop blinking and remain solid.

# Wireless Remote up to 10m

With a detachable remote, you can easily take photos or videos with the press of a button.

**Hidden  
Bluetooth  
Remote**

Figure 7: Wireless Remote Control

This image illustrates the convenience of the detachable remote control, allowing users to capture photos or videos from up to 10 meters (33 feet) away.

## 6. OPERATING INSTRUCTIONS

### 6.1 Using as a Selfie Stick

- Keep the tripod legs folded.
- Extend the pole to your desired length.
- Attach your phone to the magnetic mount.
- Use the Bluetooth remote to capture photos or start/stop video recording.



Figure 8: Selfie Stick Usage

This image shows two individuals utilizing the ULANZI MG-002 as an extended selfie stick, demonstrating its use for capturing wider group shots or scenic backgrounds.

### 6.2 Using as a Tripod

- Unfold the tripod legs as described in Section 5.1.
- Place the tripod on a stable, flat surface.
- Extend the pole to your desired height.
- Attach your phone to the magnetic mount.
- Use the Bluetooth remote for hands-free operation.


# Great Versatility

It is compatible with other accessories featuring MagSafe keeping your creativity flowing.

## -Vlog



## -Influencer Marketing



## -Livestreaming



Figure 9: Versatile Tripod Applications

This image showcases the product's versatility, illustrating its suitability for various applications such as vlogging, influencer marketing content creation, and stable livestreaming setups.

### 6.3 Adjusting Phone Orientation (Portrait/Landscape)

- The magnetic phone mount features a 360° rotation joint.
- Simply rotate your phone on the mount to switch between portrait (vertical) and landscape (horizontal) modes without detaching it.



**NEVER FALL OFF**

Figure 10: Horizontal and Vertical Shot Capability

This diagram illustrates the flexibility of the phone mount, allowing for a 200-degree tilt and easy 360-degree rotation to switch between horizontal and vertical shooting orientations.

## 7. MAINTENANCE

- **Cleaning:** Wipe the product with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, fold the tripod completely and store it in a cool, dry place away from direct sunlight.
- **Battery:** The remote control uses a small button cell battery. If the remote stops responding, replace the battery.



Figure 11: Easy to Carry and Store

This image demonstrates the compact folded size (302mm) and lightweight nature (355g) of the ULANZI MG-002, making it convenient to carry in a bag for on-the-go use.

## 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote control not pairing.	Low battery in remote; Bluetooth not enabled on phone; remote not in pairing mode.	Replace remote battery; enable Bluetooth; press and hold remote button until light blinks.
Phone not securely attaching.	Phone not MagSafe compatible; thick non-MagSafe case; foreign objects on magnet.	Ensure phone/case is MagSafe compatible; remove thick cases; clean magnetic surface.
Tripod unstable.	Legs not fully extended; uneven surface; excessive weight.	Ensure legs are locked; move to flat surface; do not exceed weight capacity.

Problem	Possible Cause	Solution
Pole not extending/retracting smoothly.	Dirt or debris in sections.	Clean pole sections gently with a dry cloth. Avoid forcing.

## 9. SPECIFICATIONS

Feature	Detail
Model Number	M001-EU (MG-002)
Material	Aluminum Alloy
Weight	355 Grams (12.5 ounces)
Folded Size	Approx. 302mm (11.8 inches)
Minimum Height	450mm (17.7 inches)
Maximum Height	1640mm (64.5 inches)
Sections	7 Sections
Magnetic Strength	54N
Remote Control Range	Up to 10m (33ft)
Compatible Devices	iPhone 12/13/14/15 Series, other smartphones with MagSafe case

## 10. WARRANTY INFORMATION

ULANZI Select products are manufactured to the highest quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included with your purchase or visit the official ULANZI website for detailed warranty terms and conditions. The warranty does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear.

## 11. CUSTOMER SUPPORT

For technical support, troubleshooting assistance, or warranty inquiries, please contact ULANZI Select customer service through the following channels:

- **Website:** Visit the official ULANZI website for FAQs and support resources.
- **Email:** Refer to your product packaging or the ULANZI website for customer service email.
- **Online Store:** For purchases made on Amazon, you can contact the seller directly through your order history.

Please have your product model number (MG-002) and purchase details ready when contacting support.

